SUZUKI

PARTS CATALOGUE

DF300AP/250AP

DF300AP
DF250AP

SUZUKI

Way of Life!

OUTBOARD MOTOR

E03

2018-8

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF250A/300A production start 2018.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E.NO.	: Engine number	OS	: Over size
F.NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: With
LH(PORT)	: Left hand side	X,XX	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
～123456	: Up to E.NO.30002F-123456	PTT	: Power trim and tilt
123456～	: From E.NO.30002F-123456		

12 x 34 x 5.6····· Figures in the description column show the dimensions of parts.
ID OD T(or W,L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual. When assembling, use "SUZUKI SERVICE MANUAL".

6. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	COLOR	ENGINE No.
DF250AP	E03	25003P	X,XX	YAY,Y5S	25003P-910001～
DF300AP	E03	30002P	L,X,XX	YAY,Y5S	30002P-910001～

PREFACE

Quand il devient nécessarie de remplacer des pièces sur SUZUKI MOTEURS HORSBOARD toujours utiliser les PIECES D'ORIGINE SUZUKI qui ont été soumises à des contriles de qualité sévères leur garantissant qualité et performance impeccables.

Ce catalogue de pièces détachées couvre la liste de toutes les pièces de rechange pour SUZUKI DF250A/300A production start 2018.

INSTRUCTIONS POUR UTILISER LE CATALOGUE

1. DIMENSIONS

Les dimensions des pièces dans ce catalogue sont indiquées en unités de millimètres.

2. ABREVIATIONS

Les abréviations utilisées dans ce catalogue sont les suivantes:

AR	: Comme requis	NT	: Nombre de dents
ASSY	: Assemblage	OPT	: Sur option
E.NO.	: Numéro du moteur	OS	: Sur-dimensionné
F.NO.	: Numéro du chfssis	T	: Epaisseur
ID	: Diamètre intérieur	US	: Sous-dimensionné
OD	: Diamètre extérieur	W	: Largeur
L	: Longueur		
LH(PORT)	: Côté gauche		
RH(STBD)	: Côte droit		
～123456	: Jusqu'à E.NO.30002F-123456		
123456～	: Depuis E.NO.30002F-123456		

12 x 34 x 5.6…… Les chiffres dans la colonne
| | | remarques montrent les dimensions
ID OD T(or W,L) des pieces comme suit.

→12345-56781 (N^{O} de pieces) : indique que le numéro des pièces a été ehangé en 12345-56781 et que les nouvelles pièces sont interchange-ables avec les anciennes, mais que celles-cine sont pas interchangeables avec les nouvelles.

←12345-56781 (N^{O} de pieces) : indique que les anciennes et nouvelles pièces sont interchangeables les unes avec les autres et sont utilisables chacune.

3. PIECES INTERNES DE L'ASSEMBLAGE

Les numéros de pièces qui comportent un point (.) avant la désignation de pièce détachée indique la pièce interne se rapportant à l'assemblage.

4. AVIS DE MODIFICATION

Un bulletin de pièces détachées vous sera envoyé à tout moment opportun quand des changements de pièces ont lieu, y compris les modifications de pièces interchangeables entre les nouvelles et anciennes pièces.

5. A NOTER

5-1. II existe certaines pièces différentes de celles de rechange pour les modèles de production vu des rainsons administratives et dont l'usage est commun avec celles d'autres modèles.

5-2. Concernant les durites en caoutchouc et les tuyaux en vinyle, ne pas manquer de les couper à la bonne longueur comme indiqué dans le catalogue des pièces détachées ou selon ce qui est utile pour le véhicule affecté.

5-3. Noter que les dessins à la page d'illustration servent à titre de référence pour les numéros de pièces détachées, et non pas comme référence pour l'assemblage. Pour cette dernière opération, se reporter au "MANUEL D'ENTRETIEN SUZUKI".

6. NOM DU MODELE / NUMERO DE SERIE DU MOTEUR

MODELE	DESTINATION	TYPE	HOUTEUR DE BARRE D'ARCASSE	COULEUR	N^{O} DELA MOTEUR
DF250AP	E03	25003P	X,XX	YAY,Y5S	25003P-910001～
DF300AP	E03	30002P	L,X,XX	YAY,Y5S	30002P-910001～

MILLIMETER → INCH CONVERSION CHART
TABLEAU DE CONVERSION DE MILLIMETRES → POUCES

	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read
Mode de lecture


	0	1	2	3	4
00	…	…	…	…	…
10	…	…	…	…	…
20	…	…	…	0.906	…
30	…	…	…	…	…

23 millimeters equal 0.906 in
23 millimètres égalent 0.906 pouce

Contents are subject to change without notice or obligation.


Les matières traitées sont susceptibles d'être modifiées sans préavis obligation de notre part.

FIG.111A




DF300A_E03_010_111A
CYLINDER HEAD

FIG.113A




DF300A_E03_010_113A
CYLINDER BLOCK

FIG.116A




DF300A_E03_010_116A
CRANKSHAFT

FIG.119A




DF300A_E03_010_119A
TIMING CHAIN

FIG.121A




DF300A_E03_010_121A
CAMSHAFT

FIG.121B




DF300A_E03_010_121B
CAMSHAFT

FIG.122A




DF300A_E03_010_122A
INTAKE MANIFOLD

FIG.136A




DF300A_E03_010_136A
TIMING GEAR COVER

FIG.140A




DF300A_E03_012_140A
EXHAUST COVER

FIG.144A




DF300A_E03_012_144A
FUEL INJECTOR

FIG.147A




DF300A_E03_012_147A
FUEL PUMP,FUEL VAPOR SEPARATOR

FIG.160A




DF300A_E03_012_160A
WATER PUMP

FIG.160B




DF300A_E03_012_160B
WATER PUMP

FIG.162A




DF300A_E03_012_162A
THERMOSTAT

FIG.163A




DF300A_E03_012_163A
THROTTLE BODY

FIG.175A




DF300A_E03_012_175A
OIL PUMP

FIG.180A




DF300A_E03_012_180A
OIL PAN

FIG.204A




DF300A_E03_012_204A
CLUTCH SHAFT

FIG.204B




DF300A_E03_012_204B
CLUTCH SHAFT

FIG.206A




DF300A_E03_012_206A
CLUTCH ROD

FIG.206B




DF300A_E03_012_206B
CLUTCH ROD

FIG.220A




DF300A_E03_012_220A
TRANSMISSION

FIG.220B




DF300A_E03_012_220B
TRANSMISSION

FIG.301A




DF300A_E03_012_301A
STARTING MOTOR

FIG.303A




DF300A_E03_018_303A
MAGNETO

FIG.310A




DF300A_E03_018_310A
RECTIFIER/IGNITION COIL

FIG.315A




DF300A_E03_018_315A
SENSOR

FIG.315B




DF300A_E03_018_315B
SENSOR

FIG.322A




DF300A_E03_018_322A
HARNESS

FIG.326A




DF300A_E03_018_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326B




DF300A_E03_018_326B
PTT SWITCH/ENGINE CONTROL UNIT

FIG.331A




DF300A_E03_018_331A
KEY LESS START

FIG.335A




DF300A_E03_018_335A
CLAMP BRACKET

FIG.335B




DF300A_E03_018_335B
CLAMP BRACKET

FIG.336A




DF300A_E03_018_336A
SWIVEL BRACKET

FIG.336B




DF300A_E03_018_336B
SWIVEL BRACKET

FIG.337A




DF300A_E03_018_337A
TRIM CYLINDER

FIG.337B




DF300A_E03_018_337B
TRIM CYLINDER

FIG.340A




DF300A_E03_018_340A
PTT MOTOR

FIG.340B




DF300A_E03_018_340B
PTT MOTOR

FIG.401A




DF300A_E03_012_401A
ENGINE HOLDER

FIG.401B




DF300A_E03_012_401B
ENGINE HOLDER

FIG.405A




DF300A_E03_012_405A
DRIVE SHAFT HOUSING

FIG.405B




DF300A_E03_012_405B
DRIVE SHAFT HOUSING

FIG.405C




DF300A_E03_012_405C
DRIVE SHAFT HOUSING

FIG.407A




DF300A_E03_012_407A
GEAR CASE

FIG.407B




DF300A_E03_012_407B
GEAR CASE

FIG.410A




DF300A_E03_012_410A
SIDE COVER

FIG.410B




DF300A_E03_010_410B
SIDE COVER

FIG.420A




DF300A_E03_010_420A
ENGINE COVER

FIG.420B




DF300A_E03_010_420B
ENGINE COVER

FIG.475A




DF300A_E03_010_475A
SQUEEZE PUMP

FIG.520A




DF300A_E03_010_520A
OPT:FLUSH MOUNT REMOCON

FIG.522A




DF300A_E03_010_522A
OPT:HARNESS (1)

FIG.523A




DF300A_E03_010_523A
OPT:HARNESS (2)

FIG.530A




DF300A_E03_010_530A
OPT:SWITCH

FIG.535A




DF300A_E03_018_535A
OPT:KEY LESS START

FIG.540A




DF300A_E03_018_540A
OPT:REMOTE CONTROL ASSY DUAL

FIG.543A




DF300A_E03_018_543A
OPT:REMOTE CONTROL ASSY SINGLE

FIG.585A




DF300A_E03_018_585A
OPT:GASKET SET

FIG.601A



DF300A_E03_018_601A
OPT:MULTI FUNCTION GAUGE (1)

FIG.602A



DF300A_E03_018_602A
OPT:MULTI FUNCTION GAUGE (2)

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11101-98J03	HEAD ASSY, CYLINDER STBD	1	
2	11128-90J00	.BOLT, CAM SHAFT HOUSING	16	
3	09206-08001	.PIN (8X11)	14	
4	01550-06207	.BOLT	4	
5	11103-98J03	HEAD ASSY, CYLINDER PORT	1	
6	11128-90J00	.BOLT, CAM SHAFT HOUSING	16	
7	09206-08001	.PIN (8X11)	14	
8	01550-06207	.BOLT	2	
9	11116-93J01	PLUG	4	
10	11141-98J10	GASKET, CYL HEAD STBD	1	
11	11142-98J10	GASKET, CYL HEAD PORT	1	
12	11216-98L10	GASKET	4	
13	11261-93J00	COVER, PROTECTION ANODE	4	
14	09280-22019	O RING (D:1.9,ID:21.8)	4	
15	55321-87J01	ANODE, PROTECTION	4	
16	09103-06281	BOLT (6X14)	4	
17	01550-08207	BOLT	4	
18	01550-08607	BOLT	5	
19	01550-08607	BOLT	4	
20	09206-14004	PIN (14X11.4X23)	4	
21	11170-93J01	COVER, CYL HEAD STBD	1	
22	11180-98J01	COVER, CYLINDER HEAD PORT	1	
23	11173-93J00	PLATE, BREATHER STBD	1	
24	11183-93J00	PLATE, BREATHER PORT	1	
25	11179-93J00	GASKET, CYL HEAD COVER STBD	1	
26	11189-93J00	GASKET, CYL HEAD COVER PORT	1	
27	09206-08001	PIN (8X11)	1	
28	02112-0612A	SCREW	14	
29	01547-06257	BOLT	16	
30	01547-06507	BOLT	6	
31	11382-93J00	CAP, OIL FILLER	1	
32	09280-26006	O RING (D:3.1,ID:26.4)	1	
33	09482-00427	SPARK PLUG (BKR6E)	6	NGK
34	11291-93J00	HOOK, ENGINE	2	

FIG.111A




FIG.111A (1-B-3) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	01550-08207	BOLT	4	
36	11115-93J10-001	GUIDE, VALVE (OS:0.5)	24	OPT
37	11291-98J00	HOOK, ENGINE	1	OPT

FIG.113A




FIG.113A (1-B-4) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11293-98J00	HOOK, ENGINE FRONT	1	
2	01550-08207	BOLT	2	
3	11301-98J30	BLOCK SET, CYLINDER	1	
4	11112-93J00	.PLUG, OIL VENTURI	2	
5	11117-93J10	.BOLT, CRANKCASE	12	
6	11117-98J10	.BOLT, CRANKCASE STUD	4	
7	11119-93J00	.BOLT, CYLINDER HEAD	16	
8	11216-98L00	.GASKET, M26 PLUG	3	
9	09248-26001	.PLUG (26X11)	3	
10	09160-18031	.WASHER (18.5X28X2.6)	2	
11	09248-18006	.PLUG (18X8)	2	
12	09159-10116	.NUT	4	
13	09206-13019	.PIN (10.4X13X16)	5	
14	16700-93J00	.VALVE, PISTON JET	1	
15	09280-10009	..O RING (D:1.3,ID:9.8)	1	
16	09280-10016	..O RING (D:1.9,ID:9.8)	1	
17	07130-0616A	.BOLT	1	
18	07130-0510A	.BOLT	6	
19	11390-98J00	.JET, PISTON COOLING	6	
20	09280-06005	..O RING (D:1.9,ID:5.7)	6	
21	09246-05006	.PLUG (1/8PT,H:8)	1	
22	11330-93J01	COVER, CRANKCASE WTR JKT	1	
23	11332-93J00	GASKET, CRANKCASE WTR JKT COV	1	
24	01550-06207	BOLT	12	
25	16430-93J00	COVER, OIL GALLERY	1	
26	16431-93J00	PLATE, OIL GALLERY	1	
27	16433-93J00	GASKET, OIL GALLERY	2	
28	01550-0835A	BOLT	9	
29	01550-08457	BOLT	8	
30	16510-96J10	FILTER ASSY, OIL	1	

FIG.116A




FIG.116A (1-B-5) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-98J00-0B0	PISTON	6	
2	12140-98J00	RING SET, PISTON	6	
3	12151-02F00	PIN, PISTON	6	
4	09381-22010	CIRCLIP	12	
5	12160-98J00	CONNROD ASSY	6	
6-1	12100-98810-0A0	BEARING SET, CONNROD	6	GREEN
6-2	12100-98810-025	BEARING SET, CONNROD (US:0.25)	6	OPT
7	12220-98J00	CRANKSHAFT	1	
8-1	12340-98J00-0A0	BEARING SET, CRANKSHAFT	4	BLACK
8-2	12340-98J00-0B0	BEARING SET, CRANKSHAFT	4	NON
8-3	12340-98J00-0C0	BEARING SET, CRANKSHAFT	4	YELLOW
8-4	12340-98J00-0D0	BEARING SET, CRANKSHAFT	4	BLUE
8-5	12340-98J00-0E0	BEARING SET, CRANKSHAFT	4	PINK
8-6	12300-98810-0AA	BEARING SET, CRANKSHAFT	4	OPT US:0.25 RED/BLACK
8-7	12300-98810-0BA	BEARING SET, CRANKSHAFT	4	OPT US:0.25 RED
8-8	12300-98810-0CA	BEARING SET, CRANKSHAFT	4	OPT US:0.25 RED/YELLOW
8-9	12300-98810-0DA	BEARING SET, CRANKSHAFT	4	OPT US:0.25 RED/BLUE
8-10	12300-98810-0EA	BEARING SET, CRANKSHAFT	4	OPT US:0.25 RED/PINK

FIG.116A




FIG.116A (1-B-6) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
9-1	12300-98821	BEARING SET, CRANK THRUST	1	
9-2	12300-98821-012	BEARING SET, CRANK THRUST	1	OPT OS:0.12
10	12242-98J00	GEAR, DRIVE (NT:32)	1	
11	09160-10104	WASHER (10.5X50X3.2)	1	
12	01550-1025A	BOLT	1	
13	09283-91001	OIL SEAL (91X109X10)	1	
14	12100-98J00-050	PISTON SET (OS:0.50)	6	OPT
15	12140-98J00-050	.RING SET, PISTON (OS:0.50)	6	OPT

FIG.119A




FIG.119A (1-B-7) TIMING CHAIN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12730-98J02	GEAR, DRIVEN (NT:40)	1	
2	09262-40018	BEARING (40X80X18)	1	LOWER
3	09262-40017	BEARING (40X80X18)	1	UPPER
4	09283-32044	OIL SEAL (32X47X6)	1	
5	12734-93J00	HOLDER, DRIVEN GEAR	1	
6	09280-70012	O RING (D:5.7,ID:69.6)	1	
7	01550-0855A	BOLT	4	
8	12761-93J00	CHAIN, TIMING 1ST	1	
9	12762-93J00	CHAIN, TIMING 2ND	2	
10	12770-93J00	BASE, TIMING CHAIN GUIDE NO.1	1	
11	12778-93J00	GASKET, GUIDE BASE	1	
12	04211-13149	PIN	2	
13	01550-0830A	BOLT	2	
14	12771-93J00	SHOE, TIMING CHAIN UPPER	1	
15	12775-93J00	SHOE, TIMING CHAIN LOWER	1	
16	12772-93J00	GUIDE, TIMING CHAIN NO.2	1	
17	01550-0830A	BOLT	2	
18	12810-93J00	TENSIONER ASSY, TIMING CHAIN	1	
19	12813-73G00	.PAD, TIMING CHAIN TENSIONER	1	
20	12812-90J00	SPACER, TIMING CHAIN TENSIONER	1	
21	01550-0830A	BOLT	1	
22	12831-93J01	ADJUSTER ASSY, TENSIONER	1	
23	12832-93J00	TENSIONER ASSY, STBD	1	
24	12833-93J00	TENSIONER ASSY, PORT	1	
25	01550-0620A	BOLT	2	
26	01550-0620A	BOLT	4	

DF300A_E03_019_119A
TIMING CHAIN

FIG.121A




FIG.121A (1-B-8) CAMSHAFT (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-98J10	CAMSHAFT, INTAKE STBD	1	
2	12705-98J10	CAMSHAFT, INTAKE PORT	1	
3	12721-98J10	CAMSHAFT, EXH STBD	1	
4	12729-98J20	CAMSHAFT, EXH PORT	1	
5	12740-93J00	SPROCKET ASSY, CAM TIMING (NT:22/32)	2	
6	12748-93J00	SPROCKET, EXH CAMSHAFT (NT:22)	2	
7	12753-93J00	BOLT, INTAKE CAMSHAFT	2	
8	12749-93J00	BOLT, CAMSHAFT EXHAUST	2	
9	09202-05032	PIN (5X12)	3	
10	09261-05006	PIN (5X18)	1	
11	16550-93J00	VALVE, OIL CONTROL	2	
12	16555-93J01	GASKET, VALVE	2	
13	01550-06257	BOLT	8	
14	12891-93J00	TAPPET	24	
15-1	12892-93J00-218	SHIM, TAPPET (T:2.175)	AR	
15-2	12892-93J00-220	SHIM, TAPPET (T:2.200)	AR	
15-3	12892-93J00-223	SHIM, TAPPET (T:2.225)	AR	
15-4	12892-93J00-225	SHIM, TAPPET (T:2.250)	AR	
15-5	12892-93J00-228	SHIM, TAPPET (T:2.275)	AR	
15-6	12892-93J00-230	SHIM, TAPPET (T:2.300)	AR	
15-7	12892-93J00-233	SHIM, TAPPET (T:2.325)	AR	
15-8	12892-93J00-235	SHIM, TAPPET (T:2.350)	AR	
15-9	12892-93J00-238	SHIM, TAPPET (T:2.375)	AR	
15-10	12892-93J00-240	SHIM, TAPPET (T:2.400)	AR	
15-11	12892-93J00-243	SHIM, TAPPET (T:2.425)	AR	
15-12	12892-93J00-245	SHIM, TAPPET (T:2.450)	AR	
15-13	12892-93J00-248	SHIM, TAPPET (T:2.475)	AR	
15-14	12892-93J00-250	SHIM, TAPPET (T:2.500)	AR	
15-15	12892-93J00-253	SHIM, TAPPET (T:2.525)	AR	

FIG.121A




FIG.121A (1-B-9) CAMSHAFT (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15-16	12892-93J00-255	SHIM, TAPPET (T:2.550)	AR	
15-17	12892-93J00-258	SHIM, TAPPET (T:2.575)	AR	
15-18	12892-93J00-260	SHIM, TAPPET (T:2.600)	AR	
15-19	12892-93J00-263	SHIM, TAPPET (T:2.625)	AR	
15-20	12892-93J00-265	SHIM, TAPPET (T:2.650)	AR	
15-21	12892-93J00-268	SHIM, TAPPET (T:2.675)	AR	
15-22	12892-93J00-270	SHIM, TAPPET (T:2.700)	AR	
15-23	12892-93J00-273	SHIM, TAPPET (T:2.725)	AR	
15-24	12892-93J00-275	SHIM, TAPPET (T:2.750)	AR	
15-25	12892-93J00-278	SHIM, TAPPET (T:2.775)	AR	
15-26	12892-93J00-280	SHIM, TAPPET (T:2.800)	AR	
15-27	12892-93J00-283	SHIM, TAPPET (T:2.825)	AR	
15-28	12892-93J00-285	SHIM, TAPPET (T:2.850)	AR	
15-29	12892-93J00-288	SHIM, TAPPET (T:2.875)	AR	
15-30	12892-93J00-290	SHIM, TAPPET (T:2.900)	AR	
15-31	12892-93J00-293	SHIM, TAPPET (T:2.925)	AR	
15-32	12892-93J00-295	SHIM, TAPPET (T:2.950)	AR	
15-33	12892-93J00-298	SHIM, TAPPET (T:2.975)	AR	
15-34	12892-93J00-300	SHIM, TAPPET (T:3.000)	AR	
16	12911-98J00	VALVE, INTAKE	12	
17	12915-93J60	VALVE, EXHAUST	12	
18	12921-93J11	SPRING, VALVE	24	
19	12931-78G00	RETAINER, VALVE SPRING	24	
20	12932-24400	COTTER, VALVE	48	
21	12933-69G10	SEAT, VALVE SPRING	24	
22	09289-05012	OIL SEAL (5.5X11.5X9.3)	24	

DF300A E03

FIG.121B




FIG.121B (1-B-10) CAMSHAFT (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-98J20	CAMSHAFT, INTAKE STBD	1	
2	12705-98J10	CAMSHAFT, INTAKE PORT	1	
3	12721-98J10	CAMSHAFT, EXH STBD	1	
4	12729-98J20	CAMSHAFT, EXH PORT	1	
5	12740-93J00	SPROCKET ASSY, CAM TIMING (NT:22/32)	2	
6	12748-93J00	SPROCKET, EXH CAMSHAFT (NT:22)	2	
7	12753-93J00	BOLT, INTAKE CAMSHAFT	2	
8	12749-93J00	BOLT, CAMSHAFT EXHAUST	2	
9	09202-05032	PIN (5X12)	3	
10	09261-05006	PIN (5X18)	1	
11	16550-93J00	VALVE, OIL CONTROL	2	
12	16555-93J01	GASKET, VALVE	2	
13	01550-06257	BOLT	8	
14	12891-93J00	TAPPET	24	
15-1	12892-93J00-218	SHIM, TAPPET (T:2.175)	AR	
15-2	12892-93J00-220	SHIM, TAPPET (T:2.200)	AR	
15-3	12892-93J00-223	SHIM, TAPPET (T:2.225)	AR	
15-4	12892-93J00-225	SHIM, TAPPET (T:2.250)	AR	
15-5	12892-93J00-228	SHIM, TAPPET (T:2.275)	AR	
15-6	12892-93J00-230	SHIM, TAPPET (T:2.300)	AR	
15-7	12892-93J00-233	SHIM, TAPPET (T:2.325)	AR	
15-8	12892-93J00-235	SHIM, TAPPET (T:2.350)	AR	
15-9	12892-93J00-238	SHIM, TAPPET (T:2.375)	AR	
15-10	12892-93J00-240	SHIM, TAPPET (T:2.400)	AR	
15-11	12892-93J00-243	SHIM, TAPPET (T:2.425)	AR	
15-12	12892-93J00-245	SHIM, TAPPET (T:2.450)	AR	
15-13	12892-93J00-248	SHIM, TAPPET (T:2.475)	AR	
15-14	12892-93J00-250	SHIM, TAPPET (T:2.500)	AR	
15-15	12892-93J00-253	SHIM, TAPPET (T:2.525)	AR	

FIG.121B




FIG.121B (1-B-11) CAMSHAFT (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15-16	12892-93J00-255	SHIM, TAPPET (T:2.550)	AR	
15-17	12892-93J00-258	SHIM, TAPPET (T:2.575)	AR	
15-18	12892-93J00-260	SHIM, TAPPET (T:2.600)	AR	
15-19	12892-93J00-263	SHIM, TAPPET (T:2.625)	AR	
15-20	12892-93J00-265	SHIM, TAPPET (T:2.650)	AR	
15-21	12892-93J00-268	SHIM, TAPPET (T:2.675)	AR	
15-22	12892-93J00-270	SHIM, TAPPET (T:2.700)	AR	
15-23	12892-93J00-273	SHIM, TAPPET (T:2.725)	AR	
15-24	12892-93J00-275	SHIM, TAPPET (T:2.750)	AR	
15-25	12892-93J00-278	SHIM, TAPPET (T:2.775)	AR	
15-26	12892-93J00-280	SHIM, TAPPET (T:2.800)	AR	
15-27	12892-93J00-283	SHIM, TAPPET (T:2.825)	AR	
15-28	12892-93J00-285	SHIM, TAPPET (T:2.850)	AR	
15-29	12892-93J00-288	SHIM, TAPPET (T:2.875)	AR	
15-30	12892-93J00-290	SHIM, TAPPET (T:2.900)	AR	
15-31	12892-93J00-293	SHIM, TAPPET (T:2.925)	AR	
15-32	12892-93J00-295	SHIM, TAPPET (T:2.950)	AR	
15-33	12892-93J00-298	SHIM, TAPPET (T:2.975)	AR	
15-34	12892-93J00-300	SHIM, TAPPET (T:3.000)	AR	
16	12911-98J00	VALVE, INTAKE	12	
17	12915-93J60	VALVE, EXHAUST	12	
18	12921-93J11	SPRING, VALVE	24	
19	12931-78G00	RETAINER, VALVE SPRING	24	
20	12932-24400	COTTER, VALVE	48	
21	12933-69G10	SEAT, VALVE SPRING	24	
22	09289-05012	OIL SEAL (5.5X11.5X9.3)	24	

DF250A E03

FIG.122A





FIG.122A (1-B-12) INTAKE MANIFOLD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-98J10	MANIFOLD, INTAKE	1	
2	13119-98J00	GASKET, INTAKE MANIFOLD	2	
3	09108-08282	STUD BOLT	4	
4	09103-08437	BOLT (8X65)	4	
5	09159-08136	NUT	4	
6	09160-08161	WASHER (8.2X23X3.2)	8	

FIG.136A



DF300A_E03_019_136A
RING GEAR COVER

FIG.136A (1-B-13) RING GEAR COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11510-98J02	COVER, RING GEAR	1	
2	11174-98J00	.HOSE, BREATHER	1	
3	11176-98J00	.UNION, BREATHER	1	
4	11514-98J00	.PLATE, RING GEAR COVER	1	
5	13710-98J00	.ARRESTER, FLAME	1	
6	13811-98J00	.SILENCER, UPPER COVER	1	
7	09401-18410	.CLIP	2	
8	01550-06127	.BOLT	4	
9	01550-06207	.BOLT	5	
10	11517-98J00	.SCREW	3	
11	11515-93J00	BRACE, RING GEAR COVER	1	
12	13841-98J10	GUARD, AIR DUCT STBD	1	
13	13851-98J10	GUARD, AIR DUCT PORT	1	
14	01550-06207	BOLT	4	
15	01550-06207	BOLT	2	
16	01550-06407	BOLT	1	
17	01550-08357	BOLT	2	
18	69711-93E10	LABEL (S.I.G.P)	1	
19	61494-93J00	LABEL, OIL & CLEARANCE	1	

FIG.140A




FIG.140A (1-B-14) EXHAUST COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	14141-93J01	COVER, EXHAUST STBD	1	
2	14140-98J01	COVER, EXHAUST PORT	1	
3	14151-93J00	GASKET, EXHAUST COVER STBD	1	
4	14152-93J00	GASKET, EXHAUST COVER PORT	1	
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	55321-87J01	ANODE, PROTECTION	2	
7	09103-06281	BOLT (6X14)	2	
8	09280-22019	O RING (D:1.9,ID:21.8)	2	
9	01550-08207	BOLT	2	
10	01550-06257	BOLT	23	

FIG.144A




FIG.144A (1-B-15) FUEL INJECTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-93J01	HOSE, FUEL (3WAY TO DLVY PIPE)	1	
2	15710-96J00	INJECTOR ASSY, FUEL	6	
3	15717-16G00	.O RING	6	
4	15735-58B00	INSULATOR, DELIVERY PIPE	4	
5	15751-93J00	PIPE, DELIVERY	2	
6	15756-93J01	HOSE, FUEL (DLVY TO DLVY)	1	
7	15762-93J00	GASKET, DELIVERY PIPE	5	
8	15830-77EA0	UNION, DELIVERY PIPE	1	
9	15831-93J00	UNION, DELIVERY PIPE	2	
10	18498-93J01	PROTECTOR, FUEL HOSE (L:340)	1	
11	09247-14041	PLUG (14X14)	1	
12	09320-08062	CUSHION	6	
13	09360-14009	UNION	1	
14	09401-11425	CLIP	4	
15	09403-16307	CLAMP	1	
16	09408-00105	CLAMP	1	
17	09408-00155	CLAMP	1	
18	01550-08407	BOLT	4	
19	15680-93J32	HOSE, FUEL INLET (TO FLTR)	1	
20	09401-13423	CLIP	1	
21	09408-00135	CLIP	2	
22	15684-98J00	GUIDE, FUEL HOSE	1	
23	01550-06127	BOLT	2	
24	09251-09005	CAP	1	

DF300A_E03_019_144A
FUEL INJECTOR

FIG.147A




FIG.147A (1-C-2) FUEL PUMP/FUEL VAPOR SEPARATOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-98J00	PUMP ASSY, FUEL	1	
2	15410-93J10	FILTER, FUEL (L)	1	
3	15411-93J10	.CAP, FUEL FILTER	1	
4	15415-93J10	.SEAL, FUEL FILTER NO.1	1	
5	15412-93J10	.FILTER ASSY, FUEL	1	
6	15413-93J10	.CASE ASSY, FUEL FILTER	1	
7	15644-93J00	COVER, FUEL FILTER	1	
8	15633-93J20	HOSE, FUEL (H)	1	
9	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->65
10	15440-93J00	FILTER, FUEL (EPI)	1	
11	09320-08501	CUSHION	2	
12	15773-90J00	UNION, FUEL HOSE (H)	1	
13	15830-93J00	UNION, 3 WAY	1	
14	09160-06126	WASHER (6.5X14X2)	3	
15	15770-93J00	COOLER, FUEL	1	
16	09168-12013	GASKET (11.8X22X1.2)	3	
17	09360-12008	UNION	1	
18	09363-08004	UNION	1	
19	15600-98J20	SEPARATOR ASSY, FUEL VAPOR	1	
20	13370-93J00	.VALVE ASSY, NEEDLE	1	
21	15626-93J00	.GASKET, SEPARATOR	1	
22	15650-93J00	.FLOAT ASSY	1	
23	15200-98J00	.PUMP ASSY, FUEL (H)	1	
24	15647-93J00	.BUSH, FUEL PUMP	1	

DF300A_E03_019_147A
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147A




FIG.147A (1-C-3) FUEL PUMP/FUEL VAPOR SEPARATOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	15641-90J00	.SPACER, FUEL PUMP	1	
26	15642-90J00	.FILTER, FUEL PUMP	1	
27	15654-99E00	.PIN, FLOAT	1	
28	02142-0408B	.SCREW	1	
29	13602-05108	.SCREW	1	
30	15760-93J00	.REGULATOR, FUEL PRESSURE	1	
31	15628-99E00	.SCREW	6	
32	15627-93J00	.SCREW	1	
33	09320-12072	CUSHION	3	
34	15675-93J00	BOLT, COOLER BRACKET	3	
35	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->50
36	09401-11414	CLIP (ID:11.5)	15	
37	15636-93J30	HOSE, FUEL	1	
38	15685-93J00	CLIP	3	
39	15672-93J10	BRACKET, FUEL COOLER	1	
40	01500-06167	BOLT	4	
41	15635-93J30	HOSE, FUEL (H)	1	
42	15632-93J30	HOSE, FUEL	1	
43	15673-98J00	BRACKET, FUEL FILTER	1	
44	01550-06257	BOLT	2	
45	15643-93J00	FILTER, FUEL (L)	1	
46	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->65
47	15634-93J20	HOSE, FUEL (H)	1	
48	09116-06525	BOLT (6X35)	3	

DF300A_E03_019_147A
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147A




FIG.147A (1-C-4) FUEL PUMP/FUEL VAPOR SEPARATOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
49	15674-93J00	BRACKET, CHECK VALVE	1	
50	15645-93J00	VALVE, CHECK	1	
51	15637-93J30	HOSE, FUEL	1	
52	15629-99E10	SCREW, DRAIN	2	
53	15683-87J00	HOSE, DRAIN	1	
54	02112-0406B	SCREW	3	
55	09343-70503-600	HOSE (7X12X600)	1	L:600->240
56	09401-11423	CLIP	2	
57	18498-87J51	PROTECTOR,EVAP HOSE (160)	1	
58	09169-06062	WASHER	2	
59	09116-06202	BOLT (6X25)	2	
60	15671-93J00	BRACKET, VAPOR SEPARATOR	1	
61	01550-06357	BOLT	2	
62	09169-08042	WASHER	6	
63	01550-08407	BOLT	3	
64	18417-93J00	BRACKET, PURGE VALVE	1	
65	01550-06127	BOLT	2	
66	09320-08086	CUSHION	1	
67	09403-14304	CLAMP	1	
68	13671-02F00	CLIP	1	
69	15114-93J00	BRACKET, FUEL PUMP NO.1	1	
70	15115-93J00	BRACKET, FUEL PUMP NO.2	1	
71	15695-98L00	UNION, EVAPORATION	1	
72	09352-50003-00A	HOSE, EVAPORATION (1000)	1	

DF300A_E03_019_147A
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147A





FIG.147A (1-C-5) FUEL PUMP/FUEL VAPOR SEPARATOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
73	09401-08412	CLIP	1	
74	09408-00056	CLIP	1	
75	09408-00050	CLIP	1	
76	18498-93J20	PROTECTOR, EVAP HOSE (900)	1	
77	15118-93J00	BOLT	1	

DF300A_E03_019_147A
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.160A




DF300A_E03_019_160A
WATER PUMP

FIG.160A (1-C-6) WATER PUMP (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-93J01	CASE, WATER PUMP	1	
2	17413-93J02	SLEEVE, CASE	1	
3	17416-93J00	SEALING, CASE	1	
4	17461-93J00	IMPELLER, WATER PUMP	1	
5	17471-98J01	PANEL, PUMP CASE UNDER	1	
6	17472-98J00	GASKET, PUMP CASE PANEL	1	
7	17473-98J00	PANEL, WATER PUMP NO.2	1	
8-1	17561-93J21	TUBE, WATER (L)	1	W/TRANSOM(L)
8-2	17561-93J03	TUBE, WATER (UL)	1	W/TRANSOM(X)
8-3	17561-93J13	TUBE, WATER (XX)	1	W/TRANSOM(XX)
9	17562-93J01	BUSH, WATER TUBE UPPER	1	
10	17563-93J00	BUSH, WATER TUBE LOWER	1	
11	17564-93J00	BUSH, WATER PUMP CASE	1	
12	17612-93J00	SPACER, WATER TUBE	1	
13	17631-93L10	FILTER, WATER PORT SIDE	1	
14	17632-93L10	FILTER, WATER STBD SIDE	1	
15	29116-93J00	BOLT, PUMP CASE PANEL	2	
16	09116-08131	BOLT (8X45)	4	
17	09132-04034	SCREW (4X18)	1	
18	09202-06031	PIN (6X12)	2	
19	09420-05009	KEY	1	
20	09168-20002	GASKET (20.5X30X1.5)	1	WATER TUBE UPPER
21	17633-93L00	COVER, WATER FILTER	1	
22	17400-98J01	WATER PUMP REPAIR KIT	1	OPT
23	17416-93J00	.SEALING, CASE	1	OPT
24	17461-93J00	.IMPELLER, WATER PUMP	1	OPT
25	17471-98J01	.PANEL, PUMP CASE UNDER	1	OPT
26	17472-98J00	.GASKET, PUMP CASE PANEL	1	OPT
27	17473-98J00	.PANEL, WATER PUMP NO.2	1	OPT
28	09420-05009	.KEY	1	OPT

DF300A E03

FIG.160B



DF300A_E03_019_160B
WATER PUMP

FIG.160B (1-C-7) WATER PUMP (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-93J01	CASE, WATER PUMP	1	
2	17413-93J02	SLEEVE, CASE	1	
3	17416-93J00	SEALING, CASE	1	
4	17461-93J00	IMPELLER, WATER PUMP	1	
5	17471-98J01	PANEL, PUMP CASE UNDER	1	
6	17472-98J00	GASKET, PUMP CASE PANEL	1	
7	17473-98J00	PANEL, WATER PUMP NO.2	1	
8-1	17561-93J03	TUBE, WATER (UL)	1	W/TRANSOM(X)
8-2	17561-93J13	TUBE, WATER (XX)	1	W/TRANSOM(XX)
9	17562-93J01	BUSH, WATER TUBE UPPER	1	
10	17563-93J00	BUSH, WATER TUBE LOWER	1	
11	17564-93J00	BUSH, WATER PUMP CASE	1	
12	17612-93J00	SPACER, WATER TUBE	1	
13	17631-93L10	FILTER, WATER PORT SIDE	1	
14	17632-93L10	FILTER, WATER STBD SIDE	1	
15	29116-93J00	BOLT, PUMP CASE PANEL	2	
16	09116-08131	BOLT (8X45)	4	
17	09132-04034	SCREW (4X18)	1	
18	09202-06031	PIN (6X12)	2	
19	09420-05009	KEY	1	
20	09168-20002	GASKET (20.5X30X1.5)	1	WATER TUBE UPPER
21	17633-93L00	COVER, WATER FILTER	1	
22	17400-98J01	WATER PUMP REPAIR KIT	1	OPT
23	17416-93J00	.SEALING, CASE	1	OPT
24	17461-93J00	.IMPELLER, WATER PUMP	1	OPT
25	17471-98J01	.PANEL, PUMP CASE UNDER	1	OPT
26	17472-98J00	.GASKET, PUMP CASE PANEL	1	OPT
27	17473-98J00	.PANEL, WATER PUMP NO.2	1	OPT
28	09420-05009	.KEY	1	OPT

DF250A E03

FIG.162A




FIG.162A (1-C-8) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11196-93J00	HOSE, WATER RETURN STBD	1	
2	11197-93J00	HOSE, WATER RETURN PORT	1	
3	11270-93J00	PLATE, CYL BLOCK WTR JKT	1	
4	11272-93J00	GASKET, CYL BLOCK PLATE	1	
5	17581-93J00	PIPE, OUTLET	2	
6	17582-93J00	GASKET, OUTLET PIPE	2	
7-1	17611-90J00-YAY	COVER, WATER PRESS VALVE (BLACK)	1	
7-2	17611-90J00-Y5S	COVER, WATER PRESS VALVE (WHITE)	1	
8	17660-99E01	VALVE, WATER PRESSURE	1	
9-1	17670-90J20	THERMOSTAT (50 DEG)	2	
9-2	17670-90J10	THERMOSTAT (71 DEG)	1	OPT
10	17681-93J00	COVER, THERMOSTAT	2	
11	17711-90J00	3 WAY, WATER HOSE	1	
12	17712-93J00	HOSE (3 WAY TO E/H COV)	1	
13	09116-06121	BOLT (6X25)	2	
14	09280-26006	O RING (D:3.1,ID:26.4)	1	
15	09320-12014	CUSHION	1	
16	09352-50903-600	HOSE (5X9X600)	1	L:600->60
17	09352-50903-600	HOSE (5X9X600)	1	L:600->120
18	09352-50903-600	HOSE (5X9X600)	1	L:600->190
19	09352-50903-600	HOSE (5X9X600)	1	L:600->300
20	09352-50903-600	HOSE (5X9X600)	1	L:600->330
21	09352-50903-600	HOSE (5X9X600)	1	
22	09352-50903-600	HOSE (5X9X600)	1	
23	09352-50903-00B	HOSE (5X9X2000)	1	L:2000->850
24	09352-50903-00B	HOSE (5X9X2000)	1	L:2000->1010
25	01550-08127	BOLT	1	
26	09367-06002	JOINT, 3 WAY	1	
27	09401-08413	CLIP	18	
28	09401-14409	CLIP	2	
29	09401-25406	CLIP	4	
30	09403-25304	CLAMP	1	
31	09408-00008	CLIP (ID:20)	1	

DF300A_E03_019_162A
THERMOSTAT

FIG.162A




FIG.162A (1-C-9) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
32	09408-00056	CLIP	1	
33	01550-06207	BOLT	6	
34	01550-06207	BOLT	4	
35	01550-06257	BOLT	10	
36	17713-98J00	HOLDER, WATER HOSE	1	
37	09401-15414	CLIP	2	
38	17915-98J01	HOSE, WATER FLUSH	1	
39	09408-00024	CLIP (ID:23)	1	
40	09408-00021	CLIP (ID:16)	1	
41	36617-93J10	BRACKET, HOSE CLAMP	1	
42	01550-06127	BOLT	1	

DF300A_E03_019_162A
THERMOSTAT

FIG.163A




FIG.163A (1-C-10) THROTTLE BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11193-98J00	HOSE, PCV	1	
2	11198-58B00	SEAL, PCV VALVE	1	
3	13100-98J10	COLLECTOR ASSY	1	
4	13137-98J00	.SPACER, COLLECTOR	4	
5	13140-98J10	.COVER, COLLECTOR	1	
6	13147-98J00	.GASKET, COLLECTOR COVER	1	
7	13180-98J00	.FUNNEL, COLLECTOR	2	
8	18590-68H00	.SENSOR, MAP	1	
9	09280-10009	.O RING (D:1.3,ID:9.8)	8	
10	01550-08167	.BOLT	4	
11	01550-08357	.BOLT	11	
12	02162-05207	.SCREW	2	
13	04211-11129	.PIN	8	
14	13134-98J00	BRACKET, COLLECTOR	1	
15	13139-98J01	GASKET, COLLECTOR	1	
16	13310-98J00	BODY ASSY, THROTTLE	1	
17	13343-98J10	GASKET, THROTTLE BODY	1	
18	13315-98J00	DAMPER, THROTTLE BODY	1	
19	13421-98J00	GASKET, THROTTLE BODY	1	
20	13813-98J00	GROMMET, THROTTLE BODY	1	
21	09401-13423	CLIP	2	
22	18118-93J00	VALVE, PCV	1	
23	09103-08370	BOLT (8X250)	6	
24	09320-08076	GROMMET	4	
25	09403-13310	CLAMP	1	
26	09408-00155	CLAMP	1	
27	01421-08357	BOLT	2	
28	01550-08167	BOLT	5	
29	01550-08357	BOLT	2	
30	01550-08607	BOLT	2	
31	04211-11129	PIN	2	
32	09159-08136	NUT	4	
33	08316-10087	NUT	2	
34	09160-08161	WASHER (8.2X23X3.2)	2	

DF300A_E03_019_163A
THROTTLE BODY

FIG.175A




FIG.175A (1-C-11) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12632-93J11	SPROCKET, OIL PUMP DRIVE (NT:32)	1	
2	16113-93J10	SPROCKET, OIL PUMP DRIVEN (NT:18)	1	
3	16400-93J10	PUMP ASSY, OIL	1	
4	16520-93J00	STRAINER, OIL PUMP	1	
5	16760-93J00	CHAIN, OIL PUMP DRIVE	1	
6	16781-93J00	TENSIONER, OIL PUMP CHAIN	1	
7	16782-93J00	SPRING, OIL PUMP TENSIONER	1	
8	16783-93J01	BOLT, OIL PUMP TENSIONER	1	
9	09181-12158	SHIM (12X20X0.5)	1	
10	09280-22020	O RING (D:2.4,ID:21.8)	2	
11	01550-0616A	BOLT	3	
12	01550-0845A	BOLT	1	
13	01550-0865A	BOLT	3	
14	01550-0885A	BOLT	1	
15	08110-60020	BEARING	1	

FIG.180A




FIG.180A (1-C-12) OIL PAN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	11261-93J10-YAY	COVER, PROTECTION ANODE (BLACK)	1	
1-2	11261-93J10-Y5S	COVER, PROTECTION ANODE (WHITE)	1	
2-1	55321-87J01	ANODE, PROTECTION	1	
2-2	55321-87J11	ANODE (MAGNESIUM)	1	OPT
3	29103-93J30	BOLT, ANODE COVER	1	
4	09103-06281	BOLT (6X14)	1	
5	09280-22019	O RING (D:1.9,ID:21.8)	1	
6	11489-93J00	GASKET, OIL PAN	1	
7-1	11501-93J03-YAY	PAN, OIL (BLACK)	1	
7-2	11501-93J03-Y5S	PAN, OIL (WHITE)	1	
8	11591-93J10	UNION, OIL PAN	1	
9	11541-93J00-019	PIPE, EXHAUST (BLACK)	1	
10	14154-93J01	SEAL, EXHAUST TUBE	1	
11	14211-98J00	TUBE, EXHAUST	1	
12	14212-93J00	GASKET, EXHAUST TUBE	1	
13	29116-93J00	BOLT, EXHAUST PIPE	4	
14	11435-93J00	PIPE, EXHAUST RELEASE	1	
15	09168-12012	GASKET (12.5X20X2.5)	1	
16	09248-12009	PLUG (12X18.65)	1	
17	09202-08006	PIN (8X12)	2	
18	09202-08006	PIN (8X12)	2	
19	01550-1050A	BOLT	4	
20	09116-08128	BOLT (8X40)	10	
21	09116-10175	BOLT (10X50)	2	
22	09116-10146	BOLT (10X195)	2	
23	09116-10184	BOLT (10X200)	2	
24	29103-93J00	BOLT, SPEEDOMETER HOSE CLAMP	1	
25	29404-93J10	CLAMP, SPEEDOMETER HOSE	1	
26	16910-93J00	GAUGE, OIL LEVEL	1	
27	16930-93J00	GUIDE, OIL LEVEL GAUGE	1	
28	09280-09008	O RING (D:2.1,ID:8.8)	1	
29	01550-06127	BOLT	1	

FIG.204A




FIG.204A (1-C-13) CLUTCH SHAFT (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-98J02	LEVER, CLUTCH	1	
2	21131-93J00	BUSH, CLUTCH LEVER	1	
3	21151-93J00	HOLDER, CLUTCH LEVER	1	
4	09160-10148	WASHER (10X20X3)	1	
5	21210-98J01	SHAFT, CLUTCH	1	
6	21230-98J01	ARM, CLUTCH SHAFT	1	
7-1	23111-93J10	ROD, CLUTCH (L)	1	W/TRANSOM(L)
7-2	23111-93J00	ROD, CLUTCH	1	W/TRANSOM(X) W/TRANSOM(XX)
8	23115-98J00	LINK, CLUTCH LEVER	1	
9	25223-94400	COVER, CLUTCH ROD	1	
10	09160-06094	WASHER (6.5X15X1.0)	2	
11	09204-01006	PIN	2	
12	09205-10006	SPRING PIN (10.2X10)	1	
13	09248-12011	PLUG (12X9)	1	
14	09260-10005	BALL	1	
15	09262-17019	BEARING (17X35X8)	1	
16	09289-18001	OIL SEAL (18X30X8)	1	
17	09306-06005	BUSH	2	
18	09306-10001	BUSH	3	
19	09383-08004	E RING	1	
20	09440-07051	SPRING	1	
21	01550-06207	BOLT	1	
22	02142-05107	SCREW	2	
23	08331-41359	CIRCLIP	1	
24	21241-98J10	LINK, CLUTCH LEVER NO.2	1	
25	67467-89J01	CONNECTOR, REMOCON CABLE	1	
26	67471-99E00	NUT, REMOCON CABLE	1	
27	09160-06055	WASHER (7X12X1)	2	
28	09385-06012	CLIP	2	

FIG.204A




FIG.204A (1-C-14) CLUTCH SHAFT (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	19115-98J10	HOLDER, CLUTCH LEVER	1	
30	01550-08557	BOLT	2	
31	67467-89J10	CONNECTOR, REMOCON CABLE NO.2	1	
32	67471-99E10	NUT, REMOCON CABLE NO.2	1	

DF300A E03

FIG.204B




FIG.204B (1-C-15) CLUTCH SHAFT (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-98J02	LEVER, CLUTCH	1	
2	21131-93J00	BUSH, CLUTCH LEVER	1	
3	21151-93J00	HOLDER, CLUTCH LEVER	1	
4	09160-10148	WASHER (10X20X3)	1	
5	21210-98J01	SHAFT, CLUTCH	1	
6	21230-98J01	ARM, CLUTCH SHAFT	1	
7	23111-93J00	ROD, CLUTCH	1	
8	23115-98J00	LINK, CLUTCH LEVER	1	
9	25223-94400	COVER, CLUTCH ROD	1	
10	09160-06094	WASHER (6.5X15X1.0)	2	
11	09204-01006	PIN	2	
12	09205-10006	SPRING PIN (10.2X10)	1	
13	09248-12011	PLUG (12X9)	1	
14	09260-10005	BALL	1	
15	09262-17019	BEARING (17X35X8)	1	
16	09289-18001	OIL SEAL (18X30X8)	1	
17	09306-06005	BUSH	2	
18	09306-10001	BUSH	3	
19	09383-08004	E RING	1	
20	09440-07051	SPRING	1	
21	01550-06207	BOLT	1	
22	02142-05107	SCREW	2	
23	08331-41359	CIRCLIP	1	
24	21241-98J10	LINK, CLUTCH LEVER NO.2	1	
25	67467-89J01	CONNECTOR, REMOCON CABLE	1	
26	67471-99E00	NUT, REMOCON CABLE	1	
27	09160-06055	WASHER (7X12X1)	2	
28	09385-06012	CLIP	2	
29	19115-98J10	HOLDER, CLUTCH LEVER	1	
30	01550-08557	BOLT	2	
31	67467-89J10	CONNECTOR, REMOCON CABLE NO.2	1	
32	67471-99E10	NUT, REMOCON CABLE NO.2	1	

DF250A E03

FIG.206A




FIG.206A (1-D-2) CLUTCH ROD (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	25112-93L00	ROD, SHIFT DRIVE (X)	1	W/TRANSOM(L) W/TRANSOM(X)
1-2	25112-93L10	ROD, SHIFT DRIVE (XX)	1	W/TRANSOM(XX)
2	25130-93L00	YOKE, SHIFTER	1	
3	25232-90J00	MAGNET, GEAR CASE	1	
4	09205-03004	SPRING PIN (3X20)	1	
5-1	25141-93L00-YAY	HOUSING, SHIFT ROD GUIDE (BLACK)	1	
5-2	25141-93L00-Y5S	HOUSING, SHIFT ROD GUIDE (WHITE)	1	
6	25222-90J00	COVER, SFT GUIDE HSG OIL SEAL	1	
7	09283-10011	OIL SEAL (10X22X8)	1	
8	25321-93L00	SLIDER, SHIFT HORIZONTAL	1	
9	29116-93J00	BOLT, SHIFT ROD HOUSING	3	
10	09160-10082	WASHER (10.5X19X2)	1	
11	25113-93L00	GEAR, SHIFT ROD (NT:13)	2	
12	25215-93L00	HOUSING, MAGNET	1	
13	09383-07003	E RING	3	
14	55122-93L00	SEALING, SHIFT ROD GUIDE HSG	1	
15	56141-93L00	HOUSING, SHIFT SLIDER	1	
16	17637-93L00	FILTER, WATER PORT FRONT SIDE	1	
17	17638-93L00	FILTER, WATER STBD FRONT SIDE	1	
18	55321-87J01	ANODE, PROTECTION	1	
19	01550-06357	BOLT	2	
20	09103-06281	BOLT (6X14)	1	
21	09206-09012	PIN (7.4X9X10)	2	
22	09132-04034	SCREW (4X18)	1	
23	25231-93L00	HOLDER, MAGNET	2	
24	25232-94300	MAGNET, GEAR CASE	2	

DF300A E03

FIG.206B




FIG.206B (1-D-3) CLUTCH ROD (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	25112-93L00	ROD, SHIFT DRIVE (X)	1	W/TRANSOM(X)
1-2	25112-93L10	ROD, SHIFT DRIVE (XX)	1	W/TRANSOM(XX)
2	25130-93L00	YOKE, SHIFTER	1	
3	25232-90J00	MAGNET, GEAR CASE	1	
4	09205-03004	SPRING PIN (3X20)	1	
5-1	25141-93L00-YAY	HOUSING, SHIFT ROD GUIDE (BLACK)	1	
5-2	25141-93L00-Y5S	HOUSING, SHIFT ROD GUIDE (WHITE)	1	
6	25222-90J00	COVER, SFT GUIDE HSG OIL SEAL	1	
7	09283-10011	OIL SEAL (10X22X8)	1	
8	25321-93L00	SLIDER, SHIFT HORIZONTAL	1	
9	29116-93J00	BOLT, SHIFT ROD HOUSING	3	
10	09160-10082	WASHER (10.5X19X2)	1	
11	25113-93L00	GEAR, SHIFT ROD (NT:13)	2	
12	25215-93L00	HOUSING, MAGNET	1	
13	09383-07003	E RING	3	
14	55122-93L00	SEALING, SHIFT ROD GUIDE HSG	1	
15	56141-93L00	HOUSING, SHIFT SLIDER	1	
16	17637-93L00	FILTER, WATER PORT FRONT SIDE	1	
17	17638-93L00	FILTER, WATER STBD FRONT SIDE	1	
18	55321-87J01	ANODE, PROTECTION	1	
19	01550-06357	BOLT	2	
20	09103-06281	BOLT (6X14)	1	
21	09206-09012	PIN (7.4X9X10)	2	
22	09132-04034	SCREW (4X18)	1	
23	25231-93L00	HOLDER, MAGNET	2	
24	25232-94300	MAGNET, GEAR CASE	2	

DF250A E03

FIG.220A




FIG.220A (1-D-4) TRANSMISSION (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-93L02	SHAFT, DRIVE (L)	1	W/TRANSOM(L)
1-2	57110-93L12	SHAFT, DRIVE (X)	1	W/TRANSOM(X)
1-3	57110-93L22	SHAFT, DRIVE (XX)	1	W/TRANSOM(XX)
2	57133-93L00	COLLAR, DRIVE SHAFT	1	
3	57134-93J00	SPACER, DRIVE SHAFT BEARING	1	
4	09159-28003	NUT	1	
5	09269-32002	BEARING (32X66X49)	1	
6	57300-93L20	SET, GEAR	1	
7-1	09181-60004	SHIM (T:0.45)	1	
7-2	09181-60005	SHIM (T:0.50)	1	
7-3	09181-60006	SHIM (T:0.55)	1	
7-4	09181-60007	SHIM (T:0.60)	1	
7-5	09181-60008	SHIM (T:0.65)	1	
7-6	09181-60009	SHIM (T:0.70)	1	
7-7	09181-60010	SHIM (T:0.75)	1	
7-8	09181-60011	SHIM (T:0.80)	1	
7-9	09181-60012	SHIM (T:0.85)	1	
7-10	09181-60013	SHIM (T:0.90)	1	
8	09140-16026	NUT	1	
9	08221-16256	WASHER	1	
10	09180-32006	SPACER (32.4X40X3)	1	REAR GEAR
11-1	09181-32035	SHIM (T:0.50)	1	REAR GEAR
11-2	09181-32036	SHIM (T:0.55)	1	REAR GEAR
11-3	09181-32037	SHIM (T:0.60)	1	REAR GEAR
11-4	09181-32038	SHIM (T:0.65)	1	REAR GEAR
11-5	09181-32039	SHIM (T:0.70)	1	REAR GEAR
11-6	09181-32040	SHIM (T:0.75)	1	REAR GEAR
11-7	09181-32041	SHIM (T:0.80)	1	REAR GEAR
11-8	09181-32042	SHIM (T:0.85)	1	REAR GEAR
11-9	09181-32043	SHIM (T:0.90)	1	REAR GEAR

FIG.220A




FIG.220A (1-D-5) TRANSMISSION (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
11-10	09181-32044	SHIM (T:0.95)	1	REAR GEAR
12	09160-60012	WASHER (60X72X3)	1	FRONT GEAR
13	09263-80002	BEARING (80X105X4)	1	FRONT GEAR
14-1	09181-93101	SHIM (T:0.50)	2	
14-2	09181-93102	SHIM (T:0.55)	2	
14-3	09181-93103	SHIM (T:0.60)	2	
14-4	09181-93104	SHIM (T:0.65)	2	
14-5	09181-93105	SHIM (T:0.70)	2	
14-6	09181-93106	SHIM (T:0.75)	2	
14-7	09181-93107	SHIM (T:0.80)	2	
14-8	09181-93108	SHIM (T:0.85)	2	
14-9	09181-93109	SHIM (T:0.90)	2	
14-10	09181-93110	SHIM (T:0.95)	2	
14-11	09181-93111	SHIM (T:1.00)	2	
14-12	09181-93112	SHIM (T:1.05)	2	
14-13	09181-93113	SHIM (T:1.10)	2	
15-1	59171-93L00	SHIM (T:3.50)	1	FRONT GEAR
15-2	59171-93L10	SHIM (T:3.55)	1	FRONT GEAR
15-3	59171-93L20	SHIM (T:3.60)	1	FRONT GEAR
15-4	59171-93L30	SHIM (T:3.65)	1	FRONT GEAR
15-5	59171-93L40	SHIM (T:3.70)	1	FRONT GEAR
15-6	59171-93L50	SHIM (T:3.75)	1	FRONT GEAR
15-7	59171-93L60	SHIM (T:3.80)	1	FRONT GEAR
15-8	59171-93L70	SHIM (T:3.85)	1	FRONT GEAR
15-9	59171-93L80	SHIM (T:3.90)	1	FRONT GEAR
15-10	59171-93L90	SHIM (T:3.95)	1	FRONT GEAR
15-11	59171-93LA0	SHIM (T:4.00)	1	FRONT GEAR
15-12	59171-93LB0	SHIM (T:4.05)	1	FRONT GEAR
15-13	59171-93LC0	SHIM (T:4.10)	1	FRONT GEAR
16	09265-30033	BEARING (30X72X28.75)	1	

FIG.220A




FIG.220A (1-D-6) TRANSMISSION (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	57610-93L10	SHAFT, PROPELLER	1	
18	57621-93L00	SHIFTER, CLUTCH DOG	1	
19	09202-08013	PIN (8X55)	1	
20	57631-93L01	PIN, CONNECTOR	1	
21	09440-58001	SPRING	1	
22	57617-93L00	SPRING, DETENT	1	
23	06111-07004	BALL	2	DETENT NO.1
24	06111-11004	BALL	2	DETENT NO.2
25	56120-93L20	HOUSING, PROP SFT BRG	1	
26	09263-30063	.BEARING (30X40X25)	1	
27	09265-32003	.BEARING (32X58X17)	1	
28	09280-00047	.O RING (D:3,ID:109)	1	
29	09282-30006	.OIL SEAL (30X45X6)	2	
30	09381-40003	.CIRCLIP	1	
31	56147-93L00	SPACER, PROP SFT BRG HSG	1	
32	56130-93J02	HOUSING, DRIVE SHAFT BRG	1	
33	09280-66004	.O RING (D:3.1,ID:65.4)	1	
34	09282-24004	.OIL SEAL (24X40X7)	2	
35	09381-40003	.CIRCLIP	1	
36	57622-93L00	SPACER, THRUST	1	FRONT
37	09164-50002	WASHER, WAVE	1	
38	09381-72003	SNAP RING	1	FRONT
39	09140-48001	NUT (M48,T:6.0)	1	REAR GEAR
40	56122-93L00	STOPPER, PROP SFT BRG HSG	1	
41	56126-93L10	WASHER, PROP SFT BRG HSG NO.1	1	
42	56127-93L00	WASHER, PROP SFT BRG HSG NO.2	1	
43	56128-93L00	SEAL, PROP SFT BRG HSG	1	
44	56129-93L00	BUSH, STOPPER	1	
45	09280-00050	O RING (D:1.8,ID:117.6)	1	
46	57527-93L00	SPACER, BEARING INNER	1	

FIG.220A




FIG.220A (1-D-7) TRANSMISSION (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
47	57541-93L00	SPACER, BEARING OUTER	1	
48	09265-50004	BEARING (50X80X20)	1	REAR GEAR R
49	09265-55001	BEARING (55X100X22.75)	1	REAR GEAR F

DF300A E03

FIG.220B




FIG.220B (1-D-8) TRANSMISSION (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-93L12	SHAFT, DRIVE (X)	1	W/TRANSOM(X)
1-2	57110-93L22	SHAFT, DRIVE (XX)	1	W/TRANSOM(XX)
2	57133-93L00	COLLAR, DRIVE SHAFT	1	
3	57134-93J00	SPACER, DRIVE SHAFT BEARING	1	
4	09159-28003	NUT	1	
5	09269-32002	BEARING (32X66X49)	1	
6	57300-93L20	SET, GEAR	1	
7-1	09181-60004	SHIM (T:0.45)	1	
7-2	09181-60005	SHIM (T:0.50)	1	
7-3	09181-60006	SHIM (T:0.55)	1	
7-4	09181-60007	SHIM (T:0.60)	1	
7-5	09181-60008	SHIM (T:0.65)	1	
7-6	09181-60009	SHIM (T:0.70)	1	
7-7	09181-60010	SHIM (T:0.75)	1	
7-8	09181-60011	SHIM (T:0.80)	1	
7-9	09181-60012	SHIM (T:0.85)	1	
7-10	09181-60013	SHIM (T:0.90)	1	
8	09140-16026	NUT	1	
9	08221-16256	WASHER	1	
10	09180-32006	SPACER (32.4X40X3)	1	REAR GEAR
11-1	09181-32035	SHIM (T:0.50)	1	REAR GEAR
11-2	09181-32036	SHIM (T:0.55)	1	REAR GEAR
11-3	09181-32037	SHIM (T:0.60)	1	REAR GEAR
11-4	09181-32038	SHIM (T:0.65)	1	REAR GEAR
11-5	09181-32039	SHIM (T:0.70)	1	REAR GEAR
11-6	09181-32040	SHIM (T:0.75)	1	REAR GEAR
11-7	09181-32041	SHIM (T:0.80)	1	REAR GEAR
11-8	09181-32042	SHIM (T:0.85)	1	REAR GEAR
11-9	09181-32043	SHIM (T:0.90)	1	REAR GEAR
11-10	09181-32044	SHIM (T:0.95)	1	REAR GEAR

FIG.220B




FIG.220B (1-D-9) TRANSMISSION (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
12	09160-60012	WASHER (60X72X3)	1	FRONT GEAR
13	09263-80002	BEARING (80X105X4)	1	FRONT GEAR
14-1	09181-93101	SHIM (T:0.50)	2	
14-2	09181-93102	SHIM (T:0.55)	2	
14-3	09181-93103	SHIM (T:0.60)	2	
14-4	09181-93104	SHIM (T:0.65)	2	
14-5	09181-93105	SHIM (T:0.70)	2	
14-6	09181-93106	SHIM (T:0.75)	2	
14-7	09181-93107	SHIM (T:0.80)	2	
14-8	09181-93108	SHIM (T:0.85)	2	
14-9	09181-93109	SHIM (T:0.90)	2	
14-10	09181-93110	SHIM (T:0.95)	2	
14-11	09181-93111	SHIM (T:1.00)	2	
14-12	09181-93112	SHIM (T:1.05)	2	
14-13	09181-93113	SHIM (T:1.10)	2	
15-1	59171-93L00	SHIM (T:3.50)	1	FRONT GEAR
15-2	59171-93L10	SHIM (T:3.55)	1	FRONT GEAR
15-3	59171-93L20	SHIM (T:3.60)	1	FRONT GEAR
15-4	59171-93L30	SHIM (T:3.65)	1	FRONT GEAR
15-5	59171-93L40	SHIM (T:3.70)	1	FRONT GEAR
15-6	59171-93L50	SHIM (T:3.75)	1	FRONT GEAR
15-7	59171-93L60	SHIM (T:3.80)	1	FRONT GEAR
15-8	59171-93L70	SHIM (T:3.85)	1	FRONT GEAR
15-9	59171-93L80	SHIM (T:3.90)	1	FRONT GEAR
15-10	59171-93L90	SHIM (T:3.95)	1	FRONT GEAR
15-11	59171-93LA0	SHIM (T:4.00)	1	FRONT GEAR
15-12	59171-93LB0	SHIM (T:4.05)	1	FRONT GEAR
15-13	59171-93LC0	SHIM (T:4.10)	1	FRONT GEAR
16	09265-30033	BEARING (30X72X28.75)	1	
17	57610-93L10	SHAFT, PROPELLER	1	

FIG.220B




FIG.220B (1-D-10) TRANSMISSION (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
18	57621-93L00	SHIFTER, CLUTCH DOG	1	
19	09202-08013	PIN (8X55)	1	
20	57631-93L01	PIN, CONNECTOR	1	
21	09440-58001	SPRING	1	
22	57617-93L00	SPRING, DETENT	1	
23	06111-07004	BALL	2	DETENT NO.1
24	06111-11004	BALL	2	DETENT NO.2
25	56120-93L20	HOUSING, PROP SFT BRG	1	
26	09263-30063	.BEARING (30X40X25)	1	
27	09265-32003	.BEARING (32X58X17)	1	
28	09280-00047	.O RING (D:3,ID:109)	1	
29	09282-30006	.OIL SEAL (30X45X6)	2	
30	09381-40003	.CIRCLIP	1	
31	56147-93L00	SPACER, PROP SFT BRG HSG	1	
32	56130-93J02	HOUSING, DRIVE SHAFT BRG	1	
33	09280-66004	.O RING (D:3.1,ID:65.4)	1	
34	09282-24004	.OIL SEAL (24X40X7)	2	
35	09381-40003	.CIRCLIP	1	
36	57622-93L00	SPACER, THRUST	1	FRONT
37	09164-50002	WASHER, WAVE	1	
38	09381-72003	SNAP RING	1	FRONT
39	09140-48001	NUT (M48,T:6.0)	1	REAR GEAR
40	56122-93L00	STOPPER, PROP SFT BRG HSG	1	
41	56126-93L10	WASHER, PROP SFT BRG HSG NO.1	1	
42	56127-93L00	WASHER, PROP SFT BRG HSG NO.2	1	
43	56128-93L00	SEAL, PROP SFT BRG HSG	1	
44	56129-93L00	BUSH, STOPPER	1	
45	09280-00050	O RING (D:1.8,ID:117.6)	1	
46	57527-93L00	SPACER, BEARING INNER	1	
47	57541-93L00	SPACER, BEARING OUTER	1	

FIG.220B




FIG.220B (1-D-11) TRANSMISSION (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
48	09265-50004	BEARING (50X80X20)	1	REAR GEAR R
49	09265-55001	BEARING (55X100X22.75)	1	REAR GEAR F

DF250A E03

FIG.301A




FIG.301A (1-D-12) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-98L10	STARTING MOTOR	1	
2	31150-98L00	.CASE, GEAR	1	
3	31170-92J00	.HOUSING, REAR	1	
4	31173-98L00	.HOLDER ASSY, BRUSH	1	
5	31191-63J00	.LEVER ASSY	1	
6	31220-98L10	.SWITCH ASSY	1	
7	31311-63J00	.ARMATURE	1	
8	31192-92J00	.SCREW SET	1	
9	31261-75F10	.BOLT, THROUGH	2	
10	31340-98L00	.CLUTCH SET, STARTER	1	
11	31313-86030	..STOPPER SET	1	
12	31320-98L00	..PINION	1	
13	31341-98L00	..SHAFT, PINION	1	
14	31343-63J00	..INTERNAL GEAR	1	
15	31344-63J00	..GEAR ASSY	3	
16	31912-98J00	BAND, STARTING MOTOR	1	
17	31918-92J01	DAMPER, LOWER	1	
18	01550-08207	BOLT	2	
19	01550-08307	BOLT	2	
20	36645-93J00	LEAD WIRE	1	

DF300A_E03_019_301A
STARTING MOTOR

FIG.303A




FIG.303A (1-D-13) MAGNETO

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32102-98J01	FLYWHEEL	1	
2	09103-12125	BOLT (12X26)	8	
3	09202-06031	PIN (6X12)	1	
4	32120-93J00	COIL, BATTERY CHARGING	1	
5	32131-93J00	HOLDER, STATOR CONNECTING	1	
6	01550-06167	BOLT	2	
7	32160-88L00	COIL, IGNITION TIMING	1	
8	09106-05030	BOLT (5X10)	2	
9	33220-98J00	SENSOR, CAM POSITION	3	
10	33221-42F00	.O RING	3	
11	01550-06167	BOLT	3	
12	09103-06231	BOLT (6X35)	4	
13	09403-13408	CLAMP	2	
14	01550-06127	BOLT	2	

FIG.310A




FIG.310A (1-D-14) RECTIFIER/IGNITION COIL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-98J01	RECTIFIER & REGULATOR	1	
2	32805-93J00	O RING, RECTIFIER & REGULATOR	2	
3	32890-98J01	HOLDER, ELECTRIC PARTS	1	
4	09160-06134	WASHER (6.5X24X1.6)	1	
5	09169-06062	WASHER	3	
6	09320-09016	CUSHION	3	
7	09116-06202	BOLT (6X25)	3	
8	09320-12076	CUSHION	1	
9	01550-06127	BOLT	1	
10	01550-06257	BOLT	4	
11	33410-93J00	COIL ASSY, IGNITION	6	
12	01550-06207	BOLT	6	
13	09408-00021	CLIP (ID:16)	1	

FIG.315A




FIG.315A (1-D-15) SENSOR TRANSOM(X,XX)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13650-52G00	SENSOR, INLET AIR TEMP	1	
2	13655-87J00	GROMMET, AIR TEMP SENSOR	1	
3	29103-93J00	BOLT, PTT MOTOR LEAD CLAMP	1	
4	34830-87J20	SENSOR ASSY, EXHAUST TEMP	2	
5	34830-87J20	SENSOR ASSY, CYLINDER TEMP	1	
6	34840-98J03	SENSOR ASSY, TRIM	1	
7	37820-98J00	SWITCH ASSY, OIL PRESSURE	1	
8	09125-06063	SCREW (6X10)	1	
9	09403-19409	CLAMP	1	
10	29404-93J10	CLAMP, PTT MOTOR LEAD	1	
11	09407-14407	CLAMP (L:145)	2	
12	34841-88L00	LEVER, TRIM SENSOR	1	
13	34845-88L01	BRACKET, TRIM SENSOR	1	
14	09140-05005	.NUT	1	
15	09125-05048	SCREW (5X16)	1	
16	09160-05029	WASHER (5.5X12X0.8)	1	
17	09103-06093	BOLT (6X20)	2	
18	18213-98J30	SENSOR, OXYGEN	1	
19	09403-07340	CLAMP	1	
20	11218-98J02	HOLDER, TEMP SENSOR	1	
21	11219-98J00	HOLDER, OIL SENSOR	1	
22	34830-98J00	SENSOR ASSY, OIL TEMP	1	

FIG.315B




FIG.315B (1-E-2) SENSOR TRANSOM(L)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13650-52G00	SENSOR, INLET AIR TEMP	1	
2	13655-87J00	GROMMET, AIR TEMP SENSOR	1	
3	29103-93J00	BOLT, PTT MOTOR LEAD CLAMP	1	
4	34830-87J20	SENSOR ASSY, EXHAUST TEMP	2	
5	34830-87J20	SENSOR ASSY, CYLINDER TEMP	1	
6	34840-98J11	SENSOR ASSY, TRIM	1	
7	37820-98J00	SWITCH ASSY, OIL PRESSURE	1	
8	09103-06307	BOLT (6X10)	1	
9	09403-19409	CLAMP	1	
10	29404-93J20	CLAMP	1	
11	09407-14407	CLAMP (L:145)	2	
12	34841-96J00	LEVER, TRIM SENSOR	1	
13	34845-96J00	BRACKET, TRIM SENSOR	1	
14	09125-05048	SCREW (5X16)	1	
15	09160-05029	WASHER (5.5X12X0.8)	1	
16	09103-06093	BOLT (6X20)	2	
17	18213-98J30	SENSOR, OXYGEN	1	
18	09403-07340	CLAMP	1	
19	11218-98J02	HOLDER, TEMP SENSOR	1	
20	11219-98J00	HOLDER, OIL SENSOR	1	
21	34830-98J00	SENSOR ASSY, OIL TEMP	1	
22	34813-93J00	PROTECTOR, LEAD WIRE	1	
23	36611-96J00	WIRE, TRIM SENSOR	1	
24	43117-96J00	CAM, TRIM SENDER	1	
25	09116-05010	BOLT (5X12)	2	
26	43118-96J00	PLATE, TRIM SENDER CAM	1	

DF300A E03

FIG.322A




FIG.322A (1-E-3) HARNESS

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-98J01	CABLE, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-98J80	HARNESS ASSY, WIRING	1	
4	09481-10504	.FUSE (10A)	2	
5	36612-98J10	.CONNECTOR, SELECT TERMINAL	1	
6	36721-98L10	.O RING, UPPER COVER	1	
7	36737-98L00	.PULLER, FUSE	1	
8	36738-98L00	.COVER, FUSE CASE UPPER	1	
9	09320-08021	.CUSHION	2	
10	38860-76F01	.RELAY	1	FOR ENG CONTROL UNIT
11	38860-76F01	.RELAY	1	FOR STARTER MOTOR
12	09481-15504	.FUSE (15A)	4	
13	09481-30504	.FUSE (30A)	3	
14	09481-40403	.FUSE (40A)	1	
15	09481-60403	.FUSE (60A)	2	
16	36612-96J00	.CAP, TERMINAL	1	
17	08310-00067	NUT	1	
18	08321-01067	WASHER	1	
19	36617-93J00	BRACKET, HARNESS	4	
20	36617-93J10	BRACKET, HARNESS	8	
21	36617-98J00	BRACKET, HARNESS	1	
22	01550-0612C	BOLT	13	
23	09403-20308	CLAMP	1	
24	09407-14407	CLAMP (L:145)	4	
25	09408-00008	CLIP (ID:20)	3	
26	09408-00184	CLAMP	3	
27	09408-00012	CLIP (ID:11.5)	1	
28	09408-00024	CLIP (ID:23)	2	
29	01550-06127	BOLT	1	

FIG.326A




FIG.326A (1-E-4) PTT SWITCH/ENGINE CONTROL UNIT (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13580-98J02	SENSOR ASSY, SHIFT POSITION	1	
2	13575-40F00	.O RING	1	
3	37729-96L00	LEVER, SHIFT SENSOR	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	07130-05167	BOLT	1	
6	08321-0105A	WASHER	1	
7	37721-93J00	SWITCH ASSY, NEUTRAL	1	
8	09137-04004	SCREW (4X16)	2	
9	09407-10404	CLAMP (L:100)	2	
10	37725-93J11	COVER, SWITCH ASSY	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH	1	
13	37857-92J00	BUSH, PTT SWITCH	1	
14	09403-11315	CLAMP	1	
15	01550-06127	BOLT	1	
16	37722-93J12	SWITCH ASSY, TILT LIMIT	1	
17-1	09407-14407	CLAMP (L:145)	1	W/TRANSOM(L)
17-2	09403-09316	CLAMP	1	W/TRANSOM(X)
				W/TRANSOM(XX)
18	29125-93J00	SCREW, TILT LIMIT CLAMP	1	W/TRANSOM(X)
				W/TRANSOM(XX)
19	38410-93J12	RELAY, PTT	1	
20	38415-93J00	HOLDER, PTT RELAY	1	
21	01550-06127	BOLT	1	
22	09407-30401	CLAMP (L:300)	1	
23-1	33930-98JB0	UNIT, ENGINE CONTROL	1	W/TRANSOM(L)
23-2	33930-98J90	UNIT, ENGINE CONTROL	1	W/TRANSOM(X)
				W/TRANSOM(XX)
24	33925-98J00	CUSHION, ENGINE CONTROL UNIT	1	
25	38890-98J11	ACTUATOR, SHIFT	1	
26	38892-98J00	DAMPER, SHIFT ACTUATOR	1	

DF300A_E03_019_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326A




FIG.326A (1-E-5) PTT SWITCH/ENGINE CONTROL UNIT (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	38895-98J00	BRACKET, SHIFT ACTUATOR	1	
28	01550-06167	BOLT	2	
29	01550-06357	BOLT	3	
30	38860-76F01	RELAY, ACTUATOR	2	
31	38915-90J00	HOLDER, RELAY	2	

DF300A E03

DF300A_E03_019_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326B




FIG.326B (1-E-6) PTT SWITCH/ENGINE CONTROL UNIT (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13580-98J02	SENSOR ASSY, SHIFT POSITION	1	
2	13575-40F00	.O RING	1	
3	37729-96L00	LEVER, SHIFT SENSOR	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	07130-05167	BOLT	1	
6	08321-0105A	WASHER	1	
7	37721-93J00	SWITCH ASSY, NEUTRAL	1	
8	09137-04004	SCREW (4X16)	2	
9	09407-10404	CLAMP (L:100)	2	
10	37725-93J11	COVER, SWITCH ASSY	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH	1	
13	37857-92J00	BUSH, PTT SWITCH	1	
14	09403-11315	CLAMP	1	
15	01550-06127	BOLT	1	
16	37722-93J12	SWITCH ASSY, TILT LIMIT	1	
17	09403-09316	CLAMP	1	
18	29125-93J00	SCREW, TILT LIMIT CLAMP	1	
19	38410-93J12	RELAY, PTT	1	
20	38415-93J00	HOLDER, PTT RELAY	1	
21	01550-06127	BOLT	1	
22	09407-30401	CLAMP (L:300)	1	
23	33930-98JA0	UNIT, ENGINE CONTROL	1	
24	33925-98J00	CUSHION, ENGINE CONTROL UNIT	1	
25	38890-98J11	ACTUATOR, SHIFT	1	
26	38892-98J00	DAMPER, SHIFT ACTUATOR	1	
27	38895-98J00	BRACKET, SHIFT ACTUATOR	1	
28	01550-06167	BOLT	2	
29	01550-06357	BOLT	3	
30	38860-76F01	RELAY, ACTUATOR	2	
31	38915-90J00	HOLDER, RELAY	2	

DF250A E03

DF300A_E03_019_326B
PTT SWITCH/ENGINE CONTROL UNIT

FIG.331A




FIG.331A (1-E-7) KEY LESS START

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32851-93J00	CUSHION, KLS CONTROLLER	1	
2	32980-38F00	HOLDER, KLS CONTROLLER	1	
3	36623-96L01	HARNESS ASSY, KLS CONT	1	
4	36615-96300	.TERMINAL, RESIN	1	
5	36662-96L00	HARNESS ASSY, KLS CAN	1	L:6500+110
6	37117-96L00	DECAL, KLS	2	
7-1	37171-96L02	CONTROLLER ASSY, KLS 433MHZ	1	
7-2	37171-96L12	CONTROLLER ASSY, KLS 315MHZ	1	
8-1	37172-96L01	REMOCON ASSY, KLS 433MHZ	2	
8-2	37172-96L10	REMOCON ASSY, KLS 315MHZ	2	
9	37173-96L10	HOLDER, KLS PARTS	1	
10	38500-93J90	BUZZER ASSY	1	
11	38860-96L01	RELAY ASSY, KLS	1	
12	09407-14407	CLAMP (L:145)	1	

NOTE: USE FREQUENCY ASSIGNED ON YOUR MARKET.
FOR DETAILES, PLEASE MAKE SURE OF SUZUKI DEALERS.

FIG.335A




FIG.335A (1-E-8) CLAMP BRACKET TRANSOM(X,XX)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-93J16-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-93J16-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-93J08-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-93J08-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41117-93J02	PLATE, CLAMP BRKT LOWER STBD	1	
4	41122-93J02	PLATE, CLAMP BRKT LOWER PORT	1	
5	09125-06063	SCREW (6X10)	4	
6	41130-93J12	SHAFT, CLAMP BRKT	1	
7	41135-93J11	WASHER, CLAMP BRACKET SHAFT	1	
8	09159-22006	NUT	1	
9-1	09100-12086	BOLT (12.7X150)	6	
9-2	09100-12085	BOLT (12.7X115)	1	OPT
9-3	09100-12092	BOLT (12.7X75)	1	OPT
10	09159-12062	NUT	6	
11	09160-13022	WASHER (13.2X45X3)	4	
12	09160-13021	WASHER (13.2X26X3)	6	
13	41155-93J02	PLATE, TRANSOM	2	
14	55320-94900	ZINC SET, PROTECTION	1	
15	09116-06121	.BOLT (6X25)	2	
16	45421-87D03	PIN, TILT LOCK	1	
17	09159-14020	NUT	2	
18	48140-93J01	CAM, TILT LIMIT SWITCH	1	
19	48144-93J00	HOLDER, TILT LIMIT SWITCH	1	
20	09103-06278	BOLT (6X25)	2	
21	55321-94910	ANODE (MAGNESIUM)	1	OPT
22	48145-93J00	COVER, TILT LIMIT SWITCH	1	
23	36894-87D00	LEAD (CLAMP TO SWIVEL)	1	
24	09125-06063	SCREW (6X10)	2	

FIG.335B




FIG.335B (1-E-9) CLAMP BRACKET TRANSOM(L)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-96J40-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-96J40-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-96J30-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-96J30-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41130-92J03	SHAFT, CLAMP BRKT	1	
4	41135-92J00	WASHER, CLAMP BRACKET SHAFT	1	
5	09159-22006	NUT	1	
6-1	09100-12086	BOLT (12.7X150)	6	
6-2	09100-12085	BOLT (12.7X115)	1	OPT
6-3	09100-12092	BOLT (12.7X75)	1	OPT
7	09159-12062	NUT	6	
8	09160-13021	WASHER (13.2X26X3)	6	
9	09160-13022	WASHER (13.2X45X3)	4	
10	41155-93J02	PLATE, TRANSOM	2	
11	55320-94900	ZINC SET, PROTECTION	1	
12	09116-06121	.BOLT (6X25)	2	
13	48140-93J01	CAM, TILT LIMIT SWITCH	1	
14	48144-93J00	HOLDER, TILT LIMIT SWITCH	1	
15	09103-06278	BOLT (6X25)	2	
16	48145-93J00	COVER, TILT LIMIT SWITCH	1	
17	55321-94910	ANODE (MAGNESIUM)	1	OPT
18	41117-93L00	PLATE, CLAMP BRACKET LWR STBD	1	
19	41122-93L00	PLATE, CLAMP BRACKET LWR PORT	1	
20	03542-0516C	SCREW	4	
21	09160-05053	WASHER	4	

DF300A E03

FIG.336A




FIG.336A (1-E-10) SWIVEL BRACKET TRANSOM(X,XX)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE, GREASE SWIVEL BRKT	4	
2	36894-87D00	LEAD (SWIVEL TO MOUNT BRKT)	1	
3-1	43111-93J24-YAY	BRACKET, SWIVEL (BLACK)	1	
3-2	43111-93J24-Y5S	BRACKET, SWIVEL (WHITE)	1	
4	43114-93J00	WASHER, SWIVEL TO CLAMP BRKT	2	
5	43211-93J00	BUSH, CLAMP SHAFT SWIVEL	2	
6	43711-97E01	BUSH, STEERING	2	
7-1	43750-93J03-YAY	BRACKET, STEERING (BLACK)	1	
7-2	43750-93J03-Y5S	BRACKET, STEERING (WHITE)	1	
8	09125-06063	SCREW (6X10)	1	
9	09160-39001	WASHER (39.5X64X1)	2	
10	09181-39001	SHIM (39.5X64X0.3)	AR	
11	09282-39001	OIL SEAL (39X51X5)	1	
12	09380-38003	CIRCLIP	1	
13	41220-93J11	LEVER, TILT LOCK	1	
14	41234-93J11	LEVER, TILT LOCK PORT	1	
15	41224-95E01	BUSH, TILT STOPPER ROD	2	
16	41230-96J00	LINK, TILT LOCK LEVER	1	
17	41233-95E10	BRACKET, TILT LOCK SPRING	1	
18	09125-06063	SCREW (6X10)	1	
19	09140-10032	NUT	1	
20	09160-06082	WASHER (6.5X13X1.0)	1	
21	09204-01006	PIN	1	
22	09440-19028	SPRING	1	
23	09443-10043	SPRING	1	

DF300A_E03_019_336A
SWIVEL BRACKET

FIG.336B




FIG.336B (1-E-11) SWIVEL BRACKET TRANSOM(L)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE, GREASE	4	
2	36894-87D00	LEAD (SWIVEL TO CLAMP)	1	
3-1	43111-96J20-YAY	BRACKET, SWIVEL (BLACK)	1	
3-2	43111-96J20-Y5S	BRACKET, SWIVEL (WHITE)	1	
4	43211-93J00	BUSH, CLAMP SHAFT SWIVEL	2	
5	43711-97E01	BUSH, STEERING	2	
6-1	43750-96J51-YAY	BRACKET, STEERING (BLACK)	1	
6-2	43750-96J51-Y5S	BRACKET, STEERING (WHITE)	1	
7	09125-06063	SCREW (6X10)	2	
8	09160-39001	WASHER (39.5X64X1)	2	
9	09181-39001	SHIM (39.5X64X0.3)	AR	
10	09380-38003	CIRCLIP	1	
11	09169-28003	WASHER	2	
12	09282-39001	OIL SEAL (39X51X5)	1	
13	36895-87D10	LEAD (SWIVEL TO HSG)	1	
14	09125-06063	SCREW (6X10)	1	
15	41220-96J10	LEVER, TILT LOCK	1	
16	41234-96J10	LEVER, TILT LOCK PORT	1	
17	41224-95E01	BUSH, TILT STOPPER ROD	2	
18	41230-96J00	LINK, TILT LOCK LEVER	1	
19	41233-95E10	BRACKET, TILT LOCK SPRING	1	
20	09125-06063	SCREW (6X10)	1	
21	09140-10032	NUT	1	
22	09160-06082	WASHER (6.5X13X1.0)	1	
23	09204-01006	PIN	1	
24	09440-19028	SPRING	1	
25	09443-10043	SPRING	1	
26	09125-06063	SCREW (6X10)	1	

DF300A E03

DF300A_E03_019_336B
SWIVEL BRACKET

FIG.337A




FIG.337A (1-E-12) TRIM CYLINDER TRANSOM(X,XX)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-98J08	TRIM ASSY, POWER WITH TILT	1	
2	31281-92J10	.BOLT	4	
3	38100-93J04	.MOTOR ASSY, PTT	1	
4	48500-98J10	.MANIFOLD ASSY	1	
5	48582-95E01	..FILTER	1	
6	48605-93J00	..O RING SET	2	
7	48615-87D00	...RING, BACKUP	4	
8	48610-93J01	..PISTON / RAM	2	
9	48630-98L00	..ROD GUIDE	2	
10	48633-93J00	...O RING	4	
11	48691-93J00	..CHECK VALVE	1	
12	48400-98J03	.CYLINDER ASSY	1	
13	48405-93J00	..O RING SET	1	
14	48650-93J00	..PISTON, FREE	1	
15	48627-93J00	..O RING SET	1	
16	48427-87D00	...O RING, PISTON	1	
17	48572-87J10	.PLUG	1	
18	48585-95E00	.O RING	2	
19	48862-87J20	.BOLT, RESERVOIR	2	
20	48864-93J01	.MANUAL VALVE	1	
21	48583-95E00	.JOINT, DRIVE	1	
22	48121-93J20	.SHAFT	1	
23	48125-93J10	.O RING SET	1	
24	48451-93J00	..BACK UP RING	4	
25	48452-93J00	..O RING	4	
26	48452-93J10	..O RING	2	
27	48126-93J00	.WASHER, TILT CYL TO MANIF	2	
28	48320-93J00	.VALVE SET, UP BLOW	1	
29	48573-93J00	.COVER	1	

DF300A_E03_019_337A
TRIM CYLINDER

FIG.337A




FIG.337A (1-E-13) TRIM CYLINDER TRANSOM(X,XX)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	48128-93J11	.BOLT	1	
31	48571-93J00	.RESERVOIR TANK	1	
32	48311-96J10	PAD, TRIM CYL RAM	2	
33	48321-93J00	SHAFT, TILT CYL UPPER	1	
34	09140-10031	NUT	2	
35	09162-10005	LOCK WASHER	2	
36	09306-24001	BUSH	2	
37	09380-21002	CIRCLIP	2	
38	09116-10175	BOLT (10X50)	8	
39	36894-87D00	LEAD, PTT TO ANODE (L:165)	1	
40	36895-87D01	LEAD, PTT TO ANODE (L:230)	1	
41	36895-87D01	LEAD, PTT TO ANODE (L:230)	1	
42	09125-06063	SCREW (6X10)	1	
43	09125-06063	SCREW (6X10)	1	
44	09125-06063	SCREW (6X10)	1	

DF300A_E03_019_337A
TRIM CYLINDER

FIG.337B




FIG.337B (1-E-14) TRIM CYLINDER TRANSOM(L)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-93L01	TRIM ASSY, POWER WITH TILT	1	
2	29404-93J10	.CLAMP	1	
3	31281-92J10	.BOLT	4	
4	38100-93L01	.MOTOR ASSY, PTT	1	
5	48502-96J05	.PUMP ASSY	1	
6	48582-95E01	..FILTER	1	
7	48864-96J10	..VALVE, MANUAL	1	
8	48503-93L00	.MANIFOLD SUB ASSY	1	
9	48401-93L00	..PISTON ASSY	1	
10	48601-93L00	..PISTON / RAM ASSY	2	
11	48627-95E00	..O RING SET	3	
12	48630-96J03	..HEAD, TRIM CYLINDER	2	
13	48633-94900	..O RING SET (2PCS)	2	
14	48641-93L00	..MANIFOLD, PTT	1	
15	48650-94900	..PISTON, FREE	1	
16	48405-93J00	...O RING SET	1	
17	48615-97E00	...RING SET, PISTON	1	
18	48570-95E01	.RESERVOIR	1	
19	48572-95E00	..CAP	1	
20	48583-95E00	.JOINT, DRIVE	1	
21	48585-95E00	.O RING	1	
22	48588-94900	.O RING SET (6PCS)	1	
23	48861-92J01	.BOLT, RESERVOIR	3	
24	48862-92J20	.BOLT, PUMP NO.1	1	
25	48862-92J30	.BOLT, PUMP NO.2	2	
26	48121-93L00	SHAFT, TILT CYL LOWER	1	
27	09160-10161	WASHER	2	
28	48311-96J20	PAD, TRIM CYL RAM	2	
29	48321-87D03	SHAFT, TILT CYL UPPER	1	
30	48326-95E00	BUSH, TILT CYL LOWER	2	

DF300A_E03_019_337B
TRIM CYLINDER

FIG.337B





FIG.337B (1-E-15) TRIM CYLINDER TRANSOM(L)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	09116-10183	BOLT (10X35)	2	
32	09140-10031	NUT	2	
33	09162-10005	LOCK WASHER	2	
34	09306-17001	BUSH	2	
35	09380-17009	CIRCLIP	2	
36	36894-87D00	LEAD, PTT TO ANODE	1	
37	09125-06063	SCREW (6X10)	1	
38	09125-05050	SCREW (5X8)	1	
39	36895-87D10	LEAD, PTT TO ANODE L	1	

DF300A E03

FIG.340A



DF300A_E03_019_340A
PTT MOTOR

FIG.340A (1-F-2) PTT MOTOR TRANSOM(X,XX)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-93J04	MOTOR ASSY, PTT	1	
2	31111-94900	.SCREW, YOKE	3	
3	31173-94920	.HOLDER ASSY, BRUSH	1	
4	31123-94910	..O RING	1	
5	31133-90J10	..BRUSH SET, PLUS	1	
6	31133-94910	...BRUSH	1	
7	31135-94900	..SPRING	2	
8	31136-90J20	..BREAKER	1	
9	33799-97E00	..OIL SEAL	1	
10	31311-93J00	.ARMATURE	1	

FIG.340B




FIG.340B (1-F-3) PTT MOTOR TRANSOM(L)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-93L01	MOTOR ASSY, PTT	1	
2	31111-94900	.SCREW, YOKE	3	
3	31173-94920	.HOLDER ASSY, BRUSH	1	
4	31123-94910	..O RING	1	
5	31133-90J10	..BRUSH SET, PLUS	1	
6	31133-94910	...BRUSH	1	
7	31135-94900	..SPRING	2	
8	31136-90J20	..BREAKER	1	
9	33799-97E00	..OIL SEAL	1	
10	31311-94900	.ARMATURE	1	

DF300A E03

DF300A_E03_019_340B
PTT MOTOR

FIG.401A




FIG.401A (1-F-4) ENGINE HOLDER (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51111-93J21-YAY	HOLDER, ENGINE (BLACK)	1	
1-2	51111-93J21-Y5S	HOLDER, ENGINE (WHITE)	1	
2	16519-93J00	SEAL, ENGINE HOLDER OIL	1	
3	17913-93J00	PLUG, WATER	1	
4	17914-93J00	GASKET, WATER PLUG	1	
5	51116-93J00	SEAL, WATER RETURN	1	
6	51211-93J00	GASKET, ENGINE HOLDER	1	
7	61155-93J20	UNION, WATER INDICATOR	1	
8	09206-08001	PIN (8X11)	2	
9	01550-08307	BOLT	6	
10	51120-93J02	COVER, MOUNT OIL SEAL	1	
11	22511-99011	.NIPPLE, GREASE	1	
12	51124-93J01	.OIL SEAL	2	
13	51125-93J00	.SCRAPER	1	
14	51123-93J00	GASKET, MOUNT OIL SEAL COVER	1	
15	09103-08109	BOLT (8X120)	2	
16	09206-08001	PIN (8X11)	2	
17	01550-0830A	BOLT	6	
18-1	51140-93J11-YAY	COVER, ENGINE HOLDER (BLACK)	1	W/TRANSOM(L)
18-2	51140-98J00-YAY	COVER, ENGINE HOLDER (BLACK)	1	W/TRANSOM(X) W/TRANSOM(XX)
18-3	51140-93J11-Y5S	COVER, ENGINE HOLDER (WHITE)	1	W/TRANSOM(L)
18-4	51140-98J00-Y5S	COVER, ENGINE HOLDER (WHITE)	1	W/TRANSOM(X) W/TRANSOM(XX)
19	51142-93J00	GASKET, ENGINE HOLDER COVER	1	
20	09116-08122	BOLT (8X30)	8	
21	51151-93J00	COVER, ENGINE HOLDER UPPER	1	
22	51152-93J00	SEAL, ENGINE HOLDER UPPER COV	1	
23	01550-08307	BOLT	3	
24	01550-08607	BOLT	2	
25	54123-93J03	PLATE, UPPER MOUNT	1	

FIG.401A




FIG.401A (1-F-5) ENGINE HOLDER (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26	54130-93J01	MOUNT, UPPER	2	
27	54112-93J00	BOLT, UPPER MOUNT	2	
28	29159-93J00	NUT, UPPER MOUNT BOLT	2	
29	09160-15051	WASHER (15X24X3)	2	
30	54137-93J02	COVER, UPPER MOUNT	1	
31	09116-10135	BOLT (10X95)	2	
32	09116-10175	BOLT (10X50)	1	
33-1	54121-98J01	STOPPER, UPPER THRUST	2	W/TRANSOM(X) W/TRANSOM(XX)
33-2	54121-93J20	STOPPER, UPPER THRUST	2	W/TRANSOM(L)
34	54140-98J00	MOUNT, UPPER THRUST REVERSE	1	
35	09116-10137	BOLT (10X70)	6	
36	09116-10175	BOLT (10X50)	4	
37	09116-10146	BOLT (10X195)	2	
38	09116-10134	BOLT (10X115)	1	
39	09116-08126	BOLT (8X65)	4	
40	09169-08038	WASHER (8.3X15X3)	2	
41	54144-93J00	SEAL, UPPER MOUNT	1	

DF300A E03

FIG.401B




FIG.401B (1-F-6) ENGINE HOLDER (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51111-93J21-YAY	HOLDER, ENGINE (BLACK)	1	
1-2	51111-93J21-Y5S	HOLDER, ENGINE (WHITE)	1	
2	16519-93J00	SEAL, ENGINE HOLDER OIL	1	
3	17913-93J00	PLUG, WATER	1	
4	17914-93J00	GASKET, WATER PLUG	1	
5	51116-93J00	SEAL, WATER RETURN	1	
6	51211-93J00	GASKET, ENGINE HOLDER	1	
7	61155-93J20	UNION, WATER INDICATOR	1	
8	09206-08001	PIN (8X11)	2	
9	01550-08307	BOLT	6	
10	51120-93J02	COVER, MOUNT OIL SEAL	1	
11	22511-99011	.NIPPLE, GREASE	1	
12	51124-93J01	.OIL SEAL	2	
13	51125-93J00	.SCRAPER	1	
14	51123-93J00	GASKET, MOUNT OIL SEAL COVER	1	
15	09103-08109	BOLT (8X120)	2	
16	09206-08001	PIN (8X11)	2	
17	01550-0830A	BOLT	6	
18-1	51140-98J00-YAY	COVER, ENGINE HOLDER (BLACK)	1	
18-2	51140-98J00-Y5S	COVER, ENGINE HOLDER (WHITE)	1	
19	51142-93J00	GASKET, ENGINE HOLDER COVER	1	
20	09116-08122	BOLT (8X30)	8	
21	51151-93J00	COVER, ENGINE HOLDER UPPER	1	
22	51152-93J00	SEAL, ENGINE HOLDER UPPER COV	1	
23	01550-08307	BOLT	3	
24	01550-08607	BOLT	2	
25	54123-93J03	PLATE, UPPER MOUNT	1	
26	54130-93J01	MOUNT, UPPER	2	
27	54112-93J00	BOLT, UPPER MOUNT	2	
28	29159-93J00	NUT, UPPER MOUNT BOLT	2	

DF300A_E03_019_401B
ENGINE HOLDER

FIG.401B




FIG.401B (1-F-7) ENGINE HOLDER (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	09160-15051	WASHER (15X24X3)	2	
30	54137-93J02	COVER, UPPER MOUNT	1	
31	09116-10135	BOLT (10X95)	2	
32	09116-10175	BOLT (10X50)	1	
33	54121-98J01	STOPPER, UPPER THRUST	2	
34	54140-98J00	MOUNT, UPPER THRUST REVERSE	1	
35	09116-10137	BOLT (10X70)	6	
36	09116-10175	BOLT (10X50)	4	
37	09116-10146	BOLT (10X195)	2	
38	09116-10134	BOLT (10X115)	1	
39	09116-08126	BOLT (8X65)	4	
40	09169-08038	WASHER (8.3X15X3)	2	
41	54144-93J00	SEAL, UPPER MOUNT	1	

DF250A E03

FIG.405A




FIG.405A (1-F-8) DRIVE SHAFT HOUSING TRANSOM(X)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-98J00-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	
1-2	52111-98J00-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	
2	09116-10176	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	57130-87D10	BUSH, DRIVE SHAFT	1	
5	09387-38002	RING	1	
6	09125-06063	SCREW (6X10)	1	
7	36894-87D00	LEAD, MT BRKT TO HSG	1	
8	09125-06063	SCREW (6X10)	1	
9	54150-98J00	MOUNT, LOWER THRUST	1	
10	54160-98J00	MOUNT, LOWER	2	
11	54112-93J00	BOLT, LOWER MOUNT	2	
12	09160-16050	WASHER (16X32X3)	2	
13	29159-93J00	NUT, LOWER MOUNT BOLT	2	
14	09160-16050	WASHER (16X32X3)	2	
15-1	54211-93J00-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
15-2	54211-93J00-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	
16-1	54221-93J00-YAY	COVER, LOWER MOUNT (BLACK)	2	
16-2	54221-93J00-Y5S	COVER, LOWER MOUNT (WHITE)	2	
17	09116-10175	BOLT (10X50)	4	
18	54165-98J01	STOPPER, LOWER THRUST REVERSE	4	
19	09160-14066	WASHER (14X50X4)	2	
20	55321-93J01	ANODE, PROTECTION	1	
21	09116-06236	BOLT (6X16)	1	

FIG.405B




FIG.405B (1-F-9) DRIVE SHAFT HOUSING TRANSOM(XX)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-98J00-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	
1-2	52111-98J00-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	
2	09116-10176	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	57130-87D10	BUSH, DRIVE SHAFT	1	
5	09387-38002	RING	1	
6	09125-06063	SCREW (6X10)	1	
7-1	52131-93J00-YAY	CASE, EXTENSION (BLACK)	1	
7-2	52131-93J00-Y5S	CASE, EXTENSION (WHITE)	1	
8	09108-10115	STUD BOLT	6	
9	09108-12013	STUD BOLT	1	
10	09202-08006	PIN (8X12)	2	
11	36894-87D00	LEAD, MT BRKT TO HSG	1	
12	09125-06063	SCREW (6X10)	1	
13	54150-98J00	MOUNT, LOWER THRUST	1	
14	54160-98J00	MOUNT, LOWER	2	
15	54112-93J00	BOLT, LOWER MOUNT	2	
16	09160-16050	WASHER (16X32X3)	2	
17	29159-93J00	NUT, LOWER MOUNT BOLT	2	
18	09160-16050	WASHER (16X32X3)	2	
19-1	54211-93J00-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
19-2	54211-93J00-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	
20-1	54221-93J00-YAY	COVER, LOWER MOUNT (BLACK)	2	
20-2	54221-93J00-Y5S	COVER, LOWER MOUNT (WHITE)	2	
21	09116-10175	BOLT (10X50)	4	
22	54165-98J01	STOPPER, LOWER THRUST REVERSE	4	
23	09160-14066	WASHER (14X50X4)	2	
24	55321-93J01	ANODE, PROTECTION	2	
25	09116-06236	BOLT (6X16)	2	

FIG.405C




FIG.405C (1-F-10) DRIVE SHAFT HOUSING TRANSOM(L)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-98J20-YAY	HOUSING, DRIVE SHAFT (BLACK)	1	
1-2	52111-98J20-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	
2	09116-10176	BOLT (10X44)	6	
3	09202-08006	PIN (8X12)	2	
4	09140-10031	NUT	2	
5	09108-10150	STUD BOLT	2	
6	09160-10141	WASHER (10.5X19X2)	2	
7	09125-06063	SCREW (6X10)	1	
8	54150-98J00	MOUNT, LOWER THRUST	1	
9	54160-98J00	MOUNT, LOWER	2	
10	54112-93J00	BOLT, LOWER MOUNT	2	
11	09160-16050	WASHER (16X32X3)	2	
12	29159-93J00	NUT, LOWER MOUNT BOLT	2	
13	09160-16050	WASHER (16X32X3)	2	
14-1	54211-93J00-YAY	BRACKET, LOWER MOUNT (BLACK)	1	
14-2	54211-93J00-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	
15-1	54221-93J00-YAY	COVER, LOWER MOUNT (BLACK)	2	
15-2	54221-93J00-Y5S	COVER, LOWER MOUNT (WHITE)	2	
16	09116-10175	BOLT (10X50)	4	
17	54165-98J01	STOPPER, LOWER THRUST REVERSE	4	
18	09160-14066	WASHER (14X50X4)	2	
19	36894-87D00	LEAD (MOUNT BRKT TO HSG)	1	
20	09125-06063	SCREW (6X10)	1	

DF300A E03

FIG.407A




FIG.407A (1-F-11) GEAR CASE (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-93L10-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-93L10-Y5S	CASE, GEAR (WHITE)	1	
2	09206-03001	.BUSH (2X3X11)	1	
3	09263-35048	.BEARING (35X56X37)	1	
4	09263-80001	.BEARING (80X100X30)	1	
5-1	09100-12052	BOLT (12X70)	1	W/TRANSOM(L)
5-2	09100-12052	BOLT (12X70)	1	W/TRANSOM(X)
6-1	09116-10150	BOLT (10X55)	6	W/TRANSOM(L)
6-2	09116-10150	BOLT (10X55)	6	W/TRANSOM(X)
7	09160-10141	WASHER (10.5X19X2)	6	W/TRANSOM(XX)
8	09160-12066	WASHER (12.5X22X2.5)	1	W/TRANSOM(L)
				W/TRANSOM(X)
9	09140-10031	NUT	6	W/TRANSOM(XX)
10	09159-12014	NUT	1	W/TRANSOM(XX)
11	09202-08006	PIN (8X12)	2	
12-1	55125-93L00-YAY	TAB, TRIM (BLACK)	1	
12-2	55125-93L00-Y5S	TAB, TRIM (WHITE)	1	
13	09116-08137	BOLT (8X22)	1	
14	55128-93J10	PLUG, DRAIN	1	
15	09168-10034	GASKET (9.5X16.5X2)	2	
16	55321-93J01	ANODE, PROTECTION	2	
17	09116-06236	BOLT (6X16)	2	
18	55332-98J00	RUBBER, EXHAUST SEAL	1	
19	55333-98J00	PLATE, EXHAUST SEAL	1	
20	55127-87D00	UNION, SPEEDOMETER HOSE	1	
21-1	09355-40805-600	HOSE (4X8X600)	1	L:600->50
				W/TRANSOM(L)
				W/TRANSOM(X)
21-2	09355-40805-600	HOSE (4X8X600)	1	L:600->180
				W/TRANSOM(XX)
22	09362-09008	UNION	1	
23	09407-10404	CLAMP (L:100)	2	
24	09202-06031	PIN (6X12)	2	

FIG.407A




FIG.407A (1-F-12) GEAR CASE (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-1	58700-93L00	PROPELLER (3X16X17)	1	OPT W/REGULAR ROTATION
25-2	58700-93L10	PROPELLER (3X16X18.5)	1	OPT W/REGULAR ROTATION
25-3	58700-93L20	PROPELLER (3X16X20)	1	OPT W/REGULAR ROTATION
25-4	58700-93L30	PROPELLER (3X16X21.5)	1	OPT W/REGULAR ROTATION
25-5	58700-93L40	PROPELLER (3X16X23)	1	OPT W/REGULAR ROTATION
25-6	58700-93L50	PROPELLER (3X16X24.5)	1	OPT W/REGULAR ROTATION
25-7	58700-93L60	PROPELLER (3X16X26)	1	OPT W/REGULAR ROTATION
25-8	58700-93L70	PROPELLER (3X16X27.5)	1	OPT W/REGULAR ROTATION
25-9	58700-93L80	PROPELLER (3X16X15)	1	OPT W/REGULAR ROTATION
25-10	58700-93J00	PROPELLER (4X15.25X18)	1	OPT W/REGULAR ROTATION
25-11	58700-93J10	PROPELLER (4X15.25X20)	1	OPT W/REGULAR ROTATION
25-12	58700-93J20	PROPELLER (4X15.25X22)	1	OPT W/REGULAR ROTATION
25-13	58700-93J30	PROPELLER (4X15.25X24)	1	OPT W/REGULAR ROTATION
25-14	58700-93J40	PROPELLER (4X15.25X26)	1	OPT W/REGULAR ROTATION
25-15	58800-93L00	PROPELLER (3X16X17)	1	OPT W/COUNTER ROTATION
25-16	58800-93L10	PROPELLER (3X16X18.5)	1	OPT W/COUNTER ROTATION
25-17	58800-93L20	PROPELLER (3X16X20)	1	OPT W/COUNTER ROTATION

FIG.407A




FIG.407A (1-F-13) GEAR CASE (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-18	58800-93L30	PROPELLER (3X16X21.5)	1	OPT W/COUNTER ROTATION
25-19	58800-93L40	PROPELLER (3X16X23)	1	OPT W/COUNTER ROTATION
25-20	58800-93L50	PROPELLER (3X16X24.5)	1	OPT W/COUNTER ROTATION
25-21	58800-93L60	PROPELLER (3X16X26)	1	OPT W/COUNTER ROTATION
25-22	58800-93J10	PROPELLER (4X15.25X20)	1	OPT W/COUNTER ROTATION
25-23	58800-93J20	PROPELLER (4X15.25X22)	1	OPT W/COUNTER ROTATION
25-24	58800-93J30	PROPELLER (4X15.25X24)	1	OPT W/COUNTER ROTATION
25-25	58800-93J40	PROPELLER (4X15.25X26)	1	OPT W/COUNTER ROTATION
26	58120-93L00	.BUSH SET, PROPELLER	1	OPT
27-1	58700-96J00	PROPELLER (3X15.5X17)	1	OPT W/REGULAR ROTATION
27-2	58700-96J10	PROPELLER (3X15.25X19)	1	OPT W/REGULAR ROTATION
27-3	58700-96J20	PROPELLER (3X15X21)	1	OPT W/REGULAR ROTATION
27-4	58700-96J30	PROPELLER (3X14.75X23)	1	OPT W/REGULAR ROTATION
27-5	58700-96J40	PROPELLER (3X14.5X25)	1	OPT W/REGULAR ROTATION
27-6	58700-96J50	PROPELLER (3X14.5X27)	1	OPT W/REGULAR ROTATION
27-7	58800-96J00	PROPELLER (3X15.5X17)	1	OPT W/COUNTER ROTATION
27-8	58800-96J10	PROPELLER (3X15.25X19)	1	OPT W/COUNTER ROTATION

FIG.407A




FIG.407A (1-F-14) GEAR CASE (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27-9	58800-96J20	PROPELLER (3X15X21)	1	OPT W/COUNTER ROTATION
27-10	58800-96J30	PROPELLER (3X14.75X23)	1	OPT W/COUNTER ROTATION
27-11	58800-96J40	PROPELLER (3X14.5X25)	1	OPT W/COUNTER ROTATION
27-12	58800-96J50	PROPELLER (3X14.5X27)	1	OPT W/COUNTER ROTATION
28	58120-93L00	.BUSH SET, PROPELLER	1	OPT
29	57632-93L10	STOPPER, PROPELLER BUSH	1	
30	57633-93L00	SPACER, PROPELLER NUT	1	
31	09141-18005	NUT	1	
32	09160-18028	WASHER (18.5X31X1)	1	
33	09204-03003	COTTER PIN (D:3.6,L:25)	1	
34	55128-93L00	PLUG, DRAIN	1	
35	09160-12066	WASHER (12.5X22X2.5)	1	W/TRANSOM(XX)
36	57630-93L00	KIT, PROPELLER NUT	1	OPT
37	25700-93L01	KIT, GEAR CASE SEALING	1	OPT NOT ILLUSTRATED

DF300A E03

FIG.407B




FIG.407B (1-F-15) GEAR CASE (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-93L10-YAY	CASE, GEAR (BLACK)	1	
1-2	55110-93L10-Y5S	CASE, GEAR (WHITE)	1	
2	09206-03001	.BUSH (2X3X11)	1	
3	09263-35048	.BEARING (35X56X37)	1	
4	09263-80001	.BEARING (80X100X30)	1	
5	09100-12052	BOLT (12X70)	1	W/TRANSOM(X)
6	09116-10150	BOLT (10X55)	6	W/TRANSOM(X)
7	09160-10141	WASHER (10.5X19X2)	6	W/TRANSOM(XX)
8	09160-12066	WASHER (12.5X22X2.5)	1	W/TRANSOM(X)
9	09140-10031	NUT	6	W/TRANSOM(XX)
10	09159-12014	NUT	1	W/TRANSOM(XX)
11	09202-08006	PIN (8X12)	2	
12-1	55125-93L00-YAY	TAB, TRIM (BLACK)	1	
12-2	55125-93L00-Y5S	TAB, TRIM (WHITE)	1	
13	09116-08137	BOLT (8X22)	1	
14	55128-93J10	PLUG, DRAIN	1	
15	09168-10034	GASKET (9.5X16.5X2)	2	
16	55321-93J01	ANODE, PROTECTION	2	
17	09116-06236	BOLT (6X16)	2	
18	55332-98J00	RUBBER, EXHAUST SEAL	1	
19	55333-98J00	PLATE, EXHAUST SEAL	1	
20	55127-87D00	UNION, SPEEDOMETER HOSE	1	
21-1	09355-40805-600	HOSE (4X8X600)	1	L:600->50 W/TRANSOM(X)
21-2	09355-40805-600	HOSE (4X8X600)	1	L:600->180 W/TRANSOM(XX)
22	09362-09008	UNION	1	
23	09407-10404	CLAMP (L:100)	2	
24	09202-06031	PIN (6X12)	2	
25-1	58700-93L00	PROPELLER (3X16X17)	1	OPT W/REGULAR ROTATION

FIG.407B




FIG.407B (1-G-2) GEAR CASE (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-2	58700-93L10	PROPELLER (3X16X18.5)	1	OPT W/REGULAR ROTATION
25-3	58700-93L20	PROPELLER (3X16X20)	1	OPT W/REGULAR ROTATION
25-4	58700-93L30	PROPELLER (3X16X21.5)	1	OPT W/REGULAR ROTATION
25-5	58700-93L40	PROPELLER (3X16X23)	1	OPT W/REGULAR ROTATION
25-6	58700-93L50	PROPELLER (3X16X24.5)	1	OPT W/REGULAR ROTATION
25-7	58700-93L60	PROPELLER (3X16X26)	1	OPT W/REGULAR ROTATION
25-8	58700-93L70	PROPELLER (3X16X27.5)	1	OPT W/REGULAR ROTATION
25-9	58700-93L80	PROPELLER (3X16X15)	1	OPT W/REGULAR ROTATION
25-10	58700-93J00	PROPELLER (4X15.25X18)	1	OPT W/REGULAR ROTATION
25-11	58700-93J10	PROPELLER (4X15.25X20)	1	OPT W/REGULAR ROTATION
25-12	58700-93J20	PROPELLER (4X15.25X22)	1	OPT W/REGULAR ROTATION
25-13	58700-93J30	PROPELLER (4X15.25X24)	1	OPT W/REGULAR ROTATION
25-14	58700-93J40	PROPELLER (4X15.25X26)	1	OPT W/REGULAR ROTATION
25-15	58800-93L00	PROPELLER (3X16X17)	1	OPT W/COUNTER ROTATION
25-16	58800-93L10	PROPELLER (3X16X18.5)	1	OPT W/COUNTER ROTATION
25-17	58800-93L20	PROPELLER (3X16X20)	1	OPT W/COUNTER ROTATION
25-18	58800-93L30	PROPELLER (3X16X21.5)	1	OPT W/COUNTER ROTATION

FIG.407B




FIG.407B (1-G-3) GEAR CASE (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-19	58800-93L40	PROPELLER (3X16X23)	1	OPT W/COUNTER ROTATION
25-20	58800-93L50	PROPELLER (3X16X24.5)	1	OPT W/COUNTER ROTATION
25-21	58800-93L60	PROPELLER (3X16X26)	1	OPT W/COUNTER ROTATION
25-22	58800-93J10	PROPELLER (4X15.25X20)	1	OPT W/COUNTER ROTATION
25-23	58800-93J20	PROPELLER (4X15.25X22)	1	OPT W/COUNTER ROTATION
25-24	58800-93J30	PROPELLER (4X15.25X24)	1	OPT W/COUNTER ROTATION
25-25	58800-93J40	PROPELLER (4X15.25X26)	1	OPT W/COUNTER ROTATION
26	58120-93L00	.BUSH SET, PROPELLER	1	OPT

FIG.407B




FIG.407B (1-G-4) GEAR CASE (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27-1	58700-96J00	PROPELLER (3X15.5X17)	1	OPT W/REGULAR ROTATION
27-2	58700-96J10	PROPELLER (3X15.25X19)	1	OPT W/REGULAR ROTATION
27-3	58700-96J20	PROPELLER (3X15X21)	1	OPT W/REGULAR ROTATION
27-4	58700-96J30	PROPELLER (3X14.75X23)	1	OPT W/REGULAR ROTATION
27-5	58700-96J40	PROPELLER (3X14.5X25)	1	OPT W/REGULAR ROTATION
27-6	58700-96J50	PROPELLER (3X14.5X27)	1	OPT W/REGULAR ROTATION
27-7	58800-96J00	PROPELLER (3X15.5X17)	1	OPT W/COUNTER ROTATION
27-8	58800-96J10	PROPELLER (3X15.25X19)	1	OPT W/COUNTER ROTATION
27-9	58800-96J20	PROPELLER (3X15X21)	1	OPT W/COUNTER ROTATION
27-10	58800-96J30	PROPELLER (3X14.75X23)	1	OPT W/COUNTER ROTATION

FIG.407B




FIG.407B (1-G-5) GEAR CASE (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27-11	58800-96J40	PROPELLER (3X14.5X25)	1	OPT W/COUNTER ROTATION
27-12	58800-96J50	PROPELLER (3X14.5X27)	1	OPT W/COUNTER ROTATION
28	58120-93L00	.BUSH SET, PROPELLER	1	OPT
29	57632-93L10	STOPPER, PROPELLER BUSH	1	
30	57633-93L00	SPACER, PROPELLER NUT	1	
31	09141-18005	NUT	1	
32	09160-18028	WASHER (18.5X31X1)	1	
33	09204-03003	COTTER PIN (D:3.6,L:25)	1	
34	55128-93L00	PLUG, DRAIN	1	
35	09160-12066	WASHER (12.5X22X2.5)	1	W/TRANSOM(XX)
36	57630-93L00	KIT, PROPELLER NUT	1	OPT
37	25700-93L01	KIT, GEAR CASE SEALING	1	OPT NOT ILLUSTRATED

DF250A E03

FIG.410A




FIG.410A (1-G-6) SIDE COVER TRANSOM(X,XX)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61131-93J01-YAY	COVER, OIL PAN STBD (BLACK)	1	
1-2	61131-93J01-Y5S	COVER, OIL PAN STBD (WHITE)	1	
2-1	61141-93J01-YAY	COVER, OIL PAN PORT (BLACK)	1	
2-2	61141-93J01-Y5S	COVER, OIL PAN PORT (WHITE)	1	
3	61137-93J00	CUSHION, OIL PAN COV UPPER	2	
4	09139-06135	SCREW (6X17)	5	
5	09139-06136	SCREW (6X65)	3	
6-1	61811-98J20-YAY	COVER, SIDE STBD (BLACK)	1	
6-2	61811-98J20-Y5S	COVER, SIDE STBD (WHITE)	1	
7-1	61821-98J10-YAY	COVER, SIDE PORT (BLACK)	1	
7-2	61821-98J10-Y5S	COVER, SIDE PORT (WHITE)	1	
8	61134-93J20	SEAL, SIDE COVER	1	
9	09409-05302-5PK	CLIP (BLACK)	2	
10	61817-93J00	PLUG, SIDE COVER	2	
11	09136-06148	SCREW (6X35)	10	
12	61827-93J02	HOLDER, SIDE COVER	1	
13	09321-10030	CUSHION	2	
14	01550-08167	BOLT	2	
15	61832-98J00	SEAL, FRONT PANEL STBD	1	
16	61812-98J00	SEAL, SIDE COVER	1	
17	61814-98J00	PROTECTOR, SIDE COVER	1	
18-1	61831-98J02-YAY	PANEL, FRONT (BLACK)	1	
18-2	61831-98J02-Y5S	PANEL, FRONT (WHITE)	1	
19	09116-08174	BOLT (8X38)	2	
20	09169-08039	WASHER	2	
21	09320-11013	CUSHION	2	
22	09321-10030	CUSHION	3	
23	17913-93J00	PLUG, WATER	1	
24	17914-93J00	GASKET, WATER PLUG	1	

FIG.410A




FIG.410A (1-G-7) SIDE COVER TRANSOM(X,XX)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25	61112-98J00	RUBBER, SIDE COVER	1	
26	61630-98J00	SHAFT, COVER HOOK (FRONT)	1	
27	63632-98J20	SHAFT, COVER HOOK (PORT)	1	
28	63632-98J30	SHAFT, COVER HOOK (STBD)	1	
29	09306-17002	BUSH	3	
30	09160-17052	WASHER (17X30X3)	3	
31	61636-98J00	BUSH	3	
32-1	61633-98J10-YAY	LEVER, HOOK RR STBD (BLACK)	1	
32-2	61633-98J10-Y5S	LEVER, HOOK RR STBD (WHITE)	1	
33-1	61634-98J10-YAY	LEVER, HOOK RR PORT (BLACK)	1	
33-2	61634-98J10-Y5S	LEVER, HOOK RR PORT (WHITE)	1	
34-1	61645-98J00-YAY	LEVER, HOOK FRONT (BLACK)	1	
34-2	61645-98J00-Y5S	LEVER, HOOK FRONT (WHITE)	1	
35	29103-93J20	BOLT, HOOK LEVER (8X45) (STBD / PORT)	2	
36	29103-93J30	BOLT, HOOK LEVER (8X25) (FRONT)	1	
37	09160-08152	WASHER (8.5X28X1.5)	2	
38	09160-08082	WASHER (8.5X16X1.2)	1	
39	61635-98J00	SPACER	2	
40	61643-98J00	BUSH	2	
41	61658-98J00	SPRING, HOOK SHAFT	3	
42	09329-14002	CUSHION	1	
43	61124-98J20	GROMMET, REMOCON CABLE	1	
44	09407-25402	CLAMP (L:250)	1	
45	61458-90J00	LABEL, ENGINE COVER	1	
46	67361-90J10	ADAPTER, HOSE (RIGGING)	1	
47	09208-06009	PIN	2	
48	09383-04002	E RING	2	

FIG.410B




FIG.410B (1-G-8) SIDE COVER TRANSOM(L)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61131-93J20-YAY	COVER, OIL PAN STBD (BLACK)	1	
1-2	61131-93J20-Y5S	COVER, OIL PAN STBD (WHITE)	1	
2-1	61141-93J20-YAY	COVER, OIL PAN PORT (BLACK)	1	
2-2	61141-93J20-Y5S	COVER, OIL PAN PORT (WHITE)	1	
3	61137-93J00	CUSHION, OIL PAN COV UPPER	2	
4	09136-06161	SCREW (6X17)	8	
5	09136-06148	SCREW (6X35)	3	
6-1	61811-98J20-YAY	COVER, SIDE STBD (BLACK)	1	
6-2	61811-98J20-Y5S	COVER, SIDE STBD (WHITE)	1	
7-1	61821-98J10-YAY	COVER, SIDE PORT (BLACK)	1	
7-2	61821-98J10-Y5S	COVER, SIDE PORT (WHITE)	1	
8	61134-93J20	SEAL, SIDE COVER	1	
9	09409-05302-5PK	CLIP (BLACK)	2	
10	61817-93J00	PLUG, SIDE COVER	2	
11	09136-06148	SCREW (6X35)	10	
12	61827-93J02	HOLDER, SIDE COVER	1	
13	09321-10030	CUSHION	2	
14	01550-08167	BOLT	2	
15	61832-98J00	SEAL, FRONT PANEL STBD	1	
16	61812-98J00	SEAL, SIDE COVER	1	
17	61814-98J00	PROTECTOR, SIDE COVER	1	
18-1	61831-98J02-YAY	PANEL, FRONT (BLACK)	1	
18-2	61831-98J02-Y5S	PANEL, FRONT (WHITE)	1	
19	09116-08174	BOLT (8X38)	2	
20	09169-08039	WASHER	2	
21	09320-11013	CUSHION	2	
22	09321-10030	CUSHION	3	
23	17913-93J00	PLUG, WATER	1	
24	17914-93J00	GASKET, WATER PLUG	1	
25	61112-98J00	RUBBER, SIDE COVER	1	

FIG.410B




FIG.410B (1-G-9) SIDE COVER TRANSOM(L)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26	61630-98J00	SHAFT, COVER HOOK (FRONT)	1	
27	63632-98J20	SHAFT, COVER HOOK (PORT)	1	
28	63632-98J30	SHAFT, COVER HOOK (STBD)	1	
29	09306-17002	BUSH	3	
30	09160-17052	WASHER (17X30X3)	3	
31	61636-98J00	BUSH	3	
32-1	61633-98J10-YAY	LEVER, HOOK RR STBD (BLACK)	1	
32-2	61633-98J10-Y5S	LEVER, HOOK RR STBD (WHITE)	1	
33-1	61634-98J10-YAY	LEVER, HOOK RR PORT (BLACK)	1	
33-2	61634-98J10-Y5S	LEVER, HOOK RR PORT (WHITE)	1	
34-1	61645-98J00-YAY	LEVER, HOOK FRONT (BLACK)	1	
34-2	61645-98J00-Y5S	LEVER, HOOK FRONT (WHITE)	1	
35	29103-93J20	BOLT, HOOK LEVER (8X45) (STBD / PORT)	2	
36	29103-93J30	BOLT, HOOK LEVER (8X25) (FRONT)	1	
37	09160-08152	WASHER (8.5X28X1.5)	2	
38	09160-08082	WASHER (8.5X16X1.2)	1	
39	61635-98J00	SPACER	2	
40	61643-98J00	BUSH	2	
41	61658-98J00	SPRING, HOOK SHAFT	3	
42	09329-14002	CUSHION	1	
43	61124-98J20	GROMMET, REMOCON CABLE	1	
44	09407-25402	CLAMP (L:250)	1	
45	61458-90J00	LABEL, ENGINE COVER	1	
46	67361-90J10	ADAPTER, HOSE (RIGGING)	1	
47	09208-06009	PIN	2	
48	09383-04002	E RING	2	

DF300A E03

FIG.420A




FIG.420A (1-G-10) ENGINE COVER (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61420-98800-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61420-98810-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-98J10-YAY	.COVER, TOP (BLACK)	1	
2-2	61431-98J10-Y5S	.COVER, TOP (WHITE)	1	
3	61432-98J01	.LOUVER, AIR INTAKE	1	
4	61433-98J01	.GRIP, UPPER COVER STBD	1	
5	61434-98J02	.GRIP, UPPER COVER PORT	1	
6	61439-98J00	.SEAL, GRIP STBD	1	
7	61439-98J10	.SEAL, GRIP PORT	1	
8	61439-98J21	.SEAL, AIR VENT NO.2	1	
9	61476-98J00	.SEAL, AIR VENT NO.1	1	
10	01550-06167	.BOLT	2	
11	01550-06207	.BOLT	3	
12	01550-06167	.BOLT	3	
13	03542-06169	.SCREW	5	
14	01550-06167	.BOLT	4	
15	03542-06169	.SCREW	4	
16	61610-98J00	.FASTENER (FRONT)	1	
17	61610-98J30	.FASTENER (PORT)	1	
18	61610-98J40	.FASTENER (STBD)	1	
19	77811-54GC0-0PG	.EMBLEM S (CHROME)	1	
20	61614-98J00	.PROTECTOR, FASTENER	1	
21	61621-98J02	.BRACKET, FASTENER FRONT	1	
22	61624-98J11	.BRACKET, FASTENER PORT	1	
23	61625-98J11	.BRACKET, FASTENER STBD	1	
24	61619-98J00	.CUSHION, ENG COV FASTENER	3	
25	01547-06167	.BOLT	6	
26	01550-06127	.BOLT	1	
27	01550-06127	.BOLT	2	
28	61425-98J00	.CUSHION, ENGINE COVER	1	

DF300A_E03_019_420A
ENGINE COVER

FIG.420A




FIG.420A (1-G-11) ENGINE COVER (DF300A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29-1	61443-96J70	.STRIPE, ENGINE COVER STBD	1	FOR YAY
29-2	61443-96J80	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
30-1	61453-96J70	.STRIPE, ENGINE COVER PORT	1	FOR YAY
30-2	61453-96J80	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
31	61441-98L00	.MARK, SUZUKI	2	
32-1	61422-98J50	MARK, EMBLEM FRONT (300)	1	FOR YAY
32-2	61422-98J30	MARK, EMBLEM FRONT (300)	1	FOR Y5S
33-1	61435-98J50	MARK, EMBLEM REAR (300)	1	FOR YAY
33-2	61435-98J30	MARK, EMBLEM REAR (300)	1	FOR Y5S
34	09800-81835	TOOL SET	1	
35-1	99011-98J80-054	MANUAL, OWNER'S	1	
35-2	99011-98J80-03B	MANUAL, OWNER'S	1	
36	68110-98J01	COVER, WEATHER	1	OPT

DF300A E03

FIG.420B




FIG.420B (1-G-12) ENGINE COVER (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61420-98800-YAY	COVER SET, ENGINE (BLACK)	1	
1-2	61420-98810-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-98J10-YAY	.COVER, TOP (BLACK)	1	
2-2	61431-98J10-Y5S	.COVER, TOP (WHITE)	1	
3	61432-98J01	.LOUVER, AIR INTAKE	1	
4	61433-98J01	.GRIP, UPPER COVER STBD	1	
5	61434-98J02	.GRIP, UPPER COVER PORT	1	
6	61439-98J00	.SEAL, GRIP STBD	1	
7	61439-98J10	.SEAL, GRIP PORT	1	
8	61439-98J21	.SEAL, AIR VENT NO.2	1	
9	61476-98J00	.SEAL, AIR VENT NO.1	1	
10	01550-06167	.BOLT	2	
11	01550-06207	.BOLT	3	
12	01550-06167	.BOLT	3	
13	03542-06169	.SCREW	5	
14	01550-06167	.BOLT	4	
15	03542-06169	.SCREW	4	
16	61610-98J00	.FASTENER (FRONT)	1	
17	61610-98J30	.FASTENER (PORT)	1	
18	61610-98J40	.FASTENER (STBD)	1	
19	77811-54GC0-0PG	.EMBLEM S (CHROME)	1	
20	61614-98J00	.PROTECTOR, FASTENER	1	
21	61621-98J02	.BRACKET, FASTENER FRONT	1	
22	61624-98J11	.BRACKET, FASTENER PORT	1	
23	61625-98J11	.BRACKET, FASTENER STBD	1	
24	61619-98J00	.CUSHION, ENG COV FASTENER	3	
25	01547-06167	.BOLT	6	
26	01550-06127	.BOLT	1	
27	01550-06127	.BOLT	2	
28	61425-98J00	.CUSHION, ENGINE COVER	1	

DF300A_E03_019_420B
ENGINE COVER

FIG.420B




FIG.420B (1-G-13) ENGINE COVER (DF250A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29-1	61443-96J70	.STRIPE, ENGINE COVER STBD	1	FOR YAY
29-2	61443-96J80	.STRIPE, ENGINE COVER STBD	1	FOR Y5S
30-1	61453-96J70	.STRIPE, ENGINE COVER PORT	1	FOR YAY
30-2	61453-96J80	.STRIPE, ENGINE COVER PORT	1	FOR Y5S
31	61441-98L00	.MARK, SUZUKI	2	
32-1	61422-98J40	MARK, EMBLEM FRONT (250)	1	FOR YAY
32-2	61422-93JE0	MARK, EMBLEM FRONT (250)	1	FOR Y5S
33-1	61435-98J60	MARK, EMBLEM REAR (250)	1	FOR YAY
33-2	61435-93JD0	MARK, EMBLEM REAR (250)	1	FOR Y5S
34	09800-81835	TOOL SET	1	
35-1	99011-98J80-054	MANUAL, OWNER'S	1	
35-2	99011-98J80-03B	MANUAL, OWNER'S	1	
36	68110-98J01	COVER, WEATHER	1	OPT

DF250A E03

FIG.475A




FIG.475A (1-G-14) SQUEEZE PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65770-93J04	PUMP, SQUEEZE	1	

FIG.520A




FIG.520A (1-G-15) OPT:FLUSH MOUNT REMOCON

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J23	REMOCON ASSY, FLUSH MOUNT	1	
2	67271-98J20	.COVER, BOTTON BASE	1	
3	67264-98J00	.COVER, TOP BASE	1	
4	67263-98J20	.COVER, LEVER	1	
5	67261-98J20	.GRIP, A	1	
6	67261-98J30	.GRIP, B	1	
7	67265-98J00	.BUTTON, NEUTRAL LOCK	1	
8	67255-98J00	.LINK, NEUTRAL LOCK NO.1	1	
9	67258-98J00	.PLATE, JOINT	1	
10	67256-98J00	.BLOCK, NEUTRAL LOCK	1	
11	67259-98J00	.SPRING	3	
12	67251-98J20	.LEVER, HANDLE	1	
13	67294-98J00	.SPACER	1	
14	67254-98J00	.LINK, NEUTRAL LOCK NO.2	1	
15	67233-98J00	.SLIDER, NEUTRAL BUTTON	1	
16	67296-98JA0	.SCREW (4X10)	3	
17	67234-98J00	.PLATE, LEVER	1	
18	67211-98J20	.HOUSING	1	
19	67269-98J20	.CLAMP, LEAD	1	
20	67296-98JB0	.SCREW (4X30)	1	
21	67227-98J20	.SCREW, TAPPING (4X35)	1	
22	67227-98J30	.SCREW, TAPPING (4X20)	1	
23	67288-98J50	.WASHER, PLANE	8	
24	67296-98JC0	.SCREW (6X40)	4	
25	67287-98J00	.NUT	4	
26	67226-98J10	.BOLT (6X50)	4	
27	67288-98J60	.WASHER	3	
28	67296-98JD0	.SCREW (5X40)	1	
29	67238-98J00	.PIN	2	
30	67288-98J70	.WASHER, PLANE	5	
31	67246-98J00	.SHAFT, DRIVE REMOCON	1	
32	67222-98J00	.PANEL ASSY, BACK	1	
33	67236-98J00	.ROLLER, DETENT	1	
34	67235-98J00	.GUIDE, DETENT ROLLER	1	

FIG.520A




FIG.520A (1-H-2) OPT:FLUSH MOUNT REMOCON

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67237-98J00	.SPRING, DETENT	1	
36	67223-98J00	.PAD, BRAKE	1	
37	67296-98JE0	.SCREW, ADJUST (5X35)	1	
38	67252-98J00	.BUSH, DRIVE	1	
39	67288-98J20	.WASHER, PLANE	1	
40	67292-98J00	.C RING	1	
41	15980-98J00	.POTENTIOMETER	1	
42	67227-98J10	.LEVER, POTENTIOMETER NO.2	1	
43	67296-94300	.SCREW (4X10)	2	
44	67288-98J00	.WASHER, PLANE	5	
45	67296-98J10	.SCREW (5X35)	1	
46	67288-98J10	.WASHER, SPRING	8	
47	67228-98J50	.WASHER, WAVE	2	
48	67296-98J60	.SCREW (8X30)	1	
49	09160-06104	.WASHER (6.5X24X2)	4	
50	67296-98J50	.SCREW (5X18)	2	
51	67272-98J00	.GROMMET	2	
52	37850-98J02	.SWITCH ASSY, PTT	1	
53	67269-98J10	.BAND	1	
54	67257-98J00	.MARK, LEVER (S)	1	
55	36890-98J00	.HARNESS, CONDENSER ADAPTER	1	

FIG.522A




FIG.522A (1-H-3) OPT:HARNESS (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-98J51	WIRE ASSY, REMOCON EXTENSION	1	
2	33830-98J11	SET, BATTERY ISOLATOR LEAD	1	
3	09407-10404	.CLAMP (L:100)	2	
4	09481-40401	.FUSE (40A)	1	
5	33911-88BL0	CAP, BCM CONNECTOR	1	
6	33925-93J00	CUSHION, BCM	AR	
7	33926-98J00	RESISTOR, TERMINAL	AR	
8	36623-98J20	HARNESS ASSY, BCM NO.1 FOR SNGL	1	
9	36615-96300	.TERMINAL RESIN	4	
10-1	36770-98J13	CONTROLLER ASSY, BOAT ELECTRIC	1	
10-2	36770-98J22	CONTROLLER, BOAT ELEC QUADRUPLE	2	
11	36775-98J00	HOLDER, BCM (L)	AR	
12	36776-98J00	HOLDER, BCM (R)	AR	
13	36622-98J00	HARNESS ASSY, DUAL STATION MAIN	AR	
14	09481-10501	.FUSE (10A)	AR	
15	36624-98J02	HARNESS ASSY, BCM NO.2 FOR SNGL	1	
16	36615-96300	.TERMINAL, RESIN	2	
17	36621-98J00	HARNESS ASSY, DUAL ENGINE	AR	
18	36623-98J30	HARNESS ASSY, BCM NO.1 FOR MULT	1	
19	36615-96300	.TERMINAL, RESIN	5	
20	36624-98J11	HARNESS ASSY, BCM NO.2 FOR MULT	1	
21	36615-96300	.TERMINAL, RESIN	2	
22	36621-98J10	HARNESS ASSY, TRIPLE ENGINE	1	
23	09403-13402	CLAMP (ID:13)	AR	
24-1	36612-98J01	CONNECTOR, COUNTER SELECT (GREEN)	1	
24-2	36612-98J20	CONNECTOR, COUNTER SELECT (WHITE)	AR	
25	36990-87D00	TERIMINAL SET, WITH SLEEVE	1	
26	36667-96L20	WIRE, GAUGE EXT	1	

FIG.523A




FIG.523A (1-H-4) OPT:HARNESS (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36625-98J10	WIRE ASSY, BATTERY	AR	
2	09481-30501	.FUSE (30A)	AR	
3	36623-98J40	HARNESS ASSY, BCM QUADRUPLE	1	
4	36615-96300	.TERMINAL	8	
5	36627-98J00	.HARNESS COMP, R/CON EXTENSION	1	
6	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF300A_E03_019_523A
OPT:HARNESS (2)

FIG.530A




FIG.530A (1-H-5) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-98J05	PANEL ASSY, MAIN SW	1	
2	37110-98J01	.SWITCH ASSY, MAIN	1	
3-1	37141-99EA0	..KEY (941)	1	
3-2	37141-99EB0	..KEY (942)	1	
3-3	37141-99E00	..KEY (931)	1	
3-4	37141-99E10	..KEY (932)	1	
3-5	37141-99E20	..KEY (933)	1	
3-6	37141-99E30	..KEY (934)	1	
3-7	37141-99E40	..KEY (935)	1	
3-8	37141-99E50	..KEY (936)	1	
3-9	37141-99E60	..KEY (937)	1	
3-10	37141-99E70	..KEY (938)	1	
3-11	37141-99E80	..KEY (939)	1	
3-12	37141-99E90	..KEY (940)	1	
4	37143-99E00	..CAP, KEY	1	
5	37139-98J10	.PANEL, MAIN SW	1	
6	37820-93J10	.SWITCH ASSY, EMERGENCY STOP	1	
7	37823-92E01	..PLATE ASSY, EMERGENCY SW LOCK	1	
8	37826-92J10	..NUT	1	
9	03122-05165	.SCREW	4	
10	37114-98J00	.SHEET, MAIN SW PANEL	1	
11	37100-98J11	PANEL ASSY, SINGLE	1	
12	37112-98J00	.NUT	1	
13	38500-93J90	BUZZER ASSY, WARNING	AR	
14	09407-08401	CLAMP (L:80)	AR	
15	37803-93J05	PANEL ASSY, EMERGENCY SW	1	
16	37825-99E10	.PANEL, EMERGENCY STOP SW	1	
17	37820-93J10	.SWITCH ASSY, EMERGENCY STOP	1	
18	37823-92E01	..PLATE ASSY, EMERGENCY SW LOCK	1	
19	37826-92J10	..NUT	1	
20	03122-05165	.SCREW	4	
21	37100-98J21	PANEL ASSY, DUAL	AR	
22	37112-98J10	.NUT	AR	

DF300A_E03_019_530A
OPT:SWITCH

FIG.530A




FIG.530A (1-H-6) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23	37100-98J31	PANEL ASSY, TRIPLE	1	
24	37112-98J10	.NUT	1	
25	37860-87L00	PANEL ASSY, TROLLING CTR SW	1	
26	37862-87L00	.PANEL	1	
27	09131-05004	.SCREW (5X16)	4	

DF300A_E03_019_530A
OPT:SWITCH

FIG.535A




FIG.535A (1-H-7) OPT:KEY LESS START

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96L01	PANEL ASSY, MAIN SWITCH KLS	1	
2	37110-96L00	.SWITCH ASSY, MAIN	1	
3-1	37141-99E00	..KEY (931)	1	
3-2	37141-99E10	..KEY (932)	1	
3-3	37141-99E20	..KEY (933)	1	
3-4	37141-99E30	..KEY (934)	1	
3-5	37141-99E40	..KEY (935)	1	
3-6	37141-99E50	..KEY (936)	1	
4	37143-96L00	..KNOB, MAIN SWITCH	1	
5	37114-98J00	.SHEET, MAIN SWITCH PANEL	1	
6	37139-96L30	.PANEL, MAIN SWITCH	1	
7	37820-93J10	.SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SW LOCK	1	
9	37826-92J10	..NUT	1	
10	03122-05165	.SCREW	4	
11	37105-96L02	HARNESS SET, KLS CONTROLLER	1	
12	32980-38F00	.HOLDER, KLS CONT	1	
13	36623-96L01	.HARNESS ASSY, KLS CONT	1	
14	36615-96300	..TERMINAL, RESIN	1	
15	36662-96L00	.HARNESS ASSY, KLS CAN EXT	1	L:6500+110
16	37173-96L10	.HOLDER, KLS PARTS	1	
17	38500-93J90	.BUZZER ASSY, KLS	1	
18	38860-96L01	.RELAY ASSY, KLS	1	
19	32851-93J00	.CUSHION, LEAD WIRE	1	
20	09407-14407	.CLAMP (L:145)	1	
21-1	37170-96L14	CONTROLLER SET, KLS 315MHZ	1	
21-2	37170-96L04	CONTROLLER SET, KLS 433MHZ	1	
22	37117-96L00	.DECAL, KLS	2	

DF300A_E03_019_535A
OPT:KEY LESS START

FIG.535A




FIG.535A (1-H-8) OPT:KEY LESS START

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
23-1	37171-96L12	.CONTROLLER ASSY, KLS 315MHZ	1	
23-2	37171-96L02	.CONTROLLER ASSY, KLS 433MHZ	1	
24-1	37172-96L10	.REMOCON ASSY, KLS 315MHZ	2	
24-2	37172-96L01	.REMOCON ASSY, KLS 433MHZ	2	
25	36663-96L00	WIRE, KLS CAN EXT	1	
26	36664-96L00	HARNESS ASSY, KLS CAN	AR	L:810+110
27	37173-96L00	HOLDER, KLS PARTS	1	

NOTE: USE FREQUENCY ASSIGNED ON YOUR MARKET.
FOR DETAILES, PLEASE MAKE SURE OF SUZUKI DEALERS.

FIG.540A




FIG.540A (1-H-9) OPT:REMOTE CONTROL ASSY DUAL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J14	REMOTE CONTROL ASSY	1	
2	67211-98J20	.HOUSING (L)	1	
3	67251-98J00	.LEVER, HANDLE	2	
4	67246-98J10	.SHAFT, DRIVE (L)	1	
5	67261-98J00	.GRIP, NO.1	1	
6	67261-98J10	.GRIP, NO.2	1	
7	67263-98J00	.COVER, LEVER	2	
8	67212-98J30	.COVER, UPPER	1	
9	67271-98J40	.COVER, BOTTOM	1	
10	67222-98J10	.PANEL ASSY, BACK (L)	1	
11	67236-98J10	.ROOLER, DETENT	2	
12	67235-98J10	.GUIDE, DETENT ROOLER	2	
13	67237-98J40	.SPRING, DETENT	2	
14	67233-98J10	.HOLDER, DETENT SPRING	2	
15	67287-92E00	.NUT	2	
16	67239-98J00	.SCREW, DETENT ADJUST	2	
17	67223-98J00	.PAD, BRAKE	2	
18	67296-98J50	.SCREW (5X18)	8	
19	67296-98JA0	.SCREW (4X10)	2	
20	67272-98J10	.GROMMET, COVER	2	
21	67252-98J10	.BUSH, DRIVE SHAFT	2	
22	67288-98J20	.WASHER	2	
23	67292-98J00	.C RING	2	
24	15980-98J00	.POTENTIOMETER	2	
25	67227-98J10	.LEVER, POTENTIOMETER NO.2	1	
26	37850-98J02	.SWITCH ASSY, PTT	1	
27	67269-98J00	.CLAMP, LEAD	1	
28	67273-98J20	.PACKING	1	
29	67296-98J60	.SCREW (8X30)	2	
30	67296-98J30	.SCREW (5X70)	4	
31	67296-98JG0	.SCREW (5X14)	2	
32	67296-98J00	.SCREW (5X12)	1	
33	67296-94300	.SCREW (4X10)	4	
34	67288-98J40	.WASHER	14	

DF300A_E03_019_540A
OPT:REMOTE CONTROL ASSY DUAL

FIG.540A




FIG.540A (1-H-10) OPT:REMOTE CONTROL ASSY DUAL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67288-98J00	.WASHER	4	
36	67288-92E20	.WASHER	2	
37	67226-98J00	.BOLT (5X50)	4	
38	09160-05024	.WASHER (5.5X16X1.5)	4	
39	67287-92E00	.NUT	4	
40	67296-98J90	.SCREW	2	
41	67227-98J00	.LEVER, POTENTIOMETER NO.1	1	
42	67284-98J10	.MARK (F-N-R)	1	
43	67257-98J00	.MARK, LEVER (S)	2	
44	67269-98J30	.BAND	1	
45	67288-98J10	.WASHER, SPRING	16	
46	67288-98J30	.WASHER	2	
47	67228-98J50	.WASHER, WAVE	2	
48	67211-98J30	.HOUSING (R)	1	
49	67222-98J20	.PANEL ASSY, BACK (R)	1	
50	67246-98J20	.SHAFT, DRIVE (R)	1	
51	67273-98J10	.PACKING (FRONT)	1	
52	67273-98J30	.PACKING (REAR)	1	
53	67277-98J00	.GROMMET	1	
54	67296-98JF0	.BOLT (5X14)	1	
55	67297-98J00	.NUT	1	
56	67237-98J50	.SPRING, DETENT	2	
57	36890-98J00	.HARNESS, CONDENSER ADAPTER	1	
58-1	36620-98J31	WIRE ASSY, REMOTE CONTROL	1	L:6500
58-2	36620-98J41	WIRE ASSY, REMOTE CONTROL	1	L:9500

DF300A_E03_019_540A
OPT:REMOTE CONTROL ASSY DUAL

FIG.543A




FIG.543A (1-H-11) OPT:REMOTE CONTROL ASSY SINGLE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J04	REMOTE CONTROL ASSY	1	
2	67211-98J20	.HOUSING	1	
3	67251-98J00	.LEVER, HANDLE	1	
4	67246-98J10	.SHAFT, DRIVE	1	
5	67261-98J00	.GRIP, NO.1	1	
6	67263-98J00	.COVER, LEVER	1	
7	67212-98J20	.COVER, UPPER	1	
8	67271-98J30	.COVER, BOTTOM	1	
9	67222-98J10	.PANEL ASSY, BACK	1	
10	67236-98J10	.ROLLER, DETENT	1	
11	67235-98J10	.GUIDE, DETENT ROLLER	1	
12	67237-98J30	.SPRING, DETENT	1	
13	67233-98J10	.HOLDER, DETENT SPRING	1	
14	67287-92E00	.NUT	1	
15	67239-98J00	.SCREW, DETENT ADJUST	1	
16	67223-98J00	.PAD, BRAKE	1	
17	67296-98J50	.SCREW (5X18)	6	
18	67296-98JA0	.SCREW (4X10)	1	
19	67272-98J10	.GROMMET, COVER	1	
20	67252-98J10	.BUSH, DRIVE SHAFT	1	
21	67288-98J20	.WASHER	1	
22	67292-98J00	.C RING	1	
23	15980-98J00	.POTENTIOMETER	1	
24	67227-98J10	.LEVER, POTENTIOMETER NO.2	1	
25	37850-98J02	.SWITCH ASSY, PTT	1	
26	67269-98J00	.CLAMP, LEAD	1	
27	67273-98J00	.PACKING	1	
28	67296-98J60	.SCREW (8X30)	1	
29	67274-98J00	.FLANGE, BASE	1	
30	67288-92E20	.WASHER	1	
31	67296-98J90	.SCREW	1	
32	67296-98JG0	.SCREW (5X14)	1	
33	67296-94300	.SCREW (4X10)	2	
34	67288-98J00	.WASHER	2	

DF300A_E03_019_543A
OPT:REMOTE CONTROL ASSY SINGLE

FIG.543A




FIG.543A (1-H-12) OPT:REMOTE CONTROL ASSY SINGLE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67296-98J20	.SCREW (5X50)	2	
36	67226-98J00	.BOLT (5X50)	4	
37	09160-05024	.WASHER (5.5X16X1.5)	4	
38	67287-92E00	.NUT	4	
39	67296-98J00	.SCREW (5X12)	1	
40	67288-98J40	.WASHER	12	
41	67296-98J10	.SCREW (5X35)	1	
42	67284-98J10	.MARK (F-N-R)	1	
43	67257-98J00	.MARK, LEVER (S)	1	
44	67269-98J30	.BAND	1	
45	67288-98J10	.WASHER, SPRING	8	
46	67288-98J30	.WASHER	1	
47	67228-98J50	.WASHER, WAVE	1	
48	67273-98J10	.PACKING (FRONT)	1	
49	67273-98J30	.PACKING (REAR)	1	
50	67277-98J00	.GROMMET	1	
51	67296-98JF0	.BOLT (5X14)	1	
52	67297-98J00	.NUT	1	
53	36890-98J00	.HARNESS, CONDENSER ADAPTER	1	
54-1	36620-98J31	WIRE ASSY, REMOTE CONTROL	1	L:6500
54-2	36620-98J41	WIRE ASSY, REMOTE CONTROL	1	L:9500

DF300A_E03_019_543A
OPT:REMOTE CONTROL ASSY SINGLE

FIG.585A




FIG.585A (1-H-13) OPT:GASKET SET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11410-98830	GASKET SET	1	
2	11141-98J10	.GASKET, CYL HEAD STBD	1	
3	11142-98J10	.GASKET, CYL HEAD PORT	1	
4	11179-93J00	.GASKET, CYL HEAD COVER STBD	1	
5	11189-93J00	.GASKET, CYL HEAD COVER PORT	1	
6	11332-93J00	.GASKET, CRANKCASE WTR JKT COV	1	
7	13119-98J00	.GASKET, INTAKE MANIFOLD	2	
8	14151-93J00	.GASKET, EXH COVER STBD	1	
9	14152-93J00	.GASKET, EXH COVER PORT	1	
10	17472-98J00	.GASKET, PUMP CASE PANEL	1	
11	11272-93J00	.GASKET, CYL BLOCK PLATE	1	
12	11489-93J00	.GASKET, OIL PAN	1	
13	14212-93J00	.GASKET, EXHAUST TUBE	1	
14	51123-93J00	.GASKET, MOUNT OIL SEAL COVER	1	
15	51142-93J00	.GASKET, ENGINE HOLDER COVER	1	
16	51211-93J00	.GASKET, ENGINE HOLDER	1	

FIG.601A




FIG.601A (1-H-14) OPT:MULTI FUNCTION GAUGE (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L63	KIT, SINGLE GAUGE ELECTRIC	1	
2	34011-96L13	.GAUGE SET, MULTI	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L20	.ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL, RESIN	5	
9	34000-96L73	KIT, DUAL GAUGE ELECTRIC	1	
10	34011-96L13	.GAUGE SET, MULTI	2	
11	34112-96L00	..NUT, GAUGE	2	
12	34193-96L00	..BEZEL, GAUGE	2	
13	34211-96L00	..COVER, GAUGE	2	
14	34825-96L00	..PACKING, GAUGE	2	
15	36661-96L20	.ADAPTER, GAUGE	1	
16	36615-96300	..TERMINAL, RESIN	5	
17	36662-88L10	.WIRE, 2 EXTENSION	2	
18	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
19	36664-88L00	.CONNECTOR, BRANCH	2	
20	36665-88L00	.UNIT, RESISTOR FEMALE	1	
21	36665-88L10	.UNIT, RESISTOR MALE	1	
22	36667-96L00	.WIRE, GAUGE ADAPTER	1	
23	36667-96L11	WIRE, DUAL GAUGE ADAPTER	1	
24	36667-96L30	WIRE, GAUGE ADAPTER	1	

DF300A_E03_019_601A
OPT:MULTI FUNCTION GAUGE (1)

FIG.602A




FIG.602A (1-H-15) OPT:MULTI FUNCTION GAUGE (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34002-96L13	KIT, DUAL STATION	1	
2	34011-96L13	.GAUGE SET, MULTI	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36662-88L10	.WIRE, 2 EXTENSION	1	
8	36664-88L00	.CONNECTOR, BRANCH	1	
9	36665-96L00	.ADAPTER, DUAL STATION	1	
10	36666-96L00	.ADAPTER, GAUGE POWER	1	
11	36682-92E00	.WIRE, GAUGE EXT	1	
12	34011-96L13	SET, MULTI GAUGE	1	
13	34112-96L00	.NUT, GAUGE	1	
14	34193-96L00	.BEZEL, GAUGE	1	
15	34211-96L00	.COVER, GAUGE	1	
16	34825-96L00	.PACKING, GAUGE	1	
17	36001-88L00	SET, WIRE	1	
18	36662-88L10	.WIRE, 2 EXTENSION	1	
19	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
20	36664-88L00	.CONNECTOR, BRANCH	1	
21	36665-88L00	.UNIT, RESISTOR FEMALE	1	
22	36665-88L10	.UNIT, RESISTOR MALE	1	
23	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
24	36662-88L20	WIRE, 6 EXTENSION	1	
25	36662-88L30	WIRE, 15 EXTENSION	1	
26	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
27	36662-88L00	WIRE, 25 EXTENSION	1	
28	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
29	36665-88L00	UNIT, RESISTOR FEMALE	1	
30	36665-88L10	UNIT, RESISTOR MALE	1	
31	36662-88L10	WIRE, 2 EXTENSION	1	
32	36664-88L00	CONNECTOR, BRANCH	1	

DF300A_E03_019_602A
OPT:MULTI FUNCTION GAUGE (2)

10000

PART NO.	FIG.NO.-REF.NO.
11101-98J03	111A-1
11103-98J03	111A-5
11112-93J00	113A-4
11115-93J10-001	111A-36
11116-93J01	111A-9
11117-93J10	113A-5
11117-98J10	113A-6
11119-93J00	113A-7
11128-90J00	111A-2
	111A-6
11141-98J10	111A-10
	585A-2
11142-98J10	111A-11
	585A-3
11170-93J01	111A-21
11173-93J00	111A-23
11174-98J00	136A-2
11176-98J00	136A-3
11179-93J00	111A-25
	585A-4
11180-98J01	111A-22
11183-93J00	111A-24
11189-93J00	111A-26
	585A-5
11193-98J00	163A-1
11196-93J00	162A-1
11197-93J00	162A-2
11198-58B00	163A-2
11216-98L00	113A-8
11216-98L10	111A-12
11218-98J02	315A-20
	315B-19
11219-98J00	315A-21
	315B-20
11261-93J00	111A-13
	140A-5
11261-93J10-Y5S	180A-1-2
11261-93J10-YAY	180A-1-1
11270-93J00	162A-3
11272-93J00	162A-4
	585A-11
11291-93J00	111A-34
11291-98J00	111A-37
11293-98J00	113A-1
11301-98J30	113A-3
11330-93J01	113A-22
11332-93J00	113A-23
	585A-6
11382-93J00	111A-31
11390-98J00	113A-19
11410-98830	585A-1
11435-93J00	180A-14
11489-93J00	180A-6
	585A-12
11501-93J03-Y5S	180A-7-2
11501-93J03-YAY	180A-7-1
11510-98J02	136A-1
11514-98J00	136A-4
11515-93J00	136A-11
11517-98J00	136A-10
11541-93J00-019	180A-9
11591-93J10	180A-8
12100-98810-025	116A-6-2
12100-98810-0A0	116A-6-1
12100-98J00-050	116A-14
12111-98J00-0B0	116A-1
12140-98J00	116A-2
12140-98J00-050	116A-15
12151-02F00	116A-3
12160-98J00	116A-5
12220-98J00	116A-7
12242-98J00	116A-10
12300-98810-0AA	116A-8-6
12300-98810-0BA	116A-8-7
12300-98810-0CA	116A-8-8
12300-98810-0DA	116A-8-9
12300-98810-0EA	116A-8-10
12300-98821	116A-9-1
12300-98821-012	116A-9-2
12340-98J00-0A0	116A-8-1
12340-98J00-0B0	116A-8-2
12340-98J00-0C0	116A-8-3
12340-98J00-0D0	116A-8-4
12340-98J00-0E0	116A-8-5
12632-93J11	175A-1
12701-98J10	121A-1
12701-98J20	121B-1
12705-98J10	121A-2
	121B-2
12721-98J10	121A-3
	121B-3
12729-98J20	121A-4
	121B-4
12730-98J02	119A-1
12734-93J00	119A-5
12740-93J00	121A-5
	121B-5
12748-93J00	121A-6
	121B-6
12749-93J00	121A-8
	121B-8
12753-93J00	121A-7
	121B-7
12761-93J00	119A-8
12762-93J00	119A-9
12770-93J00	119A-10
12771-93J00	119A-14
12772-93J00	119A-16
12775-93J00	119A-15
12778-93J00	119A-11
12810-93J00	119A-18
12812-90J00	119A-20
12813-73G00	119A-19
12831-93J01	119A-22
12832-93J00	119A-23
12833-93J00	119A-24
12891-93J00	121A-14
	121B-14
12892-93J00-218	121A-15-1
	121B-15-1
12892-93J00-220	121A-15-2
	121B-15-2
12892-93J00-223	121A-15-3
	121B-15-3
12892-93J00-225	121A-15-4
	121B-15-4
12892-93J00-228	121A-15-5
	121B-15-5
12892-93J00-230	121A-15-6
	121B-15-6
12892-93J00-233	121A-15-7
	121B-15-7
12892-93J00-235	121A-15-8
	121B-15-8
12892-93J00-238	121A-15-9
	121B-15-9
12892-93J00-240	121A-15-10
	121B-15-10
12892-93J00-243	121A-15-11
	121B-15-11
12892-93J00-245	121A-15-12
	121B-15-12
12892-93J00-248	121A-15-13
	121B-15-13
12892-93J00-250	121A-15-14
	121B-15-14
12892-93J00-253	121A-15-15
	121B-15-15
12892-93J00-255	121A-15-16
	121B-15-16
12892-93J00-258	121A-15-17
	121B-15-17
12892-93J00-260	121A-15-18
	121B-15-18
12892-93J00-263	121A-15-19
	121B-15-19
12892-93J00-265	121A-15-20
	121B-15-20
12892-93J00-268	121A-15-21
	121B-15-21
12892-93J00-270	121A-15-22
	121B-15-22
12892-93J00-273	121A-15-23
	121B-15-23
12892-93J00-275	121A-15-24
	121B-15-24
12892-93J00-278	121A-15-25
	121B-15-25
12892-93J00-280	121A-15-26
	121B-15-26
12892-93J00-283	121A-15-27
	121B-15-27
12892-93J00-285	121A-15-28
	121B-15-28
12892-93J00-288	121A-15-29
	121B-15-29
12892-93J00-290	121A-15-30
	121B-15-30
12892-93J00-293	121A-15-31
	121B-15-31
12892-93J00-295	121A-15-32
	121B-15-32
12892-93J00-298	121A-15-33
	121B-15-33
12892-93J00-300	121A-15-34
	121B-15-34
12911-98J00	121A-16
	121B-16
12915-93J60	121A-17
	121B-17
12921-93J11	121A-18
	121B-18
12931-78G00	121A-19
	121B-19
12932-24400	121A-20
12933-69G10	121A-21
	121B-21
13100-98J10	163A-3
13110-98J10	122A-1
13119-98J00	122A-2
	585A-7
13134-98J00	163A-14
13137-98J00	163A-4
13139-98J01	163A-15
13140-98J10	163A-5
13147-98J00	163A-6
13180-98J00	163A-7
13310-98J00	163A-16
13315-98J00	163A-18
13343-98J10	163A-17
13370-93J00	147A-20
13421-98J00	163A-19
13575-40F00	326A-2
	326B-2
13580-98J02	326A-1
	326B-1
13602-05108	147A-29
13650-52G00	315A-1
	315B-1
13655-87J00	315A-2
	315B-2
13671-02F00	147A-68
13710-98J00	136A-5
13811-98J00	136A-6
13813-98J00	163A-20
13841-98J10	136A-12
13851-98J10	136A-13
14140-98J01	140A-2
14141-93J01	140A-1
14151-93J00	140A-3
	585A-8
14152-93J00	140A-4
	585A-9
14154-93J01	180A-10
14211-98J00	180A-11
14212-93J00	180A-12
	585A-13
15100-98J00	147A-1
15114-93J00	147A-69
15115-93J00	147A-70
15118-93J00	147A-77
15200-98J00	147A-23
15410-93J10	147A-2
15411-93J10	147A-3
15412-93J10	147A-5
15413-93J10	147A-6
15415-93J10	147A-4
15440-93J00	147A-10
15600-98J20	147A-19
15626-93J00	147A-21
15627-93J00	147A-32
15628-99E00	147A-31
15629-99E10	147A-52
15632-93J30	147A-42
15633-93J20	147A-8
15634-93J20	147A-47
15635-93J30	147A-41
15636-93J30	147A-37
15637-93J30	147A-51
15641-90J00	147A-25
15642-90J00	147A-26
15643-93J00	147A-45
15644-93J00	147A-7
15645-93J00	147A-50
15647-93J00	147A-24
15650-93J00	147A-22
15654-99E00	147A-27
15671-93J00	147A-60
15672-93J10	147A-39
15673-98J00	147A-43
15674-93J00	147A-49
15675-93J00	147A-34
15680-93J32	144A-19
15681-93J01	144A-1
15683-87J00	147A-53
15684-98J00	144A-22
15685-93J00	147A-38
15695-98L00	147A-71
15710-96J00	144A-2
15717-16G00	144A-3
15735-58B00	144A-4
15751-93J00	144A-5
15756-93J01	144A-6
15760-93J00	147A-30
15762-93J00	144A-7
15770-93J00	147A-15
15773-90J00	147A-12
15830-77EA0	144A-8
15830-93J00	147A-13
15831-93J00	144A-9
15980-98J00	520A-41
	540A-24
	543A-23
16113-93J10	175A-2

PART NO.	FIG.NO.-REF.NO.
16400-93J10	175A-3
16430-93J00	113A-25
16431-93J00	113A-26
16433-93J00	113A-27
16510-96J10	113A-30
16519-93J00	401A-2
	401B-2
16520-93J00	175A-4
16550-93J00	121A-11
	121B-11
16555-93J01	121A-12
	121B-12
16700-93J00	113A-14
16760-93J00	175A-5
16781-93J00	175A-6
16782-93J00	175A-7
16783-93J01	175A-8
16910-93J00	180A-26
16930-93J00	180A-27
17400-98J01	160A-22
	160B-22
17410-93J01	160A-1
	160B-1
17413-93J02	160A-2
	160B-2
17416-93J00	160A-3
	160A-23
	160B-3
	160B-23
17461-93J00	160A-4
	160A-24
	160B-4
	160B-24
17471-98J01	160A-5
	160A-25
	160B-5
	160B-25
17472-98J00	160A-6
	160A-26
	160B-6
	160B-26
	585A-10
17473-98J00	160A-7
	160A-27
	160B-7
	160B-27
17561-93J03	160A-8-2
	160B-8-1
17561-93J13	160A-8-3
	160B-8-2
17561-93J21	160A-8-1
17562-93J01	160A-9
	160B-9
17563-93J00	160A-10
	160B-10
17564-93J00	160A-11
	160B-11
17581-93J00	162A-5
17582-93J00	162A-6
17611-90J00-Y5S	162A-7-2
17611-90J00-YAY	162A-7-1
17612-93J00	160A-12
	160B-12
17631-93L10	160A-13
	160B-13
17632-93L10	160A-14
	160B-14
17633-93L00	160A-21
	160B-21
17637-93L00	206A-16
	206B-16
17638-93L00	206A-17
	206B-17
17660-99E01	162A-8
17670-90J10	162A-9-2
17670-90J20	162A-9-1
17681-93J00	162A-10
17711-90J00	162A-11
17712-93J00	162A-12
17713-98J00	162A-36
17913-93J00	401A-3
	401B-3
	410A-23
	410B-23
17914-93J00	401A-4
	401B-4
	410A-24
	410B-24
17915-98J01	162A-38
17917-87L00	523A-6
18118-93J00	163A-22
18213-98J30	315A-18
	315B-17
18417-93J00	147A-64
18498-87J51	147A-57
18498-93J01	144A-10
18498-93J20	147A-76
18590-68H00	163A-8
19115-98J10	204A-29
	204B-29

20000

PART NO.	FIG.NO.-REF.NO.
21110-98J02	204A-1
	204B-1
21131-93J00	204A-2
	204B-2
21151-93J00	204A-3
	204B-3
21210-98J01	204A-5
	204B-5
21230-98J01	204A-6
	204B-6
21241-98J10	204A-24
	204B-24
22511-99011	336A-1
	336B-1
	401A-11
	401B-11
23111-93J00	204A-7-2
	204B-7
23111-93J10	204A-7-1
23115-98J00	204A-8
	204B-8
25112-93L00	206A-1-1
	206B-1-1
25112-93L10	206A-1-2
	206B-1-2
25113-93L00	206A-11
	206B-11
25130-93L00	206A-2
	206B-2
25141-93L00-Y5S	206A-5-2
	206B-5-2
25141-93L00-YAY	206A-5-1
	206B-5-1
25215-93L00	206A-12
	206B-12
25222-90J00	206A-6
	206B-6
25223-94400	204A-9
	204B-9
25231-93L00	206A-23
	206B-23
25232-90J00	206A-3
	206B-3
25232-94300	206A-24
	206B-24

PART NO.	FIG.NO.-REF.NO.
25321-93L00	206A-8
	206B-8
25700-93L01	407A-37
	407B-37
29103-93J00	180A-24
	315A-3
	315B-3
29103-93J20	410A-35
	410B-35
29103-93J30	180A-3
	410A-36
	410B-36
29116-93J00	160A-15
	160B-15
	180A-13
	206A-9
	206B-9
29125-93J00	326A-18
	326B-18
29159-93J00	401A-28
	401B-28
	405A-13
	405B-17
	405C-12
29404-93J10	180A-25
	315A-10
	337B-2
29404-93J20	315B-10
31100-98L10	301A-1
31111-94900	340A-2
	340B-2
31123-94910	340A-4
	340B-4
31133-90J10	340A-5
	340B-5
31133-94910	340A-6
	340B-6
31135-94900	340A-7
	340B-7
31136-90J20	340A-8
	340B-8
31150-98L00	301A-2
31170-92J00	301A-3
31173-94920	340A-3
	340B-3
31173-98L00	301A-4
31191-63J00	301A-5
31192-92J00	301A-8
31220-98L10	301A-6
31261-75F10	301A-9
31281-92J10	337A-2
	337B-3
31311-63J00	301A-7
31311-93J00	340A-10
31311-94900	340B-10
31313-86030	301A-11
31320-98L00	301A-12
31340-98L00	301A-10
31341-98L00	301A-13
31343-63J00	301A-14
31344-63J00	301A-15
31912-98J00	301A-16
31918-92J01	301A-17
32102-98J01	303A-1
32120-93J00	303A-4
32131-93J00	303A-5
32160-88L00	303A-7
32800-98J01	310A-1
32805-93J00	310A-2
32851-93J00	331A-1
	535A-19
32890-98J01	310A-3
32980-38F00	331A-2
	535A-12
33220-98J00	303A-9
33221-42F00	303A-10
33410-93J00	310A-11
33799-97E00	340A-9
	340B-9
33810-98J01	322A-1
33830-98J11	522A-2
33911-88BL0	522A-5
33925-93J00	522A-6
33925-98J00	326A-24
	326B-24
33926-98J00	522A-7
33930-98J90	326A-23-2
33930-98JA0	326B-23
33930-98JB0	326A-23-1
34000-96L63	601A-1
34000-96L73	601A-9
34002-96L13	602A-1
34011-96L13	601A-2

30000

PART NO.	FIG.NO.-REF.NO.
	601A-10
	602A-2
	602A-12
34112-96L00	601A-3
	601A-11
	602A-3
	602A-13
34190-88L00	602A-23
34193-96L00	601A-4
	601A-12
	602A-4
	602A-14
34211-96L00	601A-5
	601A-13
	602A-5
	602A-15
34813-93J00	315B-22
34825-96L00	601A-6
	601A-14
	602A-6
	602A-16
34830-87J20	315A-4
	315A-5
	315B-4
	315B-5
34830-98J00	315A-22
	315B-21
34840-98J03	315A-6
34840-98J11	315B-6
34841-88L00	315A-12
34841-96J00	315B-12
34845-88L01	315A-13
34845-96J00	315B-13
36001-88L00	602A-17
36610-98J80	322A-3
36611-96J00	315B-23
36612-96J00	322A-16
36612-98J01	522A-24-1
36612-98J10	322A-5
36612-98J20	522A-24-2
36615-96300	331A-4
	522A-9
	522A-16
	522A-19
	522A-21
	523A-4
	535A-14
	601A-8
	601A-16
36617-93J00	322A-19

PART NO.	FIG.NO.-REF.NO.
36617-93J10	162A-41
	322A-20
36617-98J00	322A-21
36620-98J31	540A-58-1
	543A-54-1
36620-98J41	540A-58-2
	543A-54-2
36620-98J51	522A-1
36621-98J00	522A-17
36621-98J10	522A-22
36622-98J00	522A-13
36623-96L01	331A-3
	535A-13
36623-98J20	522A-8
36623-98J30	522A-18
36623-98J40	523A-3
36624-98J02	522A-15
36624-98J11	522A-20
36625-98J10	523A-1
36627-98J00	523A-5
36645-93J00	301A-20
36661-96L20	601A-7
	601A-15
36662-88L00	602A-27
36662-88L10	601A-17
	602A-7
	602A-18
	602A-31
36662-88L20	602A-24
36662-88L30	602A-25
36662-96L00	331A-5
	535A-15
36663-88L00	601A-18
	602A-19
	602A-28
36663-96L00	535A-25
36664-88L00	601A-19
	602A-8
	602A-20
	602A-32
36664-96L00	535A-26
36665-88L00	601A-20
	602A-21
	602A-29
36665-88L10	601A-21
	602A-22
	602A-30
36665-96L00	602A-9
36666-96L00	602A-10
36667-96L00	601A-22
36667-96L11	601A-23
36667-96L20	522A-26
36667-96L30	601A-24
36682-92E00	602A-11
36721-98L10	322A-6
36737-98L00	322A-7
36738-98L00	322A-8
36770-98J13	522A-10-1
36770-98J22	522A-10-2
36775-98J00	522A-11
36776-98J00	522A-12
36890-98J00	520A-55
	540A-57
	543A-53
36894-87D00	335A-23
	336A-2
	336B-2
	337A-39
	337B-36
	405A-7
	405B-11
	405C-19
36895-87D01	337A-40
	337A-41
36895-87D10	336B-13
	337B-39
36990-87D00	522A-25
37100-96L01	535A-1
37100-98J05	530A-1
37100-98J11	530A-11
37100-98J21	530A-21
37100-98J31	530A-23
37105-96L02	535A-11
37110-96L00	535A-2
37110-98J01	530A-2
37112-98J00	530A-12
37112-98J10	530A-22
	530A-24
37114-98J00	530A-10
	535A-5
37117-96L00	331A-6
	535A-22
37139-96L30	535A-6
37139-98J10	530A-5
37141-99E00	530A-3-3
	535A-3-1
37141-99E10	530A-3-4
	535A-3-2
37141-99E20	530A-3-5
	535A-3-3
37141-99E30	530A-3-6
	535A-3-4
37141-99E40	530A-3-7
	535A-3-5
37141-99E50	530A-3-8
	535A-3-6
37141-99E60	530A-3-9
37141-99E70	530A-3-10
37141-99E80	530A-3-11
37141-99E90	530A-3-12
37141-99EA0	530A-3-1
37141-99EB0	530A-3-2
37143-96L00	535A-4
37143-99E00	530A-4
37170-96L04	535A-21-2
37170-96L14	535A-21-1
37171-96L02	331A-7-1
	535A-23-2
37171-96L12	331A-7-2
	535A-23-1
37172-96L01	331A-8-1
	535A-24-2
37172-96L10	331A-8-2
	535A-24-1
37173-96L00	535A-27
37173-96L10	331A-9
	535A-16
37721-93J00	326A-7
	326B-7
37722-93J12	326A-16
	326B-16
37725-93J11	326A-10
	326B-10
37729-96L00	326A-3
	326B-3
37803-93J05	530A-15
37820-93J10	530A-6
	530A-17
	535A-7
37820-98J00	315A-7
	315B-7
37823-92E01	530A-7
	530A-18
	535A-8
37825-99E10	530A-16
37826-92J10	530A-8
	530A-19
	535A-9
37850-92J00	326A-11
	326B-11

PART NO.	FIG.NO.-REF.NO.
37850-98J02	520A-52
	540A-26
	543A-25
37856-92J00	326A-12
	326B-12
37857-92J00	326A-13
	326B-13
37860-87L00	530A-25
37862-87L00	530A-26
38100-93J04	337A-3
	340A-1
38100-93L01	337B-4
	340B-1
38410-93J12	326A-19
	326B-19
38415-93J00	326A-20
	326B-20
38500-93J90	331A-10
	530A-13
	535A-17
38860-76F01	322A-10
	322A-11
	326A-30
	326B-30
38860-96L01	331A-11
	535A-18
38890-98J11	326A-25
	326B-25
38892-98J00	326A-26
	326B-26
38895-98J00	326A-27
	326B-27
38915-90J00	326A-31
	326B-31
39950-88L02	602A-26
40000	
41111-93J16-Y5S	335A-1-2
41111-93J16-YAY	335A-1-1
41111-96J40-Y5S	335B-1-2
41111-96J40-YAY	335B-1-1
41117-93J02	335A-3
41117-93L00	335B-18
41121-93J08-Y5S	335A-2-2
41121-93J08-YAY	335A-2-1
41121-96J30-Y5S	335B-2-2
41121-96J30-YAY	335B-2-1
41122-93J02	335A-4
41122-93L00	335B-19
41130-92J03	335B-3
41130-93J12	335A-6
41135-92J00	335B-4
41135-93J11	335A-7
41155-93J02	335A-13
	335B-10
41220-93J11	336A-13
41220-96J10	336B-15
41224-95E01	336A-15
	336B-17
41230-96J00	336A-16
	336B-18
41233-95E10	336A-17
	336B-19
41234-93J11	336A-14
41234-96J10	336B-16
43111-93J24-Y5S	336A-3-2
43111-93J24-YAY	336A-3-1
43111-96J20-Y5S	336B-3-2
43111-96J20-YAY	336B-3-1
43114-93J00	336A-4
43117-96J00	315B-24
43118-96J00	315B-26
43211-93J00	336A-5
	336B-4
43711-97E01	336A-6
	336B-5
43750-93J03-Y5S	336A-7-2
43750-93J03-YAY	336A-7-1
43750-96J51-Y5S	336B-6-2
43750-96J51-YAY	336B-6-1
45421-87D03	335A-16
48000-93L01	337B-1
48000-98J08	337A-1
48121-93J20	337A-22
48121-93L00	337B-26
48125-93J10	337A-23
48126-93J00	337A-27
48128-93J11	337A-30
48140-93J01	335A-18
	335B-13
48144-93J00	335A-19
	335B-14
48145-93J00	335A-22
	335B-16
48311-96J10	337A-32
48311-96J20	337B-28
48320-93J00	337A-28
48321-87D03	337B-29
48321-93J00	337A-33
48326-95E00	337B-30
48400-98J03	337A-12
48401-93L00	337B-9
48405-93J00	337A-13
	337B-16
48427-87D00	337A-16
48451-93J00	337A-24
48452-93J00	337A-25
48452-93J10	337A-26
48500-98J10	337A-4
48502-96J05	337B-5
48503-93L00	337B-8
48570-95E01	337B-18
48571-93J00	337A-31
48572-87J10	337A-17
48572-95E00	337B-19
48573-93J00	337A-29
48582-95E01	337A-5
	337B-6
48583-95E00	337A-21
	337B-20
48585-95E00	337A-18
	337B-21
48588-94900	337B-22
48601-93L00	337B-10
48605-93J00	337A-6
48610-93J01	337A-8
48615-87D00	337A-7
48615-97E00	337B-17
48627-93J00	337A-15
48627-95E00	337B-11
48630-96J03	337B-12
48630-98L00	337A-9
48633-93J00	337A-10
48633-94900	337B-13
48641-93L00	337B-14
48650-93J00	337A-14
48650-94900	337B-15
48691-93J00	337A-11
48861-92J01	337B-23
48862-87J20	337A-19
48862-92J20	337B-24
48862-92J30	337B-25
48864-93J01	337A-20
48864-96J10	337B-7

PART NO.	FIG.NO.-REF.NO.
50000	
51111-93J21-Y5S	401A-1-2
	401B-1-2
51111-93J21-YAY	401A-1-1
	401B-1-1
51116-93J00	401A-5
	401B-5
51120-93J02	401A-10
	401B-10
51123-93J00	401A-14
	401B-14
	585A-14
51124-93J01	401A-12
	401B-12
51125-93J00	401A-13
	401B-13
51140-93J11-Y5S	401A-18-3
51140-93J11-YAY	401A-18-1
51140-98J00-Y5S	401A-18-4
	401B-18-2
51140-98J00-YAY	401A-18-2
	401B-18-1
51142-93J00	401A-19
	401B-19
	585A-15
51151-93J00	401A-21
	401B-21
51152-93J00	401A-22
	401B-22
51211-93J00	401A-6
	401B-6
	585A-16
52111-98J00-Y5S	405A-1-2
	405B-1-2
52111-98J00-YAY	405A-1-1
	405B-1-1
52111-98J20-Y5S	405C-1-2
52111-98J20-YAY	405C-1-1
52131-93J00-Y5S	405B-7-2
52131-93J00-YAY	405B-7-1
54112-93J00	401A-27
	401B-27
	405A-11
	405B-15
	405C-10
54121-93J20	401A-33-2
54121-98J01	401A-33-1
	401B-33
54123-93J03	401A-25
	401B-25
54130-93J01	401A-26
	401B-26
54137-93J02	401A-30
	401B-30
54140-98J00	401A-34
	401B-34
54144-93J00	401A-41
	401B-41
54150-98J00	405A-9
	405B-13
	405C-8
54160-98J00	405A-10
	405B-14
	405C-9
54165-98J01	405A-18
	405B-22
	405C-17
54211-93J00-Y5S	405A-15-2
	405B-19-2
	405C-14-2
54211-93J00-YAY	405A-15-1
	405B-19-1
	405C-14-1
54221-93J00-Y5S	405A-16-2
	405B-20-2
	405C-15-2
54221-93J00-YAY	405A-16-1
	405B-20-1
	405C-15-1
55110-93L10-Y5S	407A-1-2
	407B-1-2
55110-93L10-YAY	407A-1-1
	407B-1-1
55122-93L00	206A-14
	206B-14
55125-93L00-Y5S	407A-12-2
	407B-12-2
55125-93L00-YAY	407A-12-1
	407B-12-1
55127-87D00	407A-20
	407B-20
55128-93J10	407A-14
	407B-14
55128-93L00	407A-34
	407B-34
55320-94900	335A-14
	335B-11
55321-87J01	111A-15
	140A-6
	180A-2-1
	206A-18
	206B-18
55321-87J11	180A-2-2
55321-93J01	405A-20
	405B-24
	407A-16
	407B-16
55321-94910	335A-21
	335B-17
55332-98J00	407A-18
	407B-18
55333-98J00	407A-19
	407B-19
56120-93L20	220A-25
	220B-25
56122-93L00	220A-40
	220B-40
56126-93L10	220A-41
	220B-41
56127-93L00	220A-42
	220B-42
56128-93L00	220A-43
	220B-43
56129-93L00	220A-44
	220B-44
56130-93J02	220A-32
	220B-32
56141-93L00	206A-15
	206B-15
56147-93L00	220A-31
	220B-31
57110-93L02	220A-1-1
57110-93L12	220A-1-2
	220B-1-1
57110-93L22	220A-1-3
	220B-1-2
57130-87D10	405A-4
	405B-4
57133-93L00	220A-2
	220B-2
57134-93J00	220A-3
	220B-3
57300-93L20	220A-6
	220B-6
57527-93L00	220A-46
	220B-46

PART NO.	FIG.NO.-REF.NO.
57541-93L00	220A-47
	220B-47
57610-93L10	220A-17
	220B-17
57617-93L00	220A-22
	220B-22
57621-93L00	220A-18
	220B-18
57622-93L00	220A-36
	220B-36
57630-93L00	407A-36
	407B-36
57631-93L01	220A-20
	220B-20
57632-93L10	407A-29
	407B-29
57633-93L00	407A-30
	407B-30
58120-93L00	407A-26
	407A-28
	407B-26
	407B-28
58700-93J00	407A-25-10
	407B-25-10
58700-93J10	407A-25-11
	407B-25-11
58700-93J20	407A-25-12
	407B-25-12
58700-93J30	407A-25-13
	407B-25-13
58700-93J40	407A-25-14
	407B-25-14
58700-93L00	407A-25-1
	407B-25-1
58700-93L10	407A-25-2
	407B-25-2
58700-93L20	407A-25-3
	407B-25-3
58700-93L30	407A-25-4
	407B-25-4
58700-93L40	407A-25-5
	407B-25-5
58700-93L50	407A-25-6
	407B-25-6
58700-93L60	407A-25-7
	407B-25-7
58700-93L70	407A-25-8
	407B-25-8
58700-93L80	407A-25-9
	407B-25-9
58700-96J00	407A-27-1
	407B-27-1
58700-96J10	407A-27-2
	407B-27-2
58700-96J20	407A-27-3
	407B-27-3
58700-96J30	407A-27-4
	407B-27-4
58700-96J40	407A-27-5
	407B-27-5
58700-96J50	407A-27-6
	407B-27-6
58800-93J10	407A-25-22
	407B-25-22
58800-93J20	407A-25-23
	407B-25-23
58800-93J30	407A-25-24
	407B-25-24
58800-93J40	407A-25-25
	407B-25-25
58800-93L00	407A-25-15
	407B-25-15
58800-93L10	407A-25-16
	407B-25-16
58800-93L20	407A-25-17
	407B-25-17
58800-93L30	407A-25-18
	407B-25-18
58800-93L40	407A-25-19
	407B-25-19
58800-93L50	407A-25-20
	407B-25-20
58800-93L60	407A-25-21
	407B-25-21
58800-96J00	407A-27-7
	407B-27-7
58800-96J10	407A-27-8
	407B-27-8
58800-96J20	407A-27-9
	407B-27-9
58800-96J30	407A-27-10
	407B-27-10
58800-96J40	407A-27-11
	407B-27-11
58800-96J50	407A-27-12
	407B-27-12
59171-93L00	220A-15-1
	220B-15-1
59171-93L10	220A-15-2
	220B-15-2
59171-93L20	220A-15-3
	220B-15-3
59171-93L30	220A-15-4
	220B-15-4
59171-93L40	220A-15-5
	220B-15-5
59171-93L50	220A-15-6
	220B-15-6
59171-93L60	220A-15-7
	220B-15-7
59171-93L70	220A-15-8
	220B-15-8
59171-93L80	220A-15-9
	220B-15-9
59171-93L90	220A-15-10
	220B-15-10
59171-93LA0	220A-15-11
	220B-15-11
59171-93LB0	220A-15-12
	220B-15-12
59171-93LC0	220A-15-13
	220B-15-13
60000	
61112-98J00	410A-25
	410B-25
61124-98J20	410A-43
	410B-43
61131-93J01-Y5S	410A-1-2
61131-93J01-YAY	410A-1-1
61131-93J20-Y5S	410B-1-2
61131-93J20-YAY	410B-1-1
61134-93J20	410A-8
	410B-8
61137-93J00	410A-3
	410B-3
61141-93J01-Y5S	410A-2-2
61141-93J01-YAY	410A-2-1
61141-93J20-Y5S	410B-2-2
61141-93J20-YAY	410B-2-1
61155-93J20	401A-7
	401B-7
61420-98800-YAY	420A-1-1
	420B-1-1

PART NO.	FIG.NO.-REF.NO.
61420-98810-Y5S	420A-1-2
	420B-1-2
61422-93JE0	420B-32-2
61422-98J30	420A-32-2
61422-98J40	420B-32-1
61422-98J50	420A-32-1
61425-98J00	420A-28
	420B-28
61431-98J10-Y5S	420A-2-2
	420B-2-2
61431-98J10-YAY	420A-2-1
	420B-2-1
61432-98J01	420A-3
	420B-3
61433-98J01	420A-4
	420B-4
61434-98J02	420A-5
	420B-5
61435-93JD0	420B-33-2
61435-98J30	420A-33-2
61435-98J50	420A-33-1
61435-98J60	420B-33-1
61439-98J00	420A-6
	420B-6
61439-98J10	420A-7
	420B-7
61439-98J21	420A-8
	420B-8
61441-98L00	420A-31
	420B-31
61443-96J70	420A-29-1
	420B-29-1
61443-96J80	420A-29-2
	420B-29-2
61453-96J70	420A-30-1
	420B-30-1
61453-96J80	420A-30-2
	420B-30-2
61458-90J00	410A-45
	410B-45
61476-98J00	420A-9
	420B-9
61494-93J00	136A-19
61610-98J00	420A-16
	420B-16
61610-98J30	420A-17
	420B-17
61610-98J40	420A-18
	420B-18
61614-98J00	420A-20
	420B-20
61619-98J00	420A-24
	420B-24
61621-98J02	420A-21
	420B-21
61624-98J11	420A-22
	420B-22
61625-98J11	420A-23
	420B-23
61630-98J00	410A-26
	410B-26
61633-98J10-Y5S	410A-32-2
	410B-32-2
61633-98J10-YAY	410A-32-1
	410B-32-1
61634-98J10-Y5S	410A-33-2
	410B-33-2
61634-98J10-YAY	410A-33-1
	410B-33-1
61635-98J00	410A-39
	410B-39
61636-98J00	410A-31
	410B-31
61643-98J00	410A-40
	410B-40
61645-98J00-Y5S	410A-34-2
	410B-34-2
61645-98J00-YAY	410A-34-1
	410B-34-1
61658-98J00	410A-41
	410B-41
61811-98J20-Y5S	410A-6-2
	410B-6-2
61811-98J20-YAY	410A-6-1
	410B-6-1
61812-98J00	410A-16
	410B-16
61814-98J00	410A-17
	410B-17
61817-93J00	410A-10
	410B-10
61821-98J10-Y5S	410A-7-2
	410B-7-2
61821-98J10-YAY	410A-7-1
	410B-7-1
61827-93J02	410A-12
	410B-12
61831-98J02-Y5S	410A-18-2
	410B-18-2
61831-98J02-YAY	410A-18-1
	410B-18-1
61832-98J00	410A-15
	410B-15
63632-98J20	410A-27
	410B-27
63632-98J30	410A-28
	410B-28
65770-93J04	475A-1
67200-98J04	543A-1
67200-98J14	540A-1
67200-98J23	520A-1
67211-98J20	520A-18
	540A-2
67211-98J30	540A-48
67212-98J20	543A-7
67212-98J30	540A-8
67222-98J00	520A-32
67222-98J10	540A-10
67222-98J20	540A-49
67223-98J00	520A-36
	540A-17
	543A-16
67226-98J00	540A-37
	543A-36
67226-98J10	520A-26
67227-98J00	540A-41
67227-98J10	520A-42
	540A-25
	543A-24
67227-98J20	520A-21
67227-98J30	520A-22
67228-98J50	520A-47
	540A-47
	543A-47
67233-98J00	520A-15
67233-98J10	540A-14
	543A-13
67234-98J00	520A-17
67235-98J00	520A-34
67235-98J10	540A-12
	543A-11
67236-98J00	520A-33
67236-98J10	540A-11
	543A-10
67237-98J00	520A-35
67237-98J30	543A-12
67237-98J40	540A-13
67237-98J50	540A-56
67238-98J00	520A-29
67239-98J00	540A-16
	543A-15
67246-98J00	520A-31
67246-98J10	540A-4
	543A-4
67246-98J20	540A-50
67251-98J00	540A-3
	543A-3
67251-98J20	520A-12
67252-98J00	520A-38
67252-98J10	540A-21
	543A-20
67254-98J00	520A-14
67255-98J00	520A-8
67256-98J00	520A-10
67257-98J00	520A-54
	540A-43
	543A-43
67258-98J00	520A-9
67259-98J00	520A-11
67261-98J00	540A-5
	543A-5
67261-98J10	540A-6
67261-98J20	520A-5
67261-98J30	520A-6
67263-98J00	540A-7
	543A-6
67263-98J20	520A-4
67264-98J00	520A-3
67265-98J00	520A-7
67269-98J00	540A-27
	543A-26
67269-98J10	520A-53
67269-98J20	520A-19
67269-98J30	540A-44
	543A-44
67271-98J20	520A-2
67271-98J30	543A-8
67271-98J40	540A-9
67272-98J00	520A-51
67272-98J10	540A-20
	543A-19
67273-98J00	543A-27
67273-98J10	540A-51
	543A-48
67273-98J20	540A-28
67273-98J30	540A-52
	543A-49
67274-98J00	543A-29
67277-98J00	540A-53
	543A-50
67284-98J10	540A-42
	543A-42
67287-92E00	540A-15
	540A-39
	543A-14
	543A-38
67287-98J00	520A-25
67288-92E20	540A-36
	543A-30
67288-98J00	520A-44
	540A-35
	543A-34
67288-98J10	520A-46
	540A-45
	543A-45
67288-98J20	520A-39
	540A-22
	543A-21
67288-98J30	540A-46
	543A-46
67288-98J40	540A-34
	543A-40
67288-98J50	520A-23
67288-98J60	520A-27
67288-98J70	520A-30
67292-98J00	520A-40
	540A-23
	543A-22
67294-98J00	520A-13
67296-94300	520A-43
	540A-33
	543A-33
67296-98J00	540A-32
	543A-39
67296-98J10	520A-45
	543A-41
67296-98J20	543A-35
67296-98J30	540A-30
67296-98J50	520A-50
	540A-18
	543A-17
67296-98J60	520A-48
	540A-29
	543A-28
67296-98J90	540A-40
	543A-31
67296-98JA0	520A-16
	540A-19
	543A-18
67296-98JB0	520A-20
67296-98JC0	520A-24
67296-98JD0	520A-28
67296-98JE0	520A-37
67296-98JF0	540A-54
	543A-51
67296-98JG0	540A-31
	543A-32
67297-98J00	540A-55
	543A-52
67361-90J10	410A-46
	410B-46
67467-89J01	204A-25
	204B-25
67467-89J10	204A-31
	204B-31
67471-99E00	204A-26
	204B-26
67471-99E10	204A-32
	204B-32
68110-98J01	420A-36
	420B-36
69711-93E10	136A-18
70000	
77811-54GC0-0PG	420A-19
	420B-19
90000	
99011-98J80-03B	420A-35-2
	420B-35-2
99011-98J80-054	420A-35-1
	420B-35-1
00000	

PART NO.	FIG.NO.-REF.NO.
01421-08357	163A-27
01500-06167	147A-40
01547-06167	420A-25
	420B-25
01547-06257	111A-29
01547-06507	111A-30
01550-06127	136A-8
	144A-23
	147A-65
	162A-42
	180A-29
	303A-14
	310A-9
	322A-29
	326A-15
	326A-21
	326B-15
	326B-21
	420A-26
	420A-27
	420B-26
	420B-27
01550-0612C	322A-22
01550-06167	303A-6
	303A-11
	326A-28
	326B-28
	420A-10
	420A-12
	420A-14
	420B-10
	420B-12
	420B-14
01550-0616A	175A-11
01550-06207	111A-4
	111A-8
	113A-24
	136A-9
	136A-14
	136A-15
	162A-33
	162A-34
	204A-21
	204B-21
	310A-12
	420A-11
	420B-11
01550-0620A	119A-25
	119A-26
01550-06257	121A-13
	121B-13
	140A-10
	147A-44
	162A-35
	310A-10
01550-06357	147A-61
	206A-19
	206B-19
	326A-29
	326B-29
01550-06407	136A-16
01550-08127	162A-25
01550-08167	163A-10
	163A-28
	410A-14
	410B-14
01550-08207	111A-17
	111A-35
	113A-2
	140A-9
	301A-18
01550-08307	301A-19
	401A-9
	401A-23
	401B-9
	401B-23
01550-0830A	119A-13
	119A-17
	119A-21
	401A-17
	401B-17
01550-08357	136A-17
	163A-11
	163A-29
01550-0835A	113A-28
01550-08407	144A-18
	147A-63
01550-08457	113A-29
01550-0845A	175A-12
01550-08557	204A-30
	204B-30
01550-0855A	119A-7
01550-08607	111A-18
	111A-19
	163A-30
	401A-24
	401B-24
01550-0865A	175A-13
01550-0885A	175A-14
01550-1025A	116A-12
01550-1050A	180A-19
02112-0406B	147A-54
02112-0612A	111A-28
02142-0408B	147A-28
02142-05107	204A-22
	204B-22
02162-05207	163A-12
03122-05165	530A-9
	530A-20
	535A-10
03542-0516C	335B-20
03542-06169	420A-13
	420A-15
	420B-13
	420B-15
04211-11129	163A-13
	163A-31
04211-13149	119A-12
06111-07004	220A-23
	220B-23
06111-11004	220A-24
	220B-24
07130-0510A	113A-18
07130-05167	326A-5
	326B-5
07130-0616A	113A-17
08110-60020	175A-15
08221-16256	220A-9
	220B-9
08310-00067	322A-17
08316-10087	163A-33
	322A-2
08321-0105A	326A-6
	326B-6
08321-01067	322A-18
08331-41359	204A-23
	204B-23
09100-12052	407A-5-1
	407A-5-2
	407B-5
09100-12085	335A-9-2
	335B-6-2
09100-12086	335A-9-1
	335B-6-1
09100-12092	335A-9-3
	335B-6-3
09103-06093	315A-17
	315B-16
09103-06231	303A-12
09103-06278	335A-20
	335B-15
09103-06281	111A-16
	140A-7
	180A-4
	206A-20
	206B-20
09103-06307	315B-8
09103-08109	401A-15
	401B-15
09103-08370	163A-23
09103-08437	122A-4
09103-12125	303A-2
09106-05030	303A-8
09108-08282	122A-3
09108-10115	405B-8
09108-10150	405C-5
09108-12013	405B-9
09116-05010	315B-25
09116-06121	162A-13
	335A-15
	335B-12
09116-06202	147A-59
	310A-7
09116-06236	405A-21
	405B-25
	407A-17
	407B-17
09116-06525	147A-48
09116-08122	401A-20
	401B-20
09116-08126	401A-39
	401B-39
09116-08128	180A-20
09116-08131	160A-16
	160B-16
09116-08137	407A-13
	407B-13
09116-08174	410A-19
	410B-19
09116-10134	401A-38
	401B-38
09116-10135	401A-31
	401B-31
09116-10137	401A-35
	401B-35
09116-10146	180A-22
	401A-37
	401B-37
09116-10150	407A-6-1
	407A-6-2
	407B-6
09116-10175	180A-21
	337A-38
	401A-32
	401A-36
	401B-32
	401B-36
	405A-17
	405B-21
	405C-16
09116-10176	405A-2
	405B-2
	405C-2
09116-10183	337B-31
09116-10184	180A-23
09125-05048	315A-15
	315B-14
09125-05050	337B-38
09125-06063	315A-8
	335A-5
	335A-24
	336A-8
	336A-18
	336B-7
	336B-14
	336B-20
	336B-26
	337A-42
	337A-43
	337A-44
	337B-37
	405A-6
	405A-8
	405B-6
	405B-12
	405C-7
	405C-20
09131-05004	530A-27
09132-04034	160A-17
	160B-17
	206A-22
	206B-22
09136-06148	410A-11
	410B-5
	410B-11
09136-06161	410B-4
09137-04004	326A-8
	326B-8
09139-06135	410A-4
09139-06136	410A-5
09140-05005	315A-14
09140-10031	337A-34
	337B-32
	405C-4
	407A-9
	407B-9
09140-10032	336A-19
	336B-21
09140-16026	220A-8
	220B-8
09140-48001	220A-39
	220B-39
09141-18005	407A-31
	407B-31
09159-08136	122A-5
	163A-32
09159-10116	113A-12
09159-12014	407A-10
	407B-10
09159-12062	335A-10
	335B-7
09159-14020	335A-17
09159-22006	335A-8
	335B-5
09159-28003	220A-4
	220B-4
09160-05024	540A-38
	543A-37
09160-05029	315A-16
	315B-15
	326A-4
	326B-4
09160-05053	335B-21
09160-06055	204A-27
	204B-27
09160-06082	336A-20
	336B-22
09160-06094	204A-10
	204B-10
09160-06104	520A-49
09160-06126	147A-14
09160-06134	310A-4
09160-08082	410A-38
	410B-38
09160-08152	410A-37
	410B-37
09160-08161	122A-6
	163A-34
09160-10082	206A-10
	206B-10

PART NO.	FIG.NO.-REF.NO.
09160-10104	116A-11
09160-10141	405C-6
	407A-7
	407B-7
09160-10148	204A-4
	204B-4
09160-10161	337B-27
09160-12066	407A-8
	407A-35
	407B-8
	407B-35
09160-13021	335A-12
	335B-8
09160-13022	335A-11
	335B-9
09160-14066	405A-19
	405B-23
	405C-18
09160-15051	401A-29
	401B-29
09160-16050	405A-12
	405A-14
	405B-16
	405B-18
	405C-11
	405C-13
09160-17052	410A-30
	410B-30
09160-18028	407A-32
	407B-32
09160-18031	113A-10
09160-39001	336A-9
	336B-8
09160-60012	220A-12
	220B-12
09162-10005	337A-35
	337B-33
09164-50002	220A-37
	220B-37
09168-10034	407A-15
	407B-15
09168-12012	180A-15
09168-12013	147A-16
09168-20002	160A-20
	160B-20
09169-06062	147A-58
	310A-5
09169-08038	401A-40
	401B-40
09169-08039	410A-20
	410B-20
09169-08042	147A-62
09169-28003	336B-11
09180-32006	220A-10
	220B-10
09181-12158	175A-9
09181-32035	220A-11-1
	220B-11-1
09181-32036	220A-11-2
	220B-11-2
09181-32037	220A-11-3
	220B-11-3
09181-32038	220A-11-4
	220B-11-4
09181-32039	220A-11-5
	220B-11-5
09181-32040	220A-11-6
	220B-11-6
09181-32041	220A-11-7
	220B-11-7
09181-32042	220A-11-8
	220B-11-8
09181-32043	220A-11-9
	220B-11-9
09181-32044	220A-11-10
	220B-11-10
09181-39001	336A-10
	336B-9
09181-60004	220A-7-1
	220B-7-1
09181-60005	220A-7-2
	220B-7-2
09181-60006	220A-7-3
	220B-7-3
09181-60007	220A-7-4
	220B-7-4
09181-60008	220A-7-5
	220B-7-5
09181-60009	220A-7-6
	220B-7-6
09181-60010	220A-7-7
	220B-7-7
09181-60011	220A-7-8
	220B-7-8
09181-60012	220A-7-9
	220B-7-9
09181-60013	220A-7-10
	220B-7-10
09181-93101	220A-14-1
	220B-14-1
09181-93102	220A-14-2
	220B-14-2
09181-93103	220A-14-3
	220B-14-3
09181-93104	220A-14-4
	220B-14-4
09181-93105	220A-14-5
	220B-14-5
09181-93106	220A-14-6
	220B-14-6
09181-93107	220A-14-7
	220B-14-7
09181-93108	220A-14-8
	220B-14-8
09181-93109	220A-14-9
	220B-14-9
09181-93110	220A-14-10
	220B-14-10
09181-93111	220A-14-11
	220B-14-11
09181-93112	220A-14-12
	220B-14-12
09181-93113	220A-14-13
	220B-14-13
09202-05032	121A-9
	121B-9
09202-06031	160A-18
	160B-18
	303A-3
	407A-24
	407B-24
09202-08006	180A-17
	180A-18
	405A-3
	405B-3
	405B-10
	405C-3
	407A-11
	407B-11
09202-08013	220A-19
	220B-19
09204-01006	204A-11
	204B-11
	336A-21
	336B-23
09204-03003	407A-33
	407B-33
09205-03004	206A-4
	206B-4
09205-10006	204A-12
	204B-12
09206-03001	407A-2
	407B-2
09206-08001	111A-3
	111A-7
	111A-27
	401A-8
	401A-16
	401B-8
	401B-16
09206-09012	206A-21
	206B-21
09206-13019	113A-13
09206-14004	111A-20
09208-06009	410A-47
	410B-47
09246-05006	113A-21
09247-14041	144A-11
09248-12009	180A-16
09248-12011	204A-13
	204B-13
09248-18006	113A-11
09248-26001	113A-9
09251-09005	144A-24
09260-10005	204A-14
	204B-14
09261-05006	121A-10
	121B-10
09262-17019	204A-15
	204B-15
09262-40017	119A-3
09262-40018	119A-2
09263-30063	220A-26
	220B-26
09263-35048	407A-3
	407B-3
09263-80001	407A-4
	407B-4
09263-80002	220A-13
	220B-13
09265-30033	220A-16
	220B-16
09265-32003	220A-27
	220B-27
09265-50004	220A-48
	220B-48
09265-55001	220A-49
	220B-49
09269-32002	220A-5
	220B-5
09280-00047	220A-28
	220B-28
09280-00050	220A-45
	220B-45
09280-06005	113A-20
09280-09008	180A-28
09280-10009	113A-15
	163A-9
09280-10016	113A-16
09280-22019	111A-14
	140A-8
	180A-5
09280-22020	175A-10
09280-26006	111A-32
	162A-14
09280-66004	220A-33
	220B-33
09280-70012	119A-6
09282-24004	220A-34
	220B-34
09282-30006	220A-29
	220B-29
09282-39001	336A-11
	336B-12
09283-10011	206A-7
	206B-7
09283-32044	119A-4
09283-91001	116A-13
09289-05012	121A-22
	121B-22
09289-18001	204A-16
	204B-16
09306-06005	204A-17
	204B-17
09306-10001	204A-18
	204B-18
09306-17001	337B-34
09306-17002	410A-29
	410B-29
09306-24001	337A-36
09320-08021	322A-9
09320-08062	144A-12
09320-08076	163A-24
09320-08086	147A-66
09320-08501	147A-11
09320-09016	310A-6
09320-11013	410A-21
	410B-21
09320-12014	162A-15
09320-12072	147A-33
09320-12076	310A-8
09321-10030	410A-13
	410A-22
	410B-13
	410B-22
09329-14002	410A-42
	410B-42
09343-70503-600	147A-55
09343-75001-600	147A-9
	147A-35
	147A-46
09352-50003-00A	147A-72
09352-50903-00B	162A-23
	162A-24
09352-50903-600	162A-16
	162A-17
	162A-18
	162A-19
	162A-20
	162A-21
	162A-22
09355-40805-600	407A-21-1
	407A-21-2
	407B-21-1
	407B-21-2
09360-12008	147A-17
09360-14009	144A-13
09362-09008	407A-22
	407B-22
09363-08004	147A-18
09367-06002	162A-26
09380-17009	337B-35
09380-21002	337A-37
09380-38003	336A-12
	336B-10
09381-22010	116A-4
09381-40003	220A-30
	220A-35
	220B-30
	220B-35
09381-72003	220A-38
	220B-38
09383-04002	410A-48
	410B-48
09383-07003	206A-13
	206B-13
09383-08004	204A-19
	204B-19
09385-06012	204A-28
	204B-28

PART NO.	FIG.NO.-REF.NO.
09387-38002	405A-5
	405B-5
09401-08412	147A-73
09401-08413	162A-27
09401-11414	147A-36
09401-11423	147A-56
09401-11425	144A-14
09401-13423	144A-20
	163A-21
09401-14409	162A-28
09401-15414	162A-37
09401-18410	136A-7
09401-25406	162A-29
09403-07340	315A-19
	315B-18
09403-09316	326A-17-2
	326B-17
09403-11315	326A-14
	326B-14
09403-13310	163A-25
09403-13402	522A-23
09403-13408	303A-13
09403-14304	147A-67
09403-16307	144A-15
09403-19409	315A-9
	315B-9
09403-20308	322A-23
09403-25304	162A-30
09407-08401	530A-14
09407-10404	326A-9
	326B-9
	407A-23
	407B-23
	522A-3
09407-14407	315A-11
	315B-11
	322A-24
	326A-17-1
	331A-12
	535A-20
09407-25402	410A-44
	410B-44
09407-30401	326A-22
	326B-22
09408-00008	162A-31
	322A-25
09408-00012	322A-27
09408-00021	162A-40
	310A-13
09408-00024	162A-39
	322A-28
09408-00050	147A-75
09408-00056	147A-74
	162A-32
09408-00105	144A-16
09408-00135	144A-21
09408-00155	144A-17
	163A-26
09408-00184	322A-26
09409-05302-5PK	410A-9
	410B-9
09420-05009	160A-19
	160A-28
	160B-19
	160B-28
09440-07051	204A-20
	204B-20
09440-19028	336A-22
	336B-24
09440-58001	220A-21
	220B-21
09443-10043	336A-23
	336B-25
09481-10501	522A-14
09481-10504	322A-4
09481-15504	322A-12
09481-30501	523A-2
09481-30504	322A-13
09481-40401	522A-4
09481-40403	322A-14
09481-60403	322A-15
09482-00427	111A-33
09800-81835	420A-34
	420B-34
PART NO.	FIG.NO.-REF.NO.
PART NO.	FIG.NO.-REF.NO.
PART NO.	FIG.NO.-REF.NO.

SUZUKI **DF300AP/250AP** PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved
No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION
Service Material Development Group, Service Engineering Department
300 Takatsuka, Minami, Hamamatsu, Japan

Copyright © SUZUKI MOTOR CORPORATION 2018 All Rights Reserved

SUZUKI MOTOR CORPORATION

PRINTED IN JAPAN

9900B-45418